



## INSTALLATION MANUAL

# AIR-TO-WATER HEAT PUMP

---



Please read this installation manual completely before installing the product.

### Original instruction

|                     |                    |                     |                       |
|---------------------|--------------------|---------------------|-----------------------|
| <b>EN ENGLISH</b>   | <b>IT ITALIANO</b> | <b>ES ESPAÑOL</b>   | <b>FR FRANÇAIS</b>    |
| <b>DE DEUTSCH</b>   | <b>EL ΕΛΛΗΝΙΚΑ</b> | <b>CZ ČEŠTINA</b>   | <b>NL NEDERLANDS</b>  |
| <b>PL POLSKI</b>    | <b>RO ROMÂNĂ</b>   | <b>PT PORTUGUÊS</b> | <b>HU MAGYAR</b>      |
| <b>BG БЪЛГАРСКИ</b> | <b>SR SRPSKI</b>   | <b>HR HRVATSKI</b>  | <b>SL SLOVENŠČINA</b> |
| <b>DA DANSK</b>     |                    |                     |                       |

### Outdoor Unit

[HM091 / 071 / 051MRS UA40]

[HM161 / 141 / 121MRS UB40]

[HM163 / 143 / 123MRS UB40]

# TABLE OF CONTENTS

|                                                                   |           |
|-------------------------------------------------------------------|-----------|
| <b>SAFETY INSTRUCTIONS .....</b>                                  | <b>5</b>  |
| READ ALL INSTRUCTIONS BEFORE USE .....                            | 5         |
| Safety Messages .....                                             | 5         |
| Notes for Flammable Refrigerant.....                              | 6         |
| <b>INSTALLATION PART.....</b>                                     | <b>19</b> |
| <b>GENERAL INFORMATION .....</b>                                  | <b>21</b> |
| Model information .....                                           | 21        |
| Parts and Dimensions .....                                        | 22        |
| Control Parts .....                                               | 26        |
| Remote Controller.....                                            | 28        |
| Typical Installation Example .....                                | 29        |
| Cycle Diagram .....                                               | 30        |
| Wiring Diagram .....                                              | 31        |
| <b>INSTALLATION OF OUTDOOR UNIT.....</b>                          | <b>34</b> |
| Conditions to be considered when installing the outdoor unit..... | 34        |
| Minimum Operation Space .....                                     | 35        |
| Multiple installation .....                                       | 36        |
| Installation at Seaside .....                                     | 38        |
| Seasonal wind and cautions in winter.....                         | 39        |
| Transporting the Unit .....                                       | 40        |
| Foundation for Installation.....                                  | 42        |
| <b>ELECTRICAL WIRING .....</b>                                    | <b>44</b> |
| General considerations and warnings .....                         | 44        |
| <b>WATER PIPING .....</b>                                         | <b>55</b> |
| Water Piping and Water Circuit Connection.....                    | 55        |
| Water pump Capacity .....                                         | 59        |
| Pressure Drop .....                                               | 59        |
| Performance curve.....                                            | 60        |
| Water Quality .....                                               | 62        |
| Frost protection by antifreeze .....                              | 62        |
| Frost protection by antifreeze valve .....                        | 63        |
| Water Volume and Expansion Vessel Pressure .....                  | 65        |
| <b>ACCESSORIES INSTALLATION .....</b>                             | <b>66</b> |
| Before Installation .....                                         | 69        |
| Thermostat.....                                                   | 69        |
| 2nd Circuit.....                                                  | 72        |
| 3rd Party Boiler .....                                            | 75        |
| 3rd Party Controller .....                                        | 76        |
| Meter Interface .....                                             | 77        |



|                                                                             |            |
|-----------------------------------------------------------------------------|------------|
| Central Controller .....                                                    | 79         |
| DHW Tank.....                                                               | 80         |
| DHW Tank Kit .....                                                          | 83         |
| Solar Thermal Kit .....                                                     | 85         |
| Buffer Tank temperature sensor .....                                        | 87         |
| Dry Contact .....                                                           | 88         |
| External Controller - Setting up programmable digital input operation ..... | 90         |
| Remote Controller.....                                                      | 91         |
| Remote Temperature Sensor .....                                             | 95         |
| Solar pump .....                                                            | 97         |
| External pump.....                                                          | 98         |
| Wi-Fi Modem .....                                                           | 99         |
| Energy State .....                                                          | 100        |
| Digital Input for energy saving (ESS, Smart Grid).....                      | 101        |
| 2Way Valve .....                                                            | 102        |
| 3Way Valve(A).....                                                          | 103        |
| Wall-mounted air sensor .....                                               | 104        |
| Electric Heater .....                                                       | 105        |
| Typical Installation Example .....                                          | 109        |
| Final check .....                                                           | 111        |
| <b>CONFIGURATION .....</b>                                                  | <b>112</b> |
| DIP Switch Setting .....                                                    | 112        |
| <b>SERVICE SETTING .....</b>                                                | <b>118</b> |
| How to enter service setting .....                                          | 118        |
| Service setting .....                                                       | 118        |
| Service contact .....                                                       | 119        |
| <b>INSTALLER SETTING .....</b>                                              | <b>120</b> |
| How to enter installer setting .....                                        | 120        |
| Installer setting .....                                                     | 121        |
| Installer settings in detail .....                                          | 146        |
| Auto mode - Seasonal auto temp. ....                                        | 161        |
| Domestic hot water - DHW temperature settings .....                         | 162        |
| Domestic hot water - Thermal disinfection .....                             | 163        |
| Domestic hot water - DHW heating duration.....                              | 164        |
| Domestic hot water - DHW electric re-heating.....                           | 164        |
| Domestic hot water - DHW re-circulation .....                               | 165        |
| Solarthermal system - Solar collector operating range.....                  | 166        |
| Solarthermal system - Solar tank temp. limit.....                           | 166        |
| Solarthermal system - Solathermal dT .....                                  | 166        |
| Service - Pump test run .....                                               | 167        |
| Service - Actuator test - Test mode .....                                   | 167        |

Service - Actuator test - Pump test.....167

Service - Actuator test - Valve test.....167

Service - Frost protection temperature .....168

Connectivity - Modbus address(HEX) .....169

Connectivity - CN\_EXT .....173

Connectivity - 3rd party boiler .....174

Connectivity - Energy state .....176

**COMMISSIONING.....177**

    Check List before Starting Operation.....177

    Starting Operation.....179

    Starting Operation flow chart.....179

    Trouble shooting .....180

**ANNEX.....189**

# SAFETY INSTRUCTIONS

## READ ALL INSTRUCTIONS BEFORE USE

The following safety guidelines are intended to prevent unforeseen risks or damage from unsafe or incorrect operation of the appliance.

### Safety Messages



This symbol is displayed to indicate matters and operations that can cause risk.

Read the part with this symbol carefully and follow the instructions in order to avoid risk.



### **WARNING**

This indicates that the failure to follow the instructions can cause serious injury or death.



### **CAUTION**

This indicates that the failure to follow the instructions can cause the minor injury or damage to the product.

## Notes for Flammable Refrigerant

The following symbols are displayed on units.



This appliance is filled with flammable refrigerant (for R32)



This symbol indicates that the Installation Manual should be read carefully.



This symbol indicates that service personnel should be handling this equipment with reference to the Installation Manual.



This symbol indicates that information is available in the Owner's Manual or Installation Manual.

## WARNING

### Installation

- Do not use a defective or underrated circuit breaker. Use this appliance on a dedicated circuit.
  - There is risk of fire or electric shock.
- For electrical work, contact the dealer, seller, a qualified electrician, or an Authorized Service Center.
  - There is risk of fire or electric shock.
- Always ground the unit.
  - There is risk of fire or electric shock.
- Install the panel and the cover of control box securely.
  - There is risk of fire or electric shock.
- Always install a dedicated circuit and breaker.
  - Improper wiring or installation may cause fire or electric shock.

- Use the correctly rated breaker or fuse.
  - There is risk of fire or electric.
- Do not modify or extend the power cable.
  - There is risk of fire or electric shock.
- Do not install, remove, or reinstall the unit by yourself (customer).
  - There is risk of fire, electric shock, explosion, or injury
- For antifreeze, always contact the dealer or an authorized service center.
  - Almost the antifreeze is a toxic product.
- For installation, always contact the dealer or an authorized Service Center.
  - There is risk of fire, electric shock, explosion, or injury.
- Do not install the unit on a defective installation stand.
  - It may cause injury, accident, or damage to the unit.
- Be sure the installation area does not deteriorate with age.
  - If the base collapses, the unit could fall with it, causing property damage, unit failure, and personal injury.
- Do not install the water pipe system as Open loop type.
  - It may cause failure of unit.
- Use a vacuum pump or inert (nitrogen) gas when doing leakage test or purging air. Do not compress air or oxygen and do not use flammable gases.
  - There is the risk of death, injury, fire or explosion.
- Make sure the connected condition of connector in product after maintenance.
  - Otherwise, it may cause product damage.
- Do not touch leaked refrigerant directly.
  - There is risk of frostbite.
- Copper in contact with refrigerants shall be oxygen-free or deoxidized, for example Cu-DHP as specified in EN 12735-1 and EN 12735-2.

- Compliance with national gas regulations shall be observed. (for R32)
- Refrigerant tubing shall be protected or enclosed to avoid damage. (for R32)
- The installation of pipe-work shall be kept to a minimum. (for R32)
- A brazed, welded, or mechanical connection shall be made before opening the valves to permit refrigerant to flow between the refrigerating system parts. A vacuum valve shall be provided to evacuate the interconnecting pipe and/or any uncharged refrigerating system part. (for R32)
- Any person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorises their competence to handle refrigerants safely in accordance with an industry recognised assessment specification. (for R32)
- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. (for R32)
- Do not pierce or burn. (for R32)
- Be aware that refrigerants may not contain an odour. (for R32)
- Dismantling the unit, treatment of the refrigerant oil and eventual parts should be done in accordance with local and national standards. (for R32)
- Flexible refrigerant connectors (such as connecting lines between the indoor and outdoor unit) that may be displaced during normal operations shall be protected against mechanical damage. (for R32)
- Pipe-work shall be protected from physical damage. (for R32)
- Mechanical connections (mechanical connectors or flared joints) shall be accessible for maintenance purposes. (for R32)

- **Ventilated area**

Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

- **Cabling**

Cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

## Operation

- Take care to ensure that power cable could not be pulled out or damaged during operation.
  - There is risk of fire or electric shock.
- Do not place anything on the power cable.
  - There is risk of fire or electric shock.
- Do not plug or unplug the power supply plug during operation.
  - There is risk of fire or electric shock.
- Do not touch (operate) the unit with wet hands.
  - There is risk of fire or electric shock.
- Do not place a heater or other appliances near the power cable.
  - There is risk of fire or electric shock.
- Do not allow water to run into electric parts.
  - There is risk of fire, failure of the unit, or electric shock.

- Do not store or use flammable gas or combustibles near the unit.
  - There is risk of fire or failure of unit.
- Do not use the unit in a tightly closed space for a long time.
  - It may cause damage to the unit.
- When flammable gas leaks, turn off the gas and open a window for ventilation before turning the unit on.
  - There is risk of explosion or fire.
- If strange sounds, or smell or smoke comes from unit, turn the breaker off or disconnect the power supply cable.
  - There is risk of electric shock or fire.
- Stop operation and close the window in storm or hurricane. If possible, remove the unit from the window before the hurricane arrives.
  - There is risk of property damage, failure of unit, or electric shock.
- Do not open the front cover of the unit while operation. (Do not touch the electrostatic filter, if the unit is so equipped.)
  - There is risk of physical injury, electric shock, or unit failure.
- Do not touch any electric part with wet hands. you should be power off before touching electric part.
  - There is risk of electric shock or fire.
- Do not touch refrigerant pipe and water pipe or any internal parts while the unit is operating or immediately after operation.
  - There is risk of burns or frostbite, personal injury.
- If you touch the pipe or internal parts, you should be wear protection or wait time to return to normal temperature.
  - Otherwise , it may cause burns or frostbite, personal injury.
- Turn the main power on 6 hours ago before the product starting operation.
  - Otherwise, it may cause compressor damage.



- Do not touch electric parts for 10 minutes after main power off.
  - There is risk of physical injury, electric shock.
- The inside heater of product may operate during stop mode. It is intended to protect the product.
- Be careful that some part of the control box are hot.
  - There is risk of physical injury or burns.
- When the unit is soaked (flooded or submerged), contact an Authorized Service Center.
  - There is risk of fire or electric shock.
- Be cautious that water could not be poured to the unit directly.
  - There is risk of fire, electric shock, or unit damage.
- Ventilate the unit from time to time when operating it together with a stove, etc.
  - There is risk of fire or electric shock.
- Turn the main power off when cleaning or maintaining the unit.
  - There is risk of electric shock.
- Take care to ensure that nobody could step on or fall onto the unit.
  - This could result in personal injury and unit damage.
- If the unit is not used for long time, we strongly recommend not to switch off the power supply to the unit.
  - There is risk of water freezing.
- The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation. (for R32)
- The appliance shall be stored in a room without continuously operating open flames (for example an operating gas appliance) and ignition sources (for example an operating electric heater). (for R32)
- The appliance shall be stored so as to prevent mechanical damage from occurring. (for R32)

- Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants. (for R32)
- When mechanical connectors are reused indoors, sealing parts shall be renewed. When flared joints are reused indoors, the flare part shall be re-fabricated. (for R32)
- Periodic(more than once/year) cleaning of the dust or salt particles stuck on the heat exchangers by using water. (for R32)
- Keep any required ventilation openings clear of obstruction. (for R32)

## **Repair**

- **Detection of flammable refrigerants**

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks.

A halide torch (or any other detector using a naked flame) shall not be used.

- **Leak detection methods**

The following leak detection methods are deemed acceptable for systems containing flammable refrigerants. Electronic leak detectors shall be used to detect flammable refrigerants, but the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed and the appropriate percentage of gas (25 % maximum) is confirmed.

Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.

---

**NOTE**

Examples of leak detection fluids are

- Bubble method
  - Fluorescent method agents
- 

If a leak is suspected, all naked flames shall be removed/extinguished. If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak. Removal of refrigerant shall be according to removal and evacuation procedure.

• **Charging procedures**

In addition to conventional charging procedures, the following requirements shall be followed.

- Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimise the amount of refrigerant contained in them.
- Cylinders shall be kept in an appropriate position according to the instruction.
- Ensure that the refrigeration system is earthed prior to charging the system with refrigerant.
- Label the system when charging is complete (if not already).
- Extreme care shall be taken not to overfill the refrigerating system. Prior to recharging the system, it shall be pressure tested with the appropriate purging gas.

The system shall be leak-tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.

- **Recovery**

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed.

Ensure that the correct number of cylinders for holding the total system charge are available.

All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant).

Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order.

Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of flammable refrigerants. In addition, a set of calibrated weighing scales shall be available and in good working order.

Hoses shall be complete with leak-free disconnect couplings and in good condition. Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt.

The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste Transfer Note arranged.

Do not mix refrigerants in recovery units and especially not in cylinders. If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant.

The evacuation process shall be carried out prior to returning the compressor to the suppliers.

Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.

#### • **Removal and evacuation**

When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants it is important that best practice is followed since flammability is a consideration.

The following procedure shall be adhered to:

- Remove refrigerant;
- Purge the circuit with inert gas (optional for A2L);
- Evacuate (optional for A2L);
- Purge with inert gas (optional for A2L);
- Open the circuit by cutting or brazing

The refrigerant charge shall be recovered into the correct recovery cylinders. For appliances containing flammable refrigerants other than A2L refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerants. This process may need to be repeated several times.

Compressed air or oxygen shall not be used for purging refrigerant systems.

For appliances containing flammable refrigerants, other than A2L refrigerants, refrigerants purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum.

This process shall be repeated until no refrigerant is within the system. When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place. This operation is absolutely vital if brazing operations on the pipe-work are to take place. Ensure that the outlet for the vacuum pump is not close to any potential ignition sources and that ventilation is available.

## CAUTION

### Installation

- Always check for gas (refrigerant) leakage after installation or repair of unit.
  - Low refrigerant levels may cause failure of unit.
- Keep level even when installing the unit.
  - To avoid vibration or water leakage.
- Use two or more people to lift and transport the unit.
  - Avoid personal injury.
- In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.
- Do not install the unit in potentially explosive atmospheres.
- The water may drip from the discharge pipe of the pressure-relief device and that this pipe must be left open to the atmosphere.

- The pressure-relief device is to be operated regularly to remove lime deposits and to verify that it is not blocked.
- A discharge pipe connected to the pressure-relief device is to be installed in a continuously downward direction and in a frost-free environment.

## Operation



- Do not use the unit for special purposes, such as preserving foods, works of art, etc.
  - There is risk of damage or loss of property.
- Use a soft cloth to clean. Do not use harsh detergents, solvents, etc.
  - There is risk of fire, electric shock, or damage to the plastic parts of the unit.
- Do not step on or put anything on the unit.
  - There is risk of personal injury and failure of unit.
- Use a firm stool or ladder when cleaning or maintaining the unit.
  - Be careful and avoid personal injury.
- Do not turn on the breaker or power under condition that front panel cabinet, top cover, control box cover are removed or opened.
  - Otherwise it may cause fire, electric shock, explosion or death.
- The appliance shall be disconnected from its power source during service and when replacing parts.
- Means for disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.
- The Installation kit supplied with the appliance are to be used and that old Installation kit should not be reused.

- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. Installation work must be performed in accordance with the national wiring standards by authorized personnel only.
- This equipment shall be provided with a supply conductor complying with the national regulation.
- The instructions for service to be done by specialized personnel, mandated by the manufacturer or the authorized representative may be supplied in only one Community language which the specialized personnel understand.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.






# INSTALLATION PART

Thank you for choosing LG Electronics Air-to-Water Heat Pump **THERMAV**.  
Before starting installation, please make it sure that all parts are found inside the product box.  
\*The parts can be found inside the outdoor unit by opening the side panel.

| Item                                                                              | Image                                                                               | Item                                                  | Image                                                                               |
|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------|-------------------------------------------------------------------------------------|
| Installation Manual<br>(1 Sheet)                                                  |    | Remote Controller<br>Cable<br>(Default length : 10 m) |    |
| Owner's / Installation<br>manual (Simple)                                         |    | Damper (x 4)                                          |    |
| Outdoor Unit<br>UN36A Chassis<br>(Product heating<br>capacity : 5, 7, 9 kW)       |    | Drain Cap (x 7)                                       |    |
| Outdoor Unit<br>UN36B Chassis<br>(Product heating<br>capacity :<br>12, 14, 16 kW) |    | Drain Nipple                                          |    |
| Remote Controller                                                                 |  | Strainer                                              |  |

INSTALLATION TOOLS

| Figure                                                                              | Name                  | Figure                                                                            | Name                             |
|-------------------------------------------------------------------------------------|-----------------------|-----------------------------------------------------------------------------------|----------------------------------|
|    | Screw driver          |  | Ohmmeter                         |
|    | Electric drill        |  | Ammeter                          |
|    | Measuring tape, Knife |  | Leak detector                    |
|    | Hole core drill       |  | Thermometer,<br>Horizontal meter |
|    | Spanner               |  | Fire extinguisher                |
|  | Torque wrench         |                                                                                   |                                  |

# GENERAL INFORMATION

## Model information

Additional information about all possible combinations including Energy labels and ErP datasheets can be found on following website:

<https://www.lg.com/global/support/cedoc/cedoc>

## NOTE

Search for outdoor unit's model name on that website.

## Operating condition

- Maximum operating temperature of water : 65 °C
- Minimum operating temperature of water : 15 °C
- Maximum inlet water pressure : 0.3 MPa
- Minimum inlet water pressure : 0.03 MPa

## Buyer Model Name

### Outdoor unit

| Refrigerant | No. |   |    |   |   |   |   |     |   |
|-------------|-----|---|----|---|---|---|---|-----|---|
|             | 1   | 2 | 3  | 4 | 5 | 6 | 7 | 8   | 9 |
| R32         | H   | M | 16 | 1 | M | R | S | UB4 | 0 |


| No. | Signification                                                                |
|-----|------------------------------------------------------------------------------|
| 1   | Air-to-Water-Heat Pump                                                       |
| 2   | Classification<br>- M : Monobloc                                             |
| 3   | Heating Capacity<br>- E.g) 9 kW '09'<br>- E.g) 16 kW '16'                    |
| 4   | Electrical ratings<br>- 1 : 1Ø 220-240 V~ 50 Hz<br>- 3 : 3Ø 380-415 V~ 50 Hz |
| 5   | Leaving Water Combination<br>- M : Middle Temperature                        |
| 6   | Refrigerant<br>- R : R32                                                     |
| 7   | Function<br>- S : Solo                                                       |
| 8   | Chassis Name<br>- UA4 : UN36A Chassis<br>- UB4 : UN36B Chassis               |
| 9   | Series Number                                                                |

# Parts and Dimensions

## Outdoor unit : External

[HM091 / 071 / 051MRS UA40]

(Unit : mm)



## Description



| No | Name                                   |
|----|----------------------------------------|
| 1  | Entering Water Pipe (Male PT 1 inch)   |
| 2  | Leaving Water Pipe (Male PT 1 inch)    |
| 3  | Air discharge Grille                   |
| 4  | UNIT Power (Power Cable Hole)          |
| 5  | Low Voltage (Communication Cable Hole) |

**Outdoor unit : External**

[HM161 / 141 / 121MRS UB40]

[HM163 / 143 / 123MRS UB40]

(Unit : mm)


**Description**

| No | Name                                   |
|----|----------------------------------------|
| 1  | Entering Water Pipe (Male PT 1 inch)   |
| 2  | Leaving Water Pipe (Male PT 1 inch)    |
| 3  | Air discharge Grille                   |
| 4  | UNIT Power (Power Cable Hole)          |
| 5  | Low Voltage (Communication Cable Hole) |

**Outdoor unit : Internal**

[HM091 / 071 / 051MRS UA40]

(Unit : mm)



**Description**



| No | Name                    | Remark                                     |
|----|-------------------------|--------------------------------------------|
| 1  | Compressor              | Increase pressure of the refrigerant.      |
| 2  | Fin tube Heat Exchanger | Heat exchange between refrigerant and air. |
| 3  | Fan                     | Circulating the air.                       |
| 4  | Control Box             | PCB and terminal blocks.                   |

**Outdoor unit : Internal**



[HM161 / 141 / 121MRS UB40]

[HM163 / 143 / 123MRS UB40]

(Unit : mm)



Drain holes closed with caps (8 EA)  
NOTE: If you need more drains, remove them


**Description**

| No | Name                    | Remark                                     |
|----|-------------------------|--------------------------------------------|
| 1  | Compressor              | Increase pressure of the refrigerant.      |
| 2  | Fin tube Heat Exchanger | Heat exchange between refrigerant and air. |
| 3  | Fan                     | Circulating the air.                       |
| 4  | Control Box             | PCB and terminal blocks.                   |

# Control Parts

## Control Box

[HM091 / 071 / 051MRS UA40]




## Description

| No | Name            | Remark                                                                                                 |
|----|-----------------|--------------------------------------------------------------------------------------------------------|
| 1  | Terminal blocks | The terminal blocks allow easy connection of field wiring                                              |
| 2  | Main PCB        | The main PCB(Printed Circuit Board) controls the functioning of the unit and the connected accessories |
| 3  | Cycle PCB       | The cycle PCB(Printed Circuit Board) controls the functioning of the unit                              |



[HM161 / 141 / 121MRS UB40]

[HM163 / 143 / 123MRS UB40]




### Description

| No | Name             | Remark                                                                                                 |
|----|------------------|--------------------------------------------------------------------------------------------------------|
| 1  | Terminal blocks* | The terminal blocks allow easy connection of field wiring                                              |
| 2  | Main PCB         | The main PCB(Printed Circuit Board) controls the functioning of the unit and the connected accessories |
| 3  | Cycle PCB        | The cycle PCB(Printed Circuit Board) controls the functioning of the unit                              |

\* The feature may be vary according to the type of model.

# Remote Controller




|                           |                                                                                  |
|---------------------------|----------------------------------------------------------------------------------|
| Operation display window  | - Operation and Settings status display                                          |
| Back button               | - Home screen: Show 'Monitoring screen'<br>- Other cases: Move to previous stage |
| Up/down/left/right button | - Navigate within menu and setting options<br>- Change values                    |
| OK button                 | - Enter menu<br>- Confirm settings                                               |
| On/Off button             | - Turn on/off the heat pump<br>- Enable/Disable modes (Heat/Cool/DHW/Silent)     |

## Typical Installation Example

### ⚠ CAUTION

For detailed electric wiring and water piping, please contact authorized installer.  
It is recommended to install a buffer tank - unless minimum flow rate can be guaranteed elsewhere. Especially in older houses, it is recommended to use a magnetic filter.



※ It can be different by model.

### NOTE


The exemplary diagram does not include all necessary safety and installation devices.  
This is not an 'as-built drawing'.

### Description

|  |                     |  |                             |  |                                               |  |                        |
|--|---------------------|--|-----------------------------|--|-----------------------------------------------|--|------------------------|
|  | Circulation Pump    |  | Motorized 3 Way Valve       |  | Check Valve                                   |  | RS3 Remote Controller  |
|  | Expansion Tank      |  | Motorized 2 Way Valve       |  | Safety Relief Expansion Tank Valve with drain |  | Remote Room Air Sensor |
|  | Automatic air vent  |  | Differential Pressure Valve |  | Y-type strainer                               |  | Dry Contact            |
|  | Pressure Gauge      |  | Thermostatic Mixing Valve   |  | Flow Sensor                                   |  | Wi-Fi Modem            |
|  | Flexible Connection |  | Shut Off Valve              |  | Magnetic Contactor                            |  | Thermostat             |
|  | Drain               |  | Pressure Reducing Valve     |  | Drain Pan                                     |  | Cover Plate            |
|  | Manual air vent     |  |                             |  |                                               |  |                        |

※ For more installation scenes, visit <http://partner.lge.com/> or contact your local LG office.  
Select Region → Doc. Library → (Product) Heating → Application Guide → Referenced Drawing for Application


# Cycle Diagram



## Description

| Category         | Symbol | Meaning                                    |
|------------------|--------|--------------------------------------------|
| Refrigerant side | S2     | Outdoor-HEX middle temp. sensor            |
|                  | S3     | Compressor discharge temp. sensor          |
|                  | S4     | Compressor suction pipe temp. sensor       |
|                  | S5     | Outdoor-HEX temp. sensor                   |
|                  | S6     | Outdoor air temp. sensor                   |
|                  | S7     | Compressor-injection pipe IN temp. sensor  |
|                  | S10    | PHEX liquid temp. sensor                   |
| Water Side       | S11    | Inlet water temp. sensor                   |
|                  | S12    | Outlet water temp. sensor                  |
|                  | S13    | Electric backup heater outlet temp. sensor |
|                  | S17    | Flow sensor                                |
|                  | S19    | Water pressure sensor                      |








# INSTALLATION OF OUTDOOR UNIT


The outdoor unit is installed outside to exchange heat with ambient air. Therefore, it is important to secure proper space around the outdoor unit and care for specific external conditions. This chapter presents a guide to install the outdoor unit, make a route to connect with the indoor, and what to do when installed around seaside.

## Conditions to be considered when installing the outdoor unit

For noise reduction



For good ventilation



### NOTE

- Please do not block the slits in the exterior panels!


※ It can be different by model.



# Minimum Operation Space

Following distances around the outdoor unit must be respected under any condition for normal operation. The distances are only for operation not to be seen as safety zone.

## Installation space around each unit



## Multiple installation

|  |  |
|--|--|
|  |  |
|  |  |
|  |  |


※ It can be different by model.

# Multiple installation

When installing two or more units, please observe the installation space.


- If there is an obstruction in the intake

Unit : mm



- If there is an obstruction in the discharge part


Unit : mm




- When there is an obstacle in the suction or discharge part

Unit : mm


$L > H$




$L > H$



$L \leq H$





$L \leq H$



- Multiple installation on the roof

Unit : mm

$L \leq H$




## Installation at Seaside

### ⚠ CAUTION


- Unit should not be installed in areas where corrosive gases, such as acid or alkaline gas, are produced.
- Do not install the product where it could be exposed to sea wind (salty wind) directly. It can result corrosion on the product. Corrosion, particularly on the condenser and evaporator fins, could cause product malfunction or inefficient performance.
- If outdoor unit is installed close to the seaside, it should avoid direct exposure to the sea wind. Otherwise it needs additional anti-corrosion treatment on the heat exchanger.

### Selecting the location(Outdoor Unit)

- If the outdoor unit is to be installed close to the seaside, direct exposure to the sea wind should be avoided. Install the outdoor unit on the opposite side of the sea wind direction.



- In case, to install the outdoor unit on the seaside, set up a windbreak not to be exposed to the sea wind.




- It should be strong enough like concrete to prevent the sea wind from the sea.
- The height and width should be more than 150% of the outdoor unit.
- It should be keep more than 700 mm of space between outdoor unit and the windbreak for easy air flow.
- Select a well-drained place. Periodic (more than once/year) cleaning of the dust or salt particles stuck on the heat exchanger by using water.
- If you can't meet above guide line in the seaside installation, please contact your supplier for the additional anti-corrosion treatment.

## Seasonal wind and cautions in winter

- Sufficient measures are required in a snow area or severe cold area in winter so that product can be operated well.
- Get ready for seasonal wind or snow in winter even in other areas.
- Install a suction and discharge duct not to let in snow or rain.
- Install the outdoor unit not to come in contact with snow directly. If snow piles up and freezes on the air suction hole, the system may malfunction. If it is installed at snowy area, attach the hood to the system.
- Install the outdoor unit at the higher installation console by 500 mm than the average snowfall (annual average snowfall) if it is installed at the area with much snowfall.
- Where snow accumulated on the upper part of the Outdoor Unit by more than 100 mm, always remove snow for operation.

### CAUTION



- The height of H frame must be more than 2 times the snowfall and its width shall not exceed the width of the product. (If width of the frame is wider than that of the product, snow may accumulate)
- Don't install the suction hole and discharge hole of the Outdoor Unit facing the seasonal wind.



※ It can be different by model.

## Transporting the Unit

- When carrying the suspended unit, pass the ropes between legs of base panel under the unit.
- Always lift the unit with ropes attached at four points so that impact is not applied to the unit.
- Attach the ropes to the unit at an angle  $\textcircled{A}$  of  $40^\circ$  or less.
- Use only accessories and parts which are of the designated specification when installing.
- Do not use a forklift without a pallet underneath the unit.
- Be careful not to damage the product when moving the forklift.



※ It can be different by model.

## CAUTION


**Be very careful while carrying the product.**

- Do not have only one person carry product if it is more than 20 kg.
- PP bands are used to pack some products. Do not use them as a mean for transportation because they are dangerous.
- Do not touch heat exchanger fins with your bare hands. Otherwise you may get a cut in your hands.
- Tear plastic packaging bag and scrap it so that children cannot play with it. Otherwise plastic packaging bag may suffocate children to death.
- When carrying the unit, be sure to support it at four points.  
Carrying in and lifting with 3-point support may make Outdoor Unit unstable, resulting in a fall.
- Use 2 belts of at least 8 m long.
- Place extra cloth or boards in the locations where the casing comes in contact with the sling to prevent damage.
- Hoist the unit making sure it is being lifted at its center of gravity.
- Do not tilt product by more than the maximum angle of 45°.

## Foundation for Installation

- Check the strength and level of the installation ground so that the unit will not cause any operating vibration or noise after installation.
- Fix the unit securely by means of the foundation bolts. Prepare 4 sets of M12 foundation bolts, nuts and washers available on the market.
- It is best to screw in the foundation bolts until their length are 20 mm from the foundation surface.
- When installing the unit on the ground, install a separate pedestal with enough height to install the drain nipple and higher than the average snowfall in your area.


[HM091 / 071 / 051MRS UA40]



[HM161 / 141 / 121MRS UB40]


[HM163 / 143 / 123MRS UB40]

(Unit : mm)



## ! WARNING


- Be sure that condensate does not discharge onto road to avoid accumulated freezing of condensate





- 1 Section of condensate drain pipe exposed to open air must be insulated.
- 2 If condensate is drained into a gravel-bed, the pipe must be directed into frost-free area. The gravel must be able to absorb up to 100 l of condensate per day.
- 3 If condensate water is drained into a rainwater sewer or other drainage pipe, note the slope of the pipe and make sure the pipe is frost-free.

(Unit : mm)



## ⚠ CAUTION

- Do not connect to a sewer that is connected to the interior, as leaked refrigerant may enter the building.

# ELECTRICAL WIRING

## General considerations and warnings

- Follow ordinance of your governmental organization for technical standard related to electrical equipment, wiring regulations and guidance of each electric power company.

---

### WARNING

- Be sure to have authorized electrical engineers do the electric work using special circuits in accordance with regulations and this installation manual. If power supply circuit has a lack of capacity or electric work deficiency, it may cause an electric shock or fire.
- 
- Install the Unit transmission line away from the power source wiring so that it is not affected by electric noise from the power source. (Do not run it through the same conduit.)
  - Be sure to provide designated grounding work to Unit.

---

### CAUTION

- Be sure to correct the unit to earth. Do not connect earth line to any gas pipe, liquid pipe, lightning rod or telephone earth line. If earth is incomplete, it may cause an electric shock.
- 
- Give some allowance to wiring for electrical part box of Units, because the box is sometimes removed at the time of service work.
  - Never connect the main power source to terminal block of transmission line. If connected, electrical parts will be burnt out.
  - Only the transmission line specified should be connected to the terminal block for Unit transmission.

---

### CAUTION

- This product have reversed phase protection detector that only works when the power is turned on. If there exists black out or the power goes on and off which the product is operating, attach a reversed phase protection circuit locally. running the product in reversed phase may break the compressor and other parts.
  - Use the 2-core shield cables for communication lines. Never use them together with power lines.
  - The conductive shielding layer of cable should be grounded to the metal part of both units.
  - Never use multi-core cable
  - As this unit is equipped with an inverter, to install a phase leading capacitor not only will deteriorate power factor improvement effect, but also may cause capacitor abnormal heating. Therefore, never install a phase leading capacitor.
  - Make sure that the power unbalance ratio is not greater than 2 %. If it is greater, the unit's lifespan will be reduced.
  - Introducing with a missing N-phase or with a mistaken N-phase will break the equipment
-

### General Consideration

Followings are should be considered before beginning indoor unit wiring.

- Field-supplied electrical components such as power switches, circuit breakers, wires, terminal boxes, etc should be properly chosen with compliance with national electrical legislation or regulation.
- Make it sure that supplied electricity is enough to operate the product including outdoor unit, electric heater, water tank heater, etc. The capacity of fuse also selected according to the power consumption.
- The main electricity supply should be dedicated line. Sharing main electricity supply with other devices such as washing machine or vacuum cleaner is not permitted.

### CAUTION

- Before starting wiring job, the main electricity supply should be turned off until wiring is completed.
- When adjusting or changing wiring, the main electricity supply should be turned off and ground wire should be connected securely.
- Installation place should be free from the attack of wild animal. For example, mice's wire attacking or frog's entering into the indoor unit may cause critical electrical accident.
- All power connections should be protected from dew condensation by thermal insulation.
- All electrical wiring should comply with national or local electrical legislation or regulation.
- The ground should be connected exactly. Do not earth the product to the copper pipe, steel fence at the veranda, city water outlet pipe, or any other conductivity materials.
- Fix all cable using cord clamp tightly. (When cable is not fixed with cord clamp, use additionally supplied cable ties.)

When the connection line between the indoor unit and outdoor unit is over 40 m, connect the telecommunication line and power line separately.

In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

**Point for attention regarding quality of the public electric power supply**

- European/International Technical Standard setting the limits for voltage changes, voltage fluctuations and flicker in public low-voltage supply systems for equipment with rated current  $\leq 75$  A.
  - European/International Technical Standard setting the limits for harmonic currents produced by equipment connected to public low-voltage systems with input current  $\leq 16$  A or  $> 75$  A per phase.
- 

**For 1 Phase (12, 14, 16 kW)**

- This equipment complies with IEC (EN) 61000-3-12 in harmonic currents emission limits corresponding  $R_{sce} = 33$ .
  - This equipment complies with IEC (EN) 61000-3-3.
- 

**For 3 Phase (12, 14, 16 kW)**

- This equipment complies with IEC (EN) 61000-3-12 provided that the short-circuit power  $S_{sc}$  is greater than or equal to 2428 kVA at the interface point between the user's supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a short-circuit power  $S_{sc}$  greater than or equal to 2428 kVA.
  - This equipment complies with IEC (EN) 61000-3-3.
- 

**For 1 Phase (5, 7, 9 kW)**

- This equipment complies with IEC (EN) 61000-3-2.
  - This equipment complies with IEC (EN) 61000-3-12 in harmonic currents emission limits corresponding  $R_{sce} = 33$ .
  - This equipment complies with IEC (EN) 61000-3-3.
-


## CAUTION

**After checking and confirming following conditions, start wiring work.**

- Secure dedicated power source for the Air-to-Water heat pump. The wiring diagram (attached inside the control box of the unit) is presenting related information.
- Provide a circuit breaker switch between power source and the outdoor unit.
- Although it is very rare case, sometimes the screws used to fasten internal wires can be loosen due to the vibration while product transportation.  
Check these screws and make it sure if they are all fastened tightly. If not tightened, burn-out of the wire can be occurred.
- Check the specification of power source such as phase, voltage, frequency, etc.
- Confirm that electrical capacity is sufficient.
- Be sure that the starting voltage is maintained at more than 90 percent of the rated voltage marked on the name plate.
- Confirm that the cable thickness is as specified in the power sources specification.  
(Particularly note the relation between cable length and thickness.)
- Always, the unit must be equipped with an Earth-leakage circuit breaker!
- The following troubles would be caused by abnormal voltage supply such as sudden voltage increasing or voltage drop-down.
  - Chattering of a magnetic switch (frequent on and off operation)
  - Physical damage of parts where magnetic switch is contacted
  - Break of fuse
  - Malfunction of overload protection parts or related control algorithms.
  - Failure of compressor start up
- Ground wire to ground outdoor unit to prevent electrical shock.


### Precautions when laying power wiring

Use round pressure terminals for connections to the power terminal block.



When none are available, follow the instructions below.

- Do not connect wiring of different thicknesses to the power terminal block. (Slack in the power wiring may cause abnormal heat.)
- When connecting wiring which is the same thickness, do as shown in the figure below.



- For wiring, use the designated power wire and connect firmly, then secure to prevent outside pressure being exerted on the terminal block.
- Use an appropriate manual screwdriver instead of electric screwdriver for tightening the terminal screws. A screwdriver with a small head will strip the head and make proper tightening impossible.
- Over-tightening the terminal screws may break them.

---

## WARNING


Make sure that the screws of the terminal are free from looseness.

---

### Perform the electrical wiring work according to the electrical wiring connection.

- All wiring must comply with local requirements.
- Select a power source that is capable of supplying the current required by the unit.
- Use a recognized ELCB(Electric Leakage Circuit Breaker) between the power source and the unit. A disconnection device to adequately disconnect all supply lines must be fitted.
- Model of circuit breaker recommended by authorized personnel only

\*Pipes and wires should be purchased separately for installation of the product.



※ It can be different by model.

### Description

| No | Name                               | No        | Name                                  |
|----|------------------------------------|-----------|---------------------------------------|
| 1  | Unit                               | 8         | DHW tank kit (PHLTB)*                 |
| 2  | Backup heater                      | 9         | Circuit breaker for DHW boost heater* |
| 3  | Remote controller                  | 10        | DHW boost heater*                     |
| 4  | Remote controller Connecting cable | 11        | Power supply for Unit                 |
| 5  | Power supply for Backup heater     | 12        | Connecting cable for Backup heater    |
| 6  | DHW tank*                          | 13        | Connecting cable for DHW tank kit     |
| 7  | Power supply for DHW boost heater* | *Optional |                                       |

ELCB : Earth-leakage circuit breaker

CB : Circuit breaker


Specification of wires and circuit breakers

|                              | Model name<br>(Buyer) | Power supply   | Power cable<br>(incl. Earth) | Cable spec | Circuit breaker |
|------------------------------|-----------------------|----------------|------------------------------|------------|-----------------|
| Power supply<br>Outdoor Unit | HM091MRS              | 220-240V 50 Hz | 4 mm <sup>2</sup> x 3C       | H07RN-F    | 25 A            |
|                              | HM071MRS              | 220-240V 50 Hz | 4 mm <sup>2</sup> x 3C       | H07RN-F    | 20 A            |
|                              | HM051MRS              | 220-240V 50 Hz | 4 mm <sup>2</sup> x 3C       | H07RN-F    | 16 A            |
|                              | HM161MRS              | 220-240V 50 Hz | 6 mm <sup>2</sup> x 3C       | H07RN-F    | 40 A            |
|                              | HM141MRS              | 220-240V 50 Hz | 6 mm <sup>2</sup> x 3C       | H07RN-F    | 40 A            |
|                              | HM121MRS              | 220-240V 50 Hz | 6 mm <sup>2</sup> x 3C       | H07RN-F    | 40 A            |
|                              | HM163MRS              | 380-415V 50 Hz | 4 mm <sup>2</sup> x 5C       | H07RN-F    | 16 A            |
|                              | HM143MRS              | 380-415V 50 Hz | 4 mm <sup>2</sup> x 5C       | H07RN-F    | 16 A            |
|                              | HM123MRS              | 380-415V 50 Hz | 4 mm <sup>2</sup> x 5C       | H07RN-F    | 16 A            |

※ Recommended diameter is feasible up to 20 m cable length. In any case, the diameter must be verified by professional electrician based on national rules and standards

 CAUTION

The power cord should be complied with IEC 60245 or HD 22.4 S4 (This equipment shall be provided with a cord set complying with the national regulation.)






## Electrical connections at outdoor unit

[HM091 / 071 / 051MRS UA40]

**Step 1.** Disassemble Side panel from the outdoor unit




**Step 2.** Connect power cable to main Power terminal

The earth cable is connected to the Control box case where earth symbol is  $\oplus$  marked.

**Step 3.** Use cable clamps (or cord clamps) to prevent unintended move of power cable.

**Step 4.** Reassemble Side panel to the outdoor unit by fastening screws.



Failure to do these instruction can result in fire, electric shock or death.


- Make sure the power cable do not touch to copper tube.
- Make sure to fix [cord clamp] firmly to sustain the connection of terminal.

[HM161 / 141 / 121MRS UB40]


[HM163 / 143 / 123MRS UB40]


**Step 1.** Disassemble Side panel from the outdoor unit

1 Phase(Ø), 3 Phase(Ø)

**Step 2.** Connect power cable to main Power terminalThe earth cable is connected to the Control box case where earth symbol is  $\oplus$  marked.**Step 3.** Use cable clamps (or cord clamps) to prevent unintended move of power cable.**Step 4.** Reassemble Side panel to the outdoor unit by fastening screws.

1 Phase(Ø)



**3 Phase(Ø)**

Failure to do these instruction can result in fire, electric shock or death.


- Make sure the power cable do not touch to copper tube.
- Make sure to fix [cord clamp] firmly to sustain the connection of terminal.

## Terminal Block Information

Symbols used below pictures are as follows :

- L, L1, L2 : Live (230 V AC)
- N : Neutral (230 V AC)
- BR : Brown, WH : White, BL : Blue, BK : Black

[HM091 / 071 / 051MRS UA40]



### Terminal Block 1

|                |   |                |   |          |   |           |    |   |
|----------------|---|----------------|---|----------|---|-----------|----|---|
| 1              | 2 | 3              | 4 | 5        | 6 | 7         | 8  | 9 |
| L              | N | L              | N | L        | N | L1        | L2 | N |
| WATER PUMP (C) |   | WATER PUMP (B) |   | MIX PUMP |   | MIX VALVE |    |   |

Energizing water pump for DHW-recirculation

Energizing water pump for solar thermal system

Power supply for 2nd circuit heating kit

|                |    |    |                |    |    |                                 |    |    |    |    |
|----------------|----|----|----------------|----|----|---------------------------------|----|----|----|----|
| 10             | 11 | 12 | 13             | 14 | 15 | 16                              | 17 | 18 | 19 | 20 |
| L              | L1 | N  | L1             | L2 | N  | L                               | N  | L1 | L2 | L3 |
| 3WAY VALVE (A) |    |    | 2WAY VALVE (A) |    |    | THERMOSTAT (Default : 230 V AC) |    |    |    |    |

Water flow switching between space heating and DHW tank heating

Closing other circuits during cooling operation

Connection for thermostat (230 V AC)  
Supporting type: Heating only or Heating/Cooling

### Terminal Block 2

|                      |    |
|----------------------|----|
| 21                   | 22 |
| A                    | B  |
| 3rd PARTY CONTROLLER |    |

Connection for 3rd party controller or Modbus RTU or Metering module (5 V DC)

### Terminal Block 3

|                   |    |
|-------------------|----|
| 23                | 24 |
| L                 | N  |
| WATER TANK HEATER |    |

Turn on or off booster heater

### Terminal Block 4 (Accessory)

|                           |    |
|---------------------------|----|
| 31                        | 32 |
| A                         | BK |
| E/HEATR OUT SENSOR(5V DC) |    |

### Terminal Block 5

#### 1 Phase(Ø)


|                                     |      |  |  |  |
|-------------------------------------|------|--|--|--|
| 1(L)                                | 2(N) |  |  |  |
| POWER SUPPLY (1Ø, 220-240 V, 50 Hz) |      |  |  |  |

#### 3 Phase(Ø)

|                                     |   |   |   |  |  |  |
|-------------------------------------|---|---|---|--|--|--|
| R                                   | S | T | N |  |  |  |
| POWER SUPPLY (3Ø, 380-415 V, 50 Hz) |   |   |   |  |  |  |

[HM161 / 141 / 121MRS UB40]

[HM163 / 143 / 123MRS UB40]



\* The feature may vary according to the type of model.

# WATER PIPING

Procedures about water piping and electric wiring at the indoor unit are described in this chapter.

Water piping and water circuit connection, water charging, pipe insulations will be shown for water piping procedures. For wiring, terminal block connection, connecting with the outdoor unit, electric heater wiring will be introduced.

Accessories connection, such as sanitary water tank, thermostat, 3way or 2way valves, etc will be dealt in separated chapter.

## Water Piping and Water Circuit Connection

### CAUTION

#### General Considerations

Followings are should be considered before beginning water circuit connection.

- Service space should be secured.
- Water pipes and connections should be cleaned using water.
- Space for installing external water pump should be provided if internal water pump capacity is not enough for installation field.
- Never connect electric power while proceeding water charging.

#### Definition of terms are as follow :

- Water piping : Installing pipes where water is flowing inside the pipe.
- Water circuit connecting : Making connection between the product and water pipes or between pipes and pipes. Connecting valves or elbows are, for example, in this category.


All connections should be complied with presented diagram.

#### While installing water pipes, followings should be considered :

- While inserting or putting water pipes, close the end of the pipe with pipe cap to avoid dust entering.
- When cutting or welding the pipe, always be careful that inner section of the pipe should not be defective. For example, no weldments or no burrs are found inside the pipe.
- Drain piping should be provided in case of water discharge by operation of the safety valve, drain from condensate, and snow or rain. This situation can be happened when the internal pressure is over 3.0 bar and water inside the indoor unit will be discharged to drain hose.
- In a cold climate region, water drainage must be frost-proof.

**While connecting water pipes, followings should be considered.**

- Pipe fittings (e.g. L-shape elbow, T-shape tee, diameter reducer, etc) should be tightened strongly to be free from water leakage.
- Connected sections should be leakage-proof treatment by applying teflon tape, rubber bushing, sealant solution, etc.
- Appropriate tools and tooling methods should be applied to prevent mechanical breakage of the connections.
- Drain hose should be connected with drain piping.
- Maximum allowable Torque at the water piping connection is 50 N·m



---

## WARNING

### **Water condensation on the floor**

While cooling operation using the underfloor heating, it is very important to keep leaving water temperature higher than 16 °C. Otherwise, dew condensation can be occurred on the floor. If floor is in humid environment, do not set leaving water temperature below 18 °C.

### **Water condensation on the radiator**

While cooling operation, cold water may not flow to the radiator. If cold water enters to the radiator, dew generation on the surface of the radiator can be occurred.

### **Drainage treatment**

While cooling operation, condensed dew can drop down to the bottom of the indoor unit. In this case, prepare drainage treatment (for example, vessel to contain condensed dew) to avoid water drop. Additional drain pan accessory should be installed to prevent dew to be formed.

---

## Water Charging

For water charging, please follow below procedures.

**Step 1.** Open all valves of whole water circuit. Supplied water should be charged not only inside the unit, but also in the under floor water circuit, DHW water tank circuit, FCU water circuit, and any other water circuits controlled by the product.

**Step 2.** Connect supply water into drain valve and fill valve located at the side of the shut-off valve.

### CAUTION

No water-leakage permitted at the drain and fill valve. Leakage-proof treatment which is described in previous section should be applied.

**Step 3.** Start to supply water. While supplying water, following should be kept.

- Pressure of supplying water should be pre-adjust value approximately.
- For supplying water pressure, time to be taken from 0 bar to pre-adjust value should be more than 1 minute. Sudden water supply can yield water drain through safety valve.
- Fully open the cap of air vent to assure air purging. If air is exist inside the water circuit, then performance degrade, noise at the water pipe, mechanical damage at the surface of electric heater coil.
- Open both the air vent in the water pipe and the air vent in the pump.

**Step 4.** Stop water supplying when the pressure located in remote control indicates pre-adjust value.

**Step 5.** Close drain valve and fill valve. Then wait for 20~30 seconds to observe water pressure being stabilized.

**Step 6.** If following conditions are satisfactory, then go to Next process(Pipe Insulation). Otherwise, go to step 3.

- Pressure gage indicates pre-adjust value. Note that sometimes pressure is decreased after step 5 due to water charging inside expansion vessel.
- No air purging sound is heard or no water drop are popping out from air vent.

### CAUTION

Keep the air vent of the water pipe open and keep the air vent of the pump closed. Otherwise, the pump may make noise. Close all air vents once water is spilled from the vents.

**Pipe Insulation**

**Purpose of water pipe insulation is :**

- To prevent heat loss to external environment
- To prevent dew generation on the surface of the pipe in cooling operation
- Minimum insulation thickness recommendations ensure correct operation of the product, but local regulations may vary and must be followed.
- If cooling function is used, the type of insulation must be suited for cold water and all joints must be sealed tightly to prevent that the insulation becomes wet from the inside.

| Water Piping length (m) | Minimum insulation Thickness(mm) |
|-------------------------|----------------------------------|
| <20                     | 20                               |
| 20~30                   | 30                               |
| 30~40                   | 40                               |
| 40~50                   | 50                               |

\*  $\lambda = 0.04 \text{ W/mk}$  (Thermal conductivity of pipe insulation)



## Water pump Capacity

The water pump is variable type which is capable to change flow rate, so it may be required to change default water pump capacity in case of noise by water flow. In most case, however, it is strongly recommended to set capacity as Maximum.

## Pressure Drop

### NOTE

When installing the product, install additional pump in consideration of the pressure loss and pump performance. If flow rate is low, overloading of product can occur

#### For GRUNDFOS Water Pump


| Capacity [kW] | Rated flow-rate [LPM(m <sup>3</sup> /h)] | Pump Head [m]<br>(At rated flow rate) | Product pressure drop [m]<br>(Plate heat exchanger) | Serviceable Head [m] |
|---------------|------------------------------------------|---------------------------------------|-----------------------------------------------------|----------------------|
| 5             | 15.8 (0.9)                               | 7.5                                   | 0.2                                                 | 7.3                  |
| 7             | 20.12 (1.2)                              | 7.3                                   | 0.3                                                 | 7.0                  |
| 9             | 25.87 (1.5)                              | 6.1                                   | 0.4                                                 | 5.7                  |
| 12            | 34.5 (2.1)                               | 9.8                                   | 0.8                                                 | 9.0                  |
| 14            | 40.25 (2.4)                              | 9.3                                   | 1.1                                                 | 8.2                  |
| 16            | 46.0 (2.8)                               | 8.3                                   | 1.4                                                 | 6.9                  |

#### For OH SUNG Water Pump


| Capacity [kW] | Rated flow-rate [LPM(m <sup>3</sup> /h)] | Pump Head [m]<br>(At rated flow rate) | Product pressure drop [m]<br>(Plate heat exchanger) | Serviceable Head [m] |
|---------------|------------------------------------------|---------------------------------------|-----------------------------------------------------|----------------------|
| 5             | 15.8 (0.9)                               | 10.9                                  | 0.2                                                 | 10.7                 |
| 7             | 20.1 (1.2)                               | 10.7                                  | 0.3                                                 | 10.4                 |
| 9             | 25.9 (1.5)                               | 10.3                                  | 0.4                                                 | 9.9                  |
| 12            | 34.5 (2.1)                               | 9.7                                   | 0.8                                                 | 8.9                  |
| 14            | 40.3 (2.4)                               | 9.1                                   | 1.1                                                 | 8.0                  |
| 16            | 46.0 (2.8)                               | 8.5                                   | 1.4                                                 | 7.1                  |

Performance curve


GRUNDFOS Water Pump : UPM3K GEO 20 – 75 CHBL



GRUNDFOS Water Pump : UPML GEO 20 – 105 CHBL



OH SUNG Water Pump : ODM-061P



Performance test based on standard ISO 9906 with pre-pressure 2.0 bar and liquid temperature 20 °C.

## WARNING

- If pressure drop is higher than what the pump can cover, the flow rate will drop and low-flow error (CH14) will occur.

## Water Quality

Water quality should be complied with EN 98/83 EC Directives.  
Detailed water quality condition can be found in EN 98/83 EC Directives.

### CAUTION

- If the product is installed at existing hydraulic water loop, it is important to clean hydraulic pipes to remove sludge and scale.
- Installing sludge strainer in the water loop is very important to prevent performance degrade.
- Chemical treatment to prevent rust should be performed by installer.
- It is strongly recommended to install an additional filter on the heating water circuit. Especially to remove metallic particles from the heating piping, it is advised to use a magnetic or cyclone filter, which can remove small particles. Small particles may damage the unit and will NOT be removed by the standard filter of the heat pump system.

## Frost protection by antifreeze

In areas of the country where entering water temperatures drop below 0 °C, the water pipe must be protected by using an approved antifreeze solution. Consult your AWHP unit supplier for locally approved solutions in your area. Calculate the approximate volume of water in the system. (Except the AWHP unit.) And add six liters to this total volume to allow for the water contained in AWHP unit.

| Antifreeze type  | Antifreeze mixing ratio |       |        |        |        |        |
|------------------|-------------------------|-------|--------|--------|--------|--------|
|                  | 0 °C                    | -5 °C | -10 °C | -15 °C | -20 °C | -25 °C |
| Ethylene glycol  | 0 %                     | 12 %  | 20 %   | 30 %   | -      | -      |
| Propylene glycol | 0 %                     | 17 %  | 25 %   | 33 %   | -      | -      |
| Methanol         | 0 %                     | 6 %   | 12 %   | 16 %   | 24 %   | 30 %   |

If you use frost protection function, change DIP switch setting and input the temperature condition in Installation mode of remote controller. Refer to 'CONFIGURATION > DIP Switch Setting > DIP Switch Information > Option Switch 3' and 'INSTALLER SETTING > Antifreezing Temperature'.

### CAUTION

- Use only one of the above antifreeze.
- If a antifreeze is used, pressure drop and capability degradation of the system can be occurred.
- If one of antifreezes is used, corrosion can be occurred. So please add corrosion inhibitor.
- Please check the concentration of the antifreeze periodically to keep same concentration.
- When the antifreeze is used (for installation or operation), take care to ensure that antifreeze must not be touched.
- Ensure to respect all laws and norms of your country about Anti-freeze usage.

## Frost protection by antifreeze valve


### About antifreeze valve

This is a valve to prevent freeze in winter. When no antifreeze is added to the water, you can use antifreeze valves at all lowest points of the field piping to drain the water from the system before it can freeze

### To install antifreeze valve

To protect the field piping against freezing, install the following parts:

### Antifreeze valve




※ It can be different by model.

- a Antifreeze valve (Optional – field supply)
- b Normally closed valves (recommended – field supply)

| Part                                                                                | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|   | Protection for the field piping. The antifreeze valve must be installed: <ul style="list-style-type: none"><li>• Vertically to allow water to flow out properly and free from obstructions.</li><li>• At all lowest points of the field piping.</li><li>• In the coldest part and away from heat sources.</li></ul>                                                                                                                                                                                                                                                                                                                                                                                  |
|  | Isolation of water inside the house when there is a power interruption. Normally closed valves (located indoors near the piping entry/exit points) can prevent that all water from indoor piping is drained when the antifreeze valve open. <ul style="list-style-type: none"><li>• <b>When there is a power interruption:</b> The normally closed valves close and isolate the water inside the house. If the antifreeze valve open, only the water outside the house is drained.</li><li>• <b>In other circumstances</b> (example: when there is a pump failure): The normally closed valves remain open. If the antifreeze valve open, the water from inside the house is also drained.</li></ul> |

**NOTE**

- Do not make any trap connections. If the shape of the connection pipe has the potential to create a trap effect, part of the pipe will not be able to drain and frost protection will no longer be guaranteed.
- Leave at least 15 cm clearance from the ground to prevent ice from blocking the water exit.
- Keep a distance of at least 10 cm between the antifreeze valves.
- The valve must be free of insulation for the system to work properly.
- When antifreeze valves are installed, do NOT select a minimum cooling setpoint lower than 7 °C. If lower, antifreeze valves can open during cooling operation.
- When installed outdoors, the antifreeze valve must be protected from rain, snow and direct sunlight.




## Water Volume and Expansion Vessel Pressure

Inside expansion vessel is included which is 8 liter capacity with 1 bar pre-pressure. That means, according to the volume-pressure graph, total water volume of 230 liter is supported as default. If total water volume is changed because of installation condition, the pre-pressure should be adjusted to secure proper operation.

| If                                          | Minimum water volume |
|---------------------------------------------|----------------------|
| The system contains a backup heater         | 20 L                 |
| The system does NOT contain a backup heater | 80 L                 |

\* The internal water volume of the outdoor unit is NOT included

- Pre-pressure is adjusted by the total water volume. If the indoor is located at the highest position of the water circuit, adjustment is not required.
- To adjust pre-pressure, use nitrogen gas by certificated installer.



Adjusting pre-pressure of expansion vessel is as following :

**Step 1.** Refer "Volume-Height" table.

If installation scene is belong to Case A, go to Step 2.  
 Otherwise, if it is Case B, do nothing. (pre-pressure adjustment is not required.)  
 Otherwise, if it is Case C, go to Step 3.

**Step 2.** Adjust pre-pressure by following equation.

Pre-pressure [bar] =  $(0.1 \times H + 0.3)$  [bar]  
 where H : difference between unit and the highest water pipe  
 0.3 : minimum water pressure to secure product operation

**Step 3.** Volume of expansion vessel is less than installation scene. Please install additional expansion vessel at the external water circuit.

### Volume-Height Table

|         | V < 230 liter | V ≥ 230 liter |
|---------|---------------|---------------|
| H < 7 m | Case B        | Case A        |
| H ≥ 7 m | Case A        | Case C        |

H : Difference between unit and the highest water pipe  
 V : total water volume of installation scene

## ACCESSORIES INSTALLATION

This product can interface to various accessories to extend its functionality and to improve user convenience. In this chapter, specifications about supported 3rd party accessories and how to connect to this product is introduced.

It is noted that this chapter only deal with 3rd party accessories. For accessories supported by LG Electronics, please refer to installation manual of each accessories.

### Accessories supported by LG Electronics

| Item                                              | Purpose                                      | Model                                                                                                                                                                                                                                                          |
|---------------------------------------------------|----------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DHW Heater Kit                                    | To operate with DHW tank                     | PHLTB                                                                                                                                                                                                                                                          |
| Remote temperature sensor                         | To control by air temperature                | PQRSTA0                                                                                                                                                                                                                                                        |
| Simple dry contact                                | To receive on & off external signal          | PDRYCB000                                                                                                                                                                                                                                                      |
| Thermostat Dry contact                            | Dry Contact For Thermostat                   | PDRYCB320                                                                                                                                                                                                                                                      |
| Solar Thermal Kit                                 | To operate with solar heating system         | PHLLA                                                                                                                                                                                                                                                          |
| DHW Tank (Single Coil)                            | To generate and store hot water              | OSHW-200F : 200 L, Single Heating Coil,<br>1Ø 230 V 50 Hz 2.4 kW<br>Booster heater<br>OSHW-300F : 300 L, Single Heating Coil,<br>1Ø 230 V 50 Hz 2.4 kW<br>Booster heater<br>OSHW-500F : 500 L, Single Heating Coil,<br>1Ø 230 V 50 Hz 2.4 kW<br>Booster heater |
| DHW Tank (Double Coil)                            | To generate and store hot water              | OSHW-300FD : 300 L, Double Heating Coil,<br>1Ø 230 V 50 Hz 2.4 kW<br>Booster heater                                                                                                                                                                            |
| Thermistor for Water Tank (Buffer Tank, DHW Tank) | To control hot water temperature of DHW tank | PHRSTA0                                                                                                                                                                                                                                                        |
| Backup heater                                     | To supplement insufficient capacity          | HA031M E1 / HA061M E1 / HA063M E1<br>HA031M E2 / HA061M E2 / HA063M E2                                                                                                                                                                                         |
| Meter Interface*                                  | To measure production / consumption power    | PENKTH000                                                                                                                                                                                                                                                      |

\* Only one device can be connected at a time.



| Item                                  | Purpose                                                                                                                                                                                                | Model               |
|---------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------|
| Wall-mounted outdoor air temp. sensor | To control Automatically operation with more accurate outdoor temperature<br>The basic outdoor temperature sensor is located in the back of ODU. It is especially affected by sunlight during the day. | PHATS0              |
| Cloud Gateway                         | To use Becon cloud                                                                                                                                                                                     | PWFMDB200           |
| Wi-Fi Modem                           | To enable remote system operation from smartphone                                                                                                                                                      | PWFMDD200           |
| Wi-Fi Extension Cable                 | To connect with Wi-Fi modem to the USB cable                                                                                                                                                           | PWYREW000           |
| Thermistor for 2nd Circuit            | To interlock with 2nd circuit operation and control temperature of mixing circuit or to interlock with 3rd party electric backup heater and control its outlet temperature.                            | PRSTAT5K10          |
| Extension wire                        | To extend the Remote controller wire by 10 m.                                                                                                                                                          | PZCWRC1             |
| Wired remote controller               | To control unit with 2 remote controllers                                                                                                                                                              | PREMTW101           |
| 2-Remo Control Wire                   | The wire for 2 remo control                                                                                                                                                                            | PZCWRC2             |
| 3 way valve                           | To divert water flow between space heating and DHW heating                                                                                                                                             | OSHA-3 V            |
| Thermostatic mixing valve             | To blend hot water with cold water for ensuring constant, safe shower and bath outlet temp.                                                                                                            | OSHA-MV<br>OSHA-MV1 |

\* Only one device can be connected at a time.

## ! CAUTION

- Install the drain pan when cooling.
- If not installed, water may form.
- Please refer to separate installation manual when installing drain pan.

### Accessories supported by 3rd party Companies

| Item                                | Purpose                                                                                                                                                                             | Specification                                                                                                                      |
|-------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
| Solar Heating System                | To generate auxiliary heating energy for water tank                                                                                                                                 | <ul style="list-style-type: none"> <li>• Solar collector</li> <li>• Solar pump</li> <li>• Solar Thermal Sensor : PT1000</li> </ul> |
| Thermostat                          | To control by room air temperature                                                                                                                                                  | Heating-Only type (230 V AC)<br>Cooling/Heating type (230 V AC with Mode selection switch)                                         |
| Mix Kit                             | To use 2 <sup>nd</sup> Circuit                                                                                                                                                      | <ul style="list-style-type: none"> <li>• Mixing valve</li> <li>• Mix pump</li> </ul>                                               |
| 3 <sup>rd</sup> Party Boiler        | To use auxiliary boiler.                                                                                                                                                            |                                                                                                                                    |
| 3 <sup>rd</sup> Party Controller*   | To connect external controller using modbus protocol                                                                                                                                | Modbus RTU, 9600 bps, Stopbit 1, Parity none                                                                                       |
| 3way valve and actuator             | (A) : To control water flow for hot water heating or floor heating<br>/ To control water flow when installing 3rd party boiler<br>(B) : To control close/open mode of solar circuit | 3 wire, SPDT (Single Pole Double Throw) type, 230 V AC                                                                             |
| 2way valve and actuator             | To block underfloor heating coil from cooling water                                                                                                                                 | 2 wire, NO(Normal Open) or NC(Normal Closed) type, 230 V AC                                                                        |
| External Pump                       | To control the water flow at the rear of the buffer tank                                                                                                                            |                                                                                                                                    |
| Smart Grid                          | To control operation mode depending on input signal from provider                                                                                                                   | 2 x 230VAC                                                                                                                         |
| 3 <sup>rd</sup> Party ESS*          | To control the operation mode according to the energy storage state                                                                                                                 | Modbus RTU                                                                                                                         |
| 3 <sup>rd</sup> party Backup heater | To supplement in sufficient capacity                                                                                                                                                |                                                                                                                                    |
| Antifreeze valve                    | To protect the pipes against freezing                                                                                                                                               |                                                                                                                                    |
| DHW Recirculation Pump              | To control the water flow of DHW recirculation pump                                                                                                                                 |                                                                                                                                    |

\* Only one device can be connected at a time.

## Before Installation

### ⚠ WARNING

Followings should be kept before installation

- Main power must be turned off during installing accessories.
- 3rd party accessories should be comply with supported specification.
- Proper tools should be chosen for installation.
- Never do installation with wet hands.

## Thermostat

Thermostat is generally used to control the product by air temperature. When thermostat is connected to the product, the product operation is controlled by the thermostat.


### Installation condition

### ⚠ CAUTION

- USE 220-240 V~ Thermostat
- Some electro-mechanical type thermostat has internal delay time to protect compressor. In that case, mode change can takes time more than user's expectation. Please read thermostat manual carefully if the unit does not response quickly.
- Setting temperature range by thermostat can be different with that of the unit. The heating or cooling set temperature should be chosen within the setting temperature range of the unit.
- It is highly recommended that the thermostat should be installed where space heating is mainly applied.

Following location should be avoid to secure proper operation :

- Height from floor is approximately 1.5 m.
- Thermostat can not be located where the area may be hidden when door is open.
- Thermostat can not be located where external thermal influence may be applied. (such as above heating radiator or open window)



Thermostat

## General Information

The Heat Pump supports following thermostats.

| Type              | Power  | Operating Mode                      | Supported |
|-------------------|--------|-------------------------------------|-----------|
| Mechanical<br>(1) | 230 V~ | Heating Only (3)                    | Yes       |
|                   |        | Heating / Cooling (4)               |           |
|                   |        | Heating / Cooling / DHW Heating (5) |           |
| Electrical<br>(2) | 230 V~ | Heating Only (3)                    | Yes       |
|                   |        | Heating / Cooling (4)               |           |
|                   |        | Heating / Cooling / DHW Heating (5) |           |

- (1) There is no electric circuit inside the thermostat and electric power supply to the thermostat is not required.
- (2) Electric circuit such as display, LED, buzzer, etc is included in the thermostat and electric power supply is required.
- (3) Thermostat generates "Heating ON or Heating OFF" signal according to user's heating target temperature.
- (4) Thermostat generates both "Heating ON or Heating OFF" and "Cooling ON or Cooling OFF" signal according to user's heating and cooling target temperature.
- (5) Thermostat generates "Heating ON or Heating OFF", "Cooling ON or Cooling OFF", "DHW Heating ON or DHW Heating OFF" signal according to user's heating, cooling and DHW heating target temperature.

---

## CAUTION

Choosing heating / cooling thermostat

- Heating / cooling thermostat must have "Mode Selection" feature to distinguish operation mode.
  - Heating / cooling thermostat must be able to assign heating target temperature and cooling target temperature differently.
  - If above conditions are not kept, the unit can not operation properly.
  - Heating / cooling thermostat must send cooling or heating signal immediately when temperature condition is satisfied. No delay time while sending cooling or heating signal is permitted.
-


## How to wire Heating / Cooling / DHW Heating thermostat

Follow below procedures Step 1 ~ Step 3.

**Step 1.** Uncover front cover of the unit and open the control box.

**Step 2.** Identify the power specification of the thermostat. If it is 220-240 V~, go to Step 3.

**Step 3.** Find terminal block and connect wire as below.



### WARNING

Mechanical type thermostat.

Do not connect wire (N) as mechanical type thermostat does not require electric power supply.

### CAUTION

Do not connect external electric loads.

Wire (L) and (N) should be used only for operation electric type thermostat.

Never connect external electric loads such as valves, fan coil units, etc.

If connected, Main PCB (Heater) can be seriously damaged.

## Final check

### DIP switch setting :

- Set DIP switch No. 8 to 'ON'. Otherwise, the unit can not recognize the thermostat.

### Remote Controller :

- 'Thermostat' text is displayed on the remote controller.
- Only the water temperature setting is available and the other button input is prohibited.
- In case of Heating / Cooling / DHW Heating thermostat, select 'Heat&Cool / DHW' as the Thermostat Control Type in the remote controller installer settings.
- The product operates according to Thermo On / Off conditions of the thermostat and remote controller.

| Thermo On / Off Condition |                   | Product    |
|---------------------------|-------------------|------------|
| Thermostat                | Remote Controller |            |
| Thermo Off                | Thermo Off        | Thermo Off |
| Thermo Off                | Thermo On         | Thermo Off |
| Thermo On                 | Thermo Off        | Thermo Off |
| Thermo On                 | Thermo On         | Thermo On  |

## 2<sup>nd</sup> Circuit

The 2<sup>nd</sup> circuit is a function that can separately control the circuit1 requiring high temperature and the circuit 2 requiring medium temperature, you need to prepare a separate Mix Kit.  
The mix kit must be installed in the circuit 2.

### [Install Guide Mixing circuit Heating]

| Circuit 1 \ Circuit 2  | Floor (35°C) | Convector (FCU, 45 °C) | Radiator (45 °C) | Radiator (55 °C) |
|------------------------|--------------|------------------------|------------------|------------------|
|                        |              |                        |                  |                  |
| Floor (35 °C)          | x            | x                      | x                | x                |
| Convector (FCU, 45 °C) | o            | x                      | x                | x                |
| Radiator (45 °C)       | o            | o                      | x                | x                |
| Radiator (55 °C)       | o            | o                      | o                | x                |

### [Install Guide Mixing circuit Cooling]

| Circuit 1 \ Circuit 2 | Floor (18 °C) | Convector (FCU, 5 °C) |
|-----------------------|---------------|-----------------------|
|                       |               |                       |
| Floor (18 °C)         | x             | x                     |
| Convector (FCU, 5 °C) | o             | x                     |

※ Heating circuits that are not designed for carrying cooling water must be blocked by the 2-way-valve.

---

## NOTE

Circuit 1 = Direct circuit : Zone where the water temperature is highest when heating

Circuit 2 = Mixing circuit : The other zone

---

## How to Wire Mixing Kit

Follow below procedures Step 1 ~ Step 3.

**Step 1.** Uncover front cover of the unit.

**Step 2.** Find terminal block and connect wire as below

TB 1

|          |     |              |      |      |
|----------|-----|--------------|------|------|
| 5        | 6   | 7            | 8    | 9    |
| L        | N   | L1           | L2   | N    |
| MIX PUMP |     | MIXING VALVE |      |      |
| (L)      | (N) | (L1)         | (L2) | (N1) |
| ↓        |     | ↓            |      |      |
| MIX PUMP |     | MIXING VALVE |      |      |

(L) : Live signal from PCB to mix pump

(N) : Neutral signal from PCB to mix pump


(L1) : Live signal (for Normal\* Closed type) from PCB to mixing valve

(L2) : Live signal (for Normal Open type) from PCB to mixing valve

(N1) : Neutral signal from PCB to mixing valve

\*Closed = NOT Mixed

**Step3.** Insert the temperature sensor to 'CN\_MIX\_OUT' (Brown) of the main PCB as shown below. The sensor should be mounted correctly to discharge pipe of mix pump as shown below.



## NOTE

- The location of the external pump may vary depending on the installer settings.
- Temperature sensor specification:  
 LG-accessory PRSTAT5K10 at 25 °C : 5 kΩ  
 Minimum operating temperature range : -30 °C~100 °C

**[Thermistor for Mixing circuit]**

Sensor



Sensor Holder



Sensor Connector

Follow below procedures step 1 ~ step 4.

- Step 1.** Install sensor connector to discharge pipe of mix pump.  
(Welding must be performed to connect the sensor connector to the pipe)
- Step 2.** Check if the power of the unit is turned off.
- Step 3.** Fasten the sensor connector to the sensor holder as shown in the figure below.
- Step 4.** Insert harness into PCB(CN\_MIX\_OUT) fully and fix the thermal sensor into tube connector as shown below.





## 3<sup>rd</sup> Party Boiler

The product can be used by connecting an Auxiliary boiler.

3rd party boiler can be enabled/disabled by manually via remote controller or automatically itself by means of comparing the outside air temperature and the pre-set temperature. Only Bivalent-alternative operation is possible.

While boiler is enabled, it must operate by its own controls.


### How to wire 3rd party boiler

Follow below procedures step 1 ~ step 3.

**Step 1.** Check if the power of the unit is turned off.

**Step 2.** Disassemble front panels and Distinguish terminal block in Indoor PCB.

**Step 3.** Connect Power cable to terminal block (TB\_BOILER) fully.



## 3rd Party Controller

The product can also be linked to 3rd party controller using Modbus RTU. Various datapoints and setting options are available through Modbus protocol. Contact your authorized dealer for more information.

### How to wire 3rd party controller


Follow below procedures step 1 ~ step 4.

**Step 1.** Check if the power of the unit is turned off.

**Step 2.** Disassemble front panels and distinguish control box(Indoor) of the unit.

**Step 3.** Check if the harness(White) is inserted fully to the indoor unit PCB (CN\_MODBUS).

**Step 4.** Connect the 3rd party controller to terminal block 2(21/22) completely.



### NOTE


- If CN\_MODBUS port is used to interlink with LG metering module, a 3rd-party controller cannot be connected at the same time.

## Meter Interface

This accessory (PENKTH000) can be used to connect 3rd-party wattmeter (max. 3) using pulse input or Modbus and one heatmeter using pulse input.


The consumed electric power and/or produced thermal energy is displayed on the remote controller.

### How to install Meter Interface



- ① Power input Outdoor unit
- ② Power input Backup heater
- ③ Thermal output Outdoor unit

# [Parts of Meter interface]



Meter interface body


Follow below procedures step 1 ~ step 4.

**Step 1.** Check if the power of the unit is turned off.

**Step 2.** Disassemble front panels and Distinguish control box(Indoor) of the unit.

**Step 3.** Check if the harness(White) is inserted fully to the indoor unit PCB (CN\_MODBUS).

**Step 4.** Connect the external pump to terminal block 2(21/22).



## NOTE

- If CN\_MODBUS port is used to interlink with 3rd-party controller, the metering module cannot be connected at the same time.
- Refer to manual of PENKTH000 for more information.

## Central Controller

The product can communicate and control through the central controller.  
The following functions can be controlled in the central control linked state (Operation/Stop, Desired temperature, Hot water operation / stop, Warm water temperature, Full lock, Etc)

### How to Install Central Controller

To use central controller, you need to establish an environment for mutual communication between central controller and the this product and register the corresponding devices through the functions of central controller.

To use central controller, it shall be installed in the following order.

- Step 1.** Installation environment inspection and device address setting  
Before installing central controller, check the network for any interfacing devices and assign non overlapping addresses to the connected devices.
- Step 2.** Connections  
Connect Outdoor unit and central controller through RS-485 cable.
- Step 3.** Access and Device Registration  
Log in to central controller and register device with address set.  
Consult a qualified engineer/ technician for the installation of central controller.  
If you have any installation queries, contact the LG service center or LG Electronics.


## DHW Tank

To establish DHW circuit, 3way valve and DHW sensor (PHRSTA0) or DHW kit (PHLTB) is required

### Installation condition

Installing DHW tank following considerations :

- DHW tank should be located at the flat place.
- Water quality should be complied with EN 98/83 EC directives.
- As this water tank is sanitary water tank (indirect heat exchange), do not use anti water-freezing treatment like ethylene glycol.
- It is highly recommend to wash out inside of the DHW tank after installation. It ensures generating clean hot water.
- Near the DHW tank there should be water supply and water drain for easy access and maintenance.
- Set the maximum value of the temperature control device of DHW tank.



※ For detailed connection refer to manufacturer's manual of the DHW tank.

## ⚠ WARNING

The schematic does not include all necessary safety devices. For details refer to Hydronic schemes provides by local LG office.

## General Information

**THERMAV** supports following 3way valve.

| Type                         | Power    | Operating Mode                                           | Supported |
|------------------------------|----------|----------------------------------------------------------|-----------|
| SPDT <sup>1)</sup><br>3-wire | 230 V AC | Selecting Flow A <sup>2)</sup> between Flow A and Flow B | Yes       |
|                              |          | Selecting Flow B <sup>3)</sup> between Flow A and Flow B | Yes       |

1) SPDT = Single Pole Double Throw. Three wires consist of Live1 (for selecting Flow A), Live 2 (for selecting Flow B), and Neutral (for common).


2) 'Flow A' means water flow from the unit to space heating circuit.

3) 'Flow B' means water flow from the unit to DHW tank.

## Installing recirculation pump

A DHW recirculation pump can be connected to increase comfort, as warm water will immediately be available when opening the tap.

- To limit the energy consumption, external time scheduler to determine when the recirculation pump should turn on and turn off is required.
- The pump operating start time should be prior to the DHW demand.



※ Water In / Water Out installation scene may vary depending on the model.

## ⚠ WARNING

The schematic does not include all necessary safety devices. For details refer to Hydronic schemes provided by local LG office.

### How to wire recirculation pump


Follow below procedures step 1 ~ step 4.

**Step 1.** Check if the power of the unit is turned off.

**Step 2.** Disassemble front panels and distinguish control box(Indoor) of the unit.

**Step 3.** Check if the harness(Violet) is inserted fully to the indoor unit PCB (CN\_PUMP\_A15).

**Step 4.** Connect the DHW recirculation pump to terminal block 1(1/2).



---

## CAUTION

When connecting a pump of 1.05A or higher, its output must be used as a signal line only.

---




## DHW Tank Kit

This accessory PHLTB is used to connect a DHW boost heater. The kit consists of earth-leakage breaker, circuit breaker and internal wires. It also includes the DHW thermistor.

### How to install DHW tank kit


#### [Parts of DHW Tank Kit]



Tank kit body



Sensor



Multi harness

Temperature sensor for DHW tank is used to control hot water temperature of DHW tank. If sensor will be defective or you don't need a boost heater, you can purchase it separately. (Model name : PHRSTA0)

Follow below procedures step 1 ~ step 5

**Step 1.** Uncover DHW tank kit and locate it on the wall.

**Step 2.** Insert DHW tank sensor to 'CN\_TH4' (Red) of the Main PCB as shown below.

**Step 3.** Insert the sensor probe into the sensor pocket of the DHW tank.

**Step 4.** Plug the white connector to CN\_TANK\_HEATER on Main PCB.

**Step 5.** Connect power supply to the DHW tank kit as shown fig. 1.




Fig. 1




Fig. 3

Insert sensor until the cable tie as shown below.



Fig. 2

## How to wire DHW boost heater

※ If LG tank [OSHW-x00F(D)] is used, a Boost heater is included in the tank.

**Step 1.** Open the cover at side of tank.

**Step 2.** Find terminal block and connect wires as below. Wires are field-supplied item.

(L) : Live signal from heat pump to boost heater.

(N) : Neutral signal from heat pump to boost heater.


## ⚠ WARNING

### Wire specification

- Cross-sectional area of the wire should be 6 mm<sup>2</sup>.

### Adjusting thermostat temperature

- To guarantee proper operation, it is recommended to set temperature of thermostat to maximum temperature (symbol  $\text{Ⓐ}$  at the picture).



## Solar Thermal Kit


This product can be used by connecting the solar thermal kit in the field. It can be utilized hot water heated by solar thermal system. End-user must be install solar thermal kit accessory(PHLLA) provided by LG.

### How to Install Solar Thermal Kit

#### [Parts of Solar Thermal Kit]




Sensor Holder



Tube Connector



Solar Thermal Sensor



Installation Manual


Follow below procedures step 1 ~ step 4.

**Step 1.** Check if the power of the unit is turned off.

**Step 2.** Disassemble front panels and distinguish control box(Indoor) of the unit.


**Step 3.** Install 3rd-party PT1000 sensor at outlet of Solarthermal collector. Tube connector and sensor holder might be used if necessary. Connect the sensor-wire at port CN\_SOLAR.

**Step 4.** Install tank sensors provided with the kit at top (WATER TANK SENSOR) and bottom (SOLAR PIPE SENSOR) and insert the connector at port CN\_TH4 on IDU-PCB.



### NOTE

- If single DHW-sensor is already connected at port CN\_TH4, disconnect first, before connecting the double-sensor.



Insert sensor until the cable tie as shown below.



## CAUTION

Sensor mounting

Insert sensor into sensor socket and bolt it tightly.

## Buffer Tank temperature sensor

If a big buffer tank is connected in parallel to the heat pump, a separate sensor can be connected to PCB-connector TB\_SENSOR/BUFFER.

It can be sensing the temperature at the top of the tank or at its outlet pipe.

Consequently, the desired target water temperature (as set by User or defined by weather-dependent function) is compared to the buffer tank temperature.

### How to wire Buffer Tank temperature sensor


#### [Parts of Buffer Tank temperature sensor]



Buffer Tank sensor



Connect harness



Installation Manual

Follow below procedures step 1 ~ step 5.


**Step 1.** Check if the power of the unit is turned off.

**Step 2.** Disassemble front panels and distinguish control box(Indoor) of the unit.

**Step 3.** Insert the connect harness into PCB(TB\_SENSOR / BUFFER) like as below.

**Step 4.** Connect Buffer Tank sensor and Connect harness.

**Step 5.** Install Buffer Tank sensor at the top of the tank or at its outlet pipe.



Indoor PCB

## Dry Contact

Dry Contact is a solution for automatic control of HVAC system at the owner's best. In simple words, it's a switch which can be used to turn the unit On/Off after getting the signal from external sources.

### How to install dry contact

#### [Parts of Dry contact]



Dry Contact body



Cable(for connecting with IDU)


Follow below procedures step 1 ~ step 4.

**Step 1.** Check if the power of the unit is turned off.

**Step 2.** Disassemble front panels and distinguish terminal block in Indoor PCB.

**Step 3.** Connect cable to the unit PCB(CN\_CC) fully.

**Step 4.** Then, Insert harness to the dry contact PCB(CN\_INDOOR) firmly as shown below.




---

## NOTE


- For more information about installing Dry Contact, Please refer installation manual provided with Dry Contact.
  - For more settings about Dry Contact, Please refer to "Dry Contact Mode / CN\_CC / CN\_EXT" that installer setting part.
-

**[Setting of Contact Signal Input]**

- For input contact closure only(No power input)



- For input contact voltage : DC 12 V, 24 V~

**Setting\_SW Setting**

- Normal (0) : Possible to be controlled by the remote controller.
- Forced (1) : Not possible to be controlled by the remote controller.
- There is no OPER\_SW setting that each input signal is disabled.

## External Controller - Setting up programmable digital input operation

If you require to control depending on external digital input(ON/OFF), connect cable to indoor PCB(CN\_EXT).


Follow below procedures step 1 ~ step 4.

**Step 1.** Check if the power of the unit is turned off.

**Step 2.** Disassemble front panels and distinguish control box(Indoor) of the unit

**Step 3.** Connect the external controller to PCB(CN\_EXT) completely.


**Step 4.** Connect the cable and field installation part.



Indoor PCB




CN\_EXT



Adapter Cable

\*Delivered part


### Installation example #1



- SW : Single pole switch
  - Select a part with contacts for extremely low amperage
  - DC 5 V ~ 12 V is used at the contact point
  - Switch load is approximately 0.5 ~ 1 mA

- Control cable
  - Cable size : 22 to 26 AWG
  - Don't extend the cable more than 10 meters

### Installation example #2



- X : Relay (a point of contact, fixed DC 0.5 ~ 1 mA)

- SW : Distance ON/OFF switch


- Control cable (Indoor unit to Relay Circuit)
  - Cable size : 22 to 26 AWG
  - Don't extend the cable more than 10 meters





## Remote Controller

### Installation of Remote Controller

- After fixing the remote controller installation plate on the desired location, fix it firmly with the provided screws.
  - If the installation plate is not flat on the surface, it may result in the controller being twisted and cause a defect.
  - If there is a mounting box, install the remote controller installation plate using the fixings holes which suit, as in the below diagrams.
  - Do not leave a gap with the wall or product loose after the installation.
  - If you are using the air temperature sensor in the remote control, refer to the Remote Temperature sensor guide.




- The wired remote controller cable can be installed in 3 directions. Install to the suitable direction according to the installation environment.
  - Installation direction: Rear entry, top side, right side
  - When you install the remote controller cable at the top side and right side, remove the remote controller cable guide hole before the installation.
    - ※ Use a long nose pliers to remove the guide hole.
- After removing the hole, trim the cut surface neatly.




- After fixing the remote controller top side on the installation plate attached to the wall as in the following figure, press the bottom side to combine with the installation plate.
  - Do not leave a gap in the top, bottom, left, and right side of the remote controller and the installation plate after combining them.
  - Before combining with the installation plate, arrange the cables to avoid interference with the circuit parts.

#### <Procedure of Combining>




- When you remove the remote controller from the installation plate, insert a small flat head screwdriver into the bottom side separation hole and turn clockwise to separate the remote controller.
  - There are 2 separation holes at the bottom part. Slowly separate one by one.
  - Be careful not to damage the internal parts during the removal.



- Use the connection cables to connect the indoor unit with the remote controller.

|         |        |
|---------|--------|
| DC 12 V | Red    |
| Signal  | Yellow |
| GND     | Black  |



- For the following cases, separately purchase and use the cables suitable for the situation.
  - Do not install the cable over 50 m.(It may cause communication issues.)
  - If the distance between the wired remote controller and the unit is 10 m or more : 10 m extension cable (model name: PZCWRC1)


## NOTE

During the wired remote controller installation, do not bury it in the wall. (It may cause temperature sensor failure.)

Do not install the cable over 50 m. (It may cause communication defect.)

When you install the extension cable, carefully check the direction of the connectors on the remote controller side and the product side before the installation.

Specification of extension cable: AWG 24, 3 conductor or above.



**Cable connection method to use external device**

## 1) Wired remote controller-cable connection method.

- In the wired remote controller, connect the part marked in the following figure (J02C, DO-Port) to the cable.
- According to the installation environment, there are 3 directions (Rear entry, top side, and right side) for the installation.

## 2) Cable extension connection method


- Among the cables connected to the wired remote controller, cut the remaining connectors on the other side, and then extend and connect the cables
- Extension cable specification: 24~26 AWG.

---

**! CAUTION**

For the External device connection, use the cable insulated with sheath for the extension connection.

Before combining with the installation plate, arrange the cables to avoid interference with the internal parts.




## Remote Temperature Sensor

Remote temperature sensor can be installed any place a user wants to detect the temperature.

### Installation condition

Role and constraint while installation of remote air temperature sensor is very similar to that of thermostat.

- Distance between the unit and the remote air temperature sensor should be less than 15 m due to length of the connection cable of remote air temperature sensor.



Remote Air Temperature Sensor

### CAUTION

- Choose the place where the average temperature can be measured for the unit operates.
- Avoid direct sunlight.
- Choose the place where the cooling/heating devices do not affect the remote sensor.
- Choose the place where the outlet of the cooling fan do not affect the remote sensor.
- Choose the place where the remote sensor isn't affected when door is open.

### NOTE

- For more information about installing Remote Temperature Sensor, Please refer installation manual provided with Remote Temperature Sensor.
- For more settings about Remote Temperature Sensor, Please refer to chapter 'Installer settings' (Configuration/Select room devices).

## How to Install Remote Temperature Sensor


### [Parts of Remote Temperature Sensor]



Cable



Screw(to fix remote sensor)



Installation Manual


Follow below procedures step 1 ~ step 5.

**Step 1.** Decide where the remote temperature sensor is installed. Then, Determine the location and height of the fixing screws in fig. 1 (Interval between the screws : 60 mm)

**Step 2.** Check if the power of the unit is turned off.

**Step 3.** Disassemble front panels and distinguish control box(Indoor) of the unit.

**Step 4.** Insert temperature sensor into PCB(CN\_ROOM1) and fix the sensor firmly. (Fig. 2)



[Fig. 1]


[Fig. 2]

### NOTE

- If remote air sensor is used to control mixing circuit, use port CN\_ROOM2.  
The polarity is not relevant, if you have to extend the wire.

**Step 5.** Integrate the remote temperature sensor with the screws as the order of arrows.

### Fixing the Remote Sensor



## Solar pump

Solar pump can be required to energize water flow when solar thermal system is installed.

### How to wire solar pump


Follow below procedures step 1 ~ step 4.

**Step 1.** Check if the power of the unit is turned off.

**Step 2.** Disassemble front panels and distinguish control box(Indoor) of the unit.

**Step 3.** Check if the harness(Black) is inserted fully to the indoor unit PCB (CN\_PUMP\_A4).

**Step 4.** Connect the external pump to terminal block 1(3/4).



## ⚠ CAUTION

When connecting a pump of 1.05A or higher, its output must be used as a signal line only.

## NOTE

PWM-type pump is not supported by this controller.

## External pump

External pump (3rd-party) can be utilized if internal pump cannot overcome system pressure losses; if secondary pump is needed (in case parallel buffer tank) or - if two heating circuits are needed - as circuit pump to feed the radiator circuit.


### How to wire external pump

Follow below procedures step 1 ~ step 3.

**Step 1.** Check if the power of the unit is turned off.

**Step 2.** Disassemble front panels and distinguish terminal block in Indoor PCB.

**Step 3.** Connect signal cable to terminal block fully.





## Wi-Fi Modem


Wi-fi modem enables remote system operation from smartphone. Available functions include selection of on/off, operation mode, DHW heating, temperature setup and weekly scheduling etc. For detailed instructions, refer to the manual included in the accessories.

### How to wire Wi-Fi Modem


#### [Parts of Wi-Fi modem]



Wi-Fi modem body



USB Cable



Extension Cable

※ Extension cable for Wi-Fi Modem : PWYREW000 (Sold Separately)

Follow below procedures step 1 ~ step 5.


**Step 1.** Check if the power of the unit is turned off.

**Step 2.** Disassemble front panels and distinguish control box(Indoor) of the unit.

**Step 3.** Connect the USB cable to the indoor unit PCB (CN\_WIFI ; Blue) until it clicks into place.

**Step 4.** Connect the Wi-Fi modem to the USB cable fully.

**Step 5.** Refer to the image below to install the Wi-Fi modem in the marked position.



## Energy State

This product provides energy states that enable customers to use as much as possible of their own renewable energy. It can shift setpoints depending on input signal from Energy Storage System (ESS) or from any other third-party device using Modbus RTU or Digital 230V inputs.

### Available Energy States

There are 8 energy states available. 4 fixed and 4 customizable - each with the possibility to enhance self-consumption of renewable energy.

| Energy state | Command                      | Battery State of charge | Operation (standard setting)          |                      |                                  |                      |                                       |                       |
|--------------|------------------------------|-------------------------|---------------------------------------|----------------------|----------------------------------|----------------------|---------------------------------------|-----------------------|
|              |                              |                         | Heating                               |                      | Cooling                          |                      | Domestic Hot Water                    |                       |
|              |                              |                         | Setting                               | Range                | Setting                          | Range                | Setting                               | Range                 |
| 1            | Operation Off (Utility lock) | Low                     | Forced internal operation off         | Fixed                | Forced internal operation off    | Fixed                | Forced internal operation off         | Fixed                 |
| 2            | Normal Operation             | Normal                  | Maintain operation status             | Fixed                | Maintain operation status        | Fixed                | Maintain operation status             | Fixed                 |
| 3            | Operation On Recommend       | High                    | Increase 2 °C from target temperature | Fixed                | Maintain operation Status        | Fixed                | Increase 5 °C from target temperature | Fixed                 |
| 4            | Operation On Recommend       | Very High               | Maintain operation status             | Fixed                | Maintain operation status        | Fixed                | DHW Target 80 °C                      | Fixed                 |
| 5            | Operation On Command         | Very High               | Increase from target temperature      | 0/+30 (Default : +5) | Decrease from target temperature | 0/-30 (Default : -5) | Increase from target temperature      | 0/+50 (Default : +30) |
| 6            | Operation On Recommend       | High                    | Increase from target temperature      | 0/+30 (Default : +2) | Decrease from target temperature | 0/-30 (Default : -2) | Increase from target temperature      | 0/+50 (Default : +10) |
| 7            | Operation Save               | Low                     | Decrease from target temperature      | 0/-30 (Default : -2) | Increase from target temperature | 0/+30 (Default : +2) | Decrease from Target Temperature      | 0/-50 (Default : 0)   |
| 8            | Operation Super Save         | Very Low                | Decrease from target temperature      | 0/-30 (Default : -5) | Increase from target temperature | 0/+30 (Default : +5) | Decrease from Target Temperature      | 0/-50 (Default : 0)   |

## Digital Input for energy saving (ESS, Smart Grid)

This product provides two digital inputs (TB\_SG:ES1/ES2) that can be used to switch between energy states when not using Modbus RTU (CN-COM).

### Available Energy States

There are 8 energy states available in total. Four different states can be triggered using the 230V-inputs – by default Energy states 1-4.

With the digital input assignment in the menu 'Energy state/Digital input assignment' of the control panel, different Energy states can be selected for Signals 0:1 and 1:1.

0:0 is always linked with ES2 (Normal operation) and 1:0 is always linked with ES1 (Operation off/Utility lock).


### How to set Digital input signal

Follow below procedures step 1 ~ step 3.

**Step 1.** Check if the power of the unit is turned off.

**Step 2.** Disassemble front panels and distinguish terminal block in Indoor PCB.

**Step 3.** Connect signal cable to terminal block in PCB (ES2, ES1) fully as shown below.



### Energy state depending on input signal (ES1 / ES2)

| Input Signal |     | Output state   |                                 |
|--------------|-----|----------------|---------------------------------|
| ES1          | ES2 | Default        | Range                           |
| 0            | 0   | Energy state 2 | fixed                           |
| 1            | 0   | Energy state 1 |                                 |
| 0            | 1   | Energy state 3 | Energy state 3 ~ Energy state 8 |
| 1            | 1   | Energy state 4 |                                 |

# 2Way Valve

2way valve is required to control water flow while cooling operation. Role of 2way valve is to cut off water flow into under floor loop in cooling mode when fan coil unit is equipped for cooling operation.

## General Information

**THERMAV.** supports following 2way valve.

| Type                    | Power    | Operating Mode              | Supported |
|-------------------------|----------|-----------------------------|-----------|
| NO 2-wire <sup>1)</sup> | 230 V AC | Energize : Valve Closing    | Yes       |
|                         |          | De-Energize : Valve Opening |           |
| NC 2-wire <sup>2)</sup> | 230 V AC | Energize : Valve Opening    | Yes       |
|                         |          | De-Energize : Valve Closing |           |

1) Normal Open type. When electric power is NOT supplied, the valve is open.  
(When electric power is supplied, the valve is closed.)

2) Normal Closed type. When electric power is NOT supplied, the valve is closed.  
(When electric power is supplied, the valve is open.)


## How to Wire 2Way Valve

Follow below procedures Step 1 ~ Step 2.

**Step 1.** Uncover front cover of the unit.

**Step 2.** Find terminal block and connect wire as below.

**TB 1**



(NO) : Live signal (for Normal Open type) from PCB to 2way valve.

(NC) : Live signal (for Normal Closed type) from PCB to 2way valve.

(N) : Neutral signal from PCB to 2way valve.

## ! CAUTION

### Dew Condensation

- Wrong wiring can yield dew condensation on the floor.  
If radiator is connected at the under floor water loop, dew condensation can be occurred on the surface of the radiator.

## ! WARNING

### Wiring

- Normal Open type should be connected to wire (NO) and wire (N) for valve opening in cooling mode.
- Normal closed type should be connected to wire (NC) and wire (N) for valve closing in cooling mode.

## Final Check

### Flow direction :

- Water should not flow into under floor loop in cooling mode.
- To verify the flow direction, check temperature at the water inlet of the under floor loop.
- If correctly wired, this temperatures should not drop below 16 °C in cooling mode.

## 3Way Valve(A)

3Way Valve(A) is required to operate DHW water tank. Role of 3way valve is flow switching between space heating circuit and water tank heating loop.

### General Information

**THERMA V** supports following 3way valve.

| Type                         | Power      | Operating Mode                                           | Supported |
|------------------------------|------------|----------------------------------------------------------|-----------|
| SPDT <sup>1)</sup><br>3-wire | 220-240 V~ | Selecting Flow A <sup>2)</sup> between Flow A and Flow B | Yes       |
|                              |            | Selecting Flow B <sup>3)</sup> between Flow A and Flow B | Yes       |

1) SPDT = Single Pole Double Throw. Three wires consist of Live1 (for selecting Flow A), Live 2 (for selecting Flow B), and Neutral (for common).

2) Flow A means 'water flow from the unit to space heating circuit.


3) Flow B means 'water flow from the unit to DHW water tank.'

### How to wire 3way valve(A)

Follow below procedures Step 1 ~ Step 2.

Step 1. Uncover front cover of the unit.

Step 2. Find terminal block and connect wire as below.



## WARNING

- 3way valve should select water tank loop when electric power is supplied to wire (W) and wire (N).
- 3way valve should select the heating circuit when electric power is supplied to wire (H) and wire (N).

## NOTE


Operation time of flow control valve(e.g. 3way valve or 2way valve) should be less than 90 seconds.

## Wall-mounted air sensor


Wall-mounted air sensor is highly recommended when the outdoor unit is excessively exposed to sunlight. It is used for weather-dependent operation (Auto mode).

### How to wire Wall-mounted air sensor

[Parts of Wall-mounted air sensor]



Wall-mounted air sensor



Installation Manual



External Cable

\* It is not provided.

Follow below procedures step 1 ~ step 5.

**Step 1.** Decide where the wall-mounted temperature sensor is installed.  
Then, Fixing the sensor on the wall.


**Step 2.** Disassemble cover of the sensor and check the thermistor.

**Step 3.** Connect External cable with the sensor like Fig. 1.


**Step 4.** Check if the power of the unit is turned off.

**Step 5.** Disassemble the front panel of the Indoor unit.

**Step 6.** Insert External cable into PCB(TB\_SENSOR/AMBIENT)



[Fig. 1]



Indoor PCB

[Fig. 2]

## Electric Heater

### How to Pipe Electric Heater

Follow below procedures Step 1 ~ Step 4.

**Step 1.** Uncover the electric heater accessory.

**Step 2.** Check the diameter of pre-installed pipes of unit.

**Step 3.** If the diameter of pre-installed pipes is different from diameter of electric heater accessory kit, it is necessary to reduce or expand pipe's diameter.

**Step 4.** Connect the pipes. The inlet pipe of electric heater accessory must be connected to outlet of the unit.

---

### WARNING

Followings should be kept before installation

- The unit should be stop before the piping work.
- Never connect electric power while piping electric heater.
- Before the piping working, water in the part(or to heating loop) installed with electric heater should be drained. After working, water should be charged.

---


### CAUTION

- Electric Heater should be installed with enough space for installation and service.
  - Water pipes and connections should be cleaned using water.
  - Methods to prevent leakage in plumbing connections must be applied.
  - Heater must not be impacted.
  - Do not let dirty particle be dropped inside tank to avoid possibility of degrade.
  - After installation, make it sure that no leakage is appeared in the connection.
-

## Terminal Block Information

Symbols used below pictures are as follows :

- L, L1, L2 : Live (220-240 V~)
- N : Neutral (220-240 V~)
- R, S, T : Live (380-415 V 3N~)
- BR : Brown, WH : White, BL : Blue, BK : Black






### How to Wire Electric Heater

Follow below procedures Step 1 ~ Step 4.


**Step 1.** Uncover the electric heater accessory.

**Step 2.** Find the terminal block and connect wires. (Wires are field-supplied item.)


**Step 3.** Connect terminal block ports of unit and electric heater accessory.




**(1Ø 3 kW)    Terminal Block 2 (In Backup Heater)**



**(1Ø 6 kW)    Terminal Block 2 (In Backup Heater)**




(3Ø 6 kW) Terminal Block 2 (In Backup Heater)




Step 4. Connect power supply cable to terminal block 2.

Terminal Block 2 (In 1Ø Backup Heater)



Terminal Block 2 (In 3Ø Backup Heater)



NOTE


Turn off electric power supply before setting DIP switch.  
Whenever adjusting DIP switch, turn off electric power supply to avoid electric shock.

| Description                        | Setting |                                       | Default |
|------------------------------------|---------|---------------------------------------|---------|
| Selecting electric heater capacity |         | Electric heater is not used           |         |
|                                    |         | Half capacity is used only for HA061M |         |
|                                    |         | Full capacity is used                 |         |


\* For the above change, you need to adjust 6 and 7 of Indoor PCB option switch2.

## Typical Installation Example (Backup heater for Monobloc)

### Floor heating + Backup Heater (Only Heating)



### Floor heating + Convactor + Backup Heater (Heating + Cooling)



## NOTE

- When the Backup Heater is installed in a reversible system, condensation may occur inside the Backup Heater.
- To provide a bypass for the condensate, install 3way valve.
- During cooling operation, connect the 3-Way Valve using the 2-Way Valve connection terminal to prevent water from going to the Backup Heater


## How to Install 3way Valve for Backup Heater Bypass

Follow below procedures Step 1 ~ Step 2.

Step 1. Uncover front cover of the unit.

Step 2. Find terminal block and connect wire as below.

When Tightening the connect wire on terminal block, Be careful to prevent a shock or injury. (230 VAC)



### ⚠ WARNING

- When type of 2way valve is NO type, 3way valve should select Flow A(bypass). Electric power is supplied to wire(NO) and wire(N).
- When type of 2way valve is NC type, 3way valve should select Flow B(heating In Backup heater). Electric power is supplied to wire(NC) and wire(N).

### ⚠ CAUTION

- 3way valve should be connected together with 2way valve in terminal block.
- Keep the distance between 3way valve and Backup Heater more than 0.5m.
- To prevent reverse flow, It is important to use one way valve(check valve) to Backup Heater water outlet.

## How to Connect Backup Heater Sensor to Unit

Follow below procedures Step 1 – Step 5.

- ① Find backup heater terminal block Kit(Fig. 1).
- ② Assemble the terminal block kit using screw on unit.
- ③ Plug it to 'E/Heater Out' (White Connector) of CN\_TH3 in the Main PCB (Unit) as shown Fig.2.
- ④ Connect harness between the unit and the Backup Heater until it clicks into place.(Fig. 3).
- ⑤ Use the cord clamp to fix the cable through low voltage hole.




Fig.1




Fig.2



Fig.3

※ The terminal block connection number may differ depending on the model. Refer to the "Wiring Diagram" in the SVC Manual.

## Final check

| No. | Check point                               | Description                                                                                                                                                                                                                                                                                                                                               |
|-----|-------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | Connection of Water Inlet/Outlet          | <ul style="list-style-type: none"> <li>- Check if the shut-off valves should be assembled with Water inlet and outlet pipe of the unit</li> <li>- Check the location of the water inlet/outlet water pipe</li> </ul>                                                                                                                                      |
| 2   | Hydraulic pressure                        | <ul style="list-style-type: none"> <li>- Check the pressure of supplying water by using pressure gauge inside the unit (Monitoring screen).</li> <li>- Pressure of Supplying water should be Under 3.0 bar approximately</li> </ul>                                                                                                                       |
| 3   | Water pump capacity                       | <ul style="list-style-type: none"> <li>- To secure enough water flow rate, do not set water pump capacity as Minimum.</li> <li>- It can lead unexpected flow rate error CH14. (Refer to 'Water Piping and Water Circuit Connection')</li> </ul>                                                                                                           |
| 4   | Transmission line and power source wiring | <ul style="list-style-type: none"> <li>- Check if Transmission line and power source wiring are separated from each other.</li> <li>- If it is not, electronic noise may occur from the power source.</li> </ul>                                                                                                                                          |
| 5   | The power cord specifications             | <ul style="list-style-type: none"> <li>- Check the power cord specifications (Refer to 'Communication cable')</li> </ul>                                                                                                                                                                                                                                  |
| 6   | 3Way Valve                                | <ul style="list-style-type: none"> <li>- Water should flow from Water outlet of the unit to sanitary tank Water inlet when sanitary tank heating is selected.</li> <li>- To verify the flow direction, Make sure that the water outlet temperature of the unit and water inlet temperature of sanitary Water tank are similar</li> </ul>                  |
| 7   | 2Way Valve                                | <ul style="list-style-type: none"> <li>- Water should not flow into under floor loop in cooling mode.</li> <li>- To verify the flow direction, check temperature at the water inlet of the under floor loop.</li> <li>- If correctly wired, this temperatures should not drop below 16 °C in cooling mode.</li> </ul>                                     |
| 8   | Air Vent                                  | <ul style="list-style-type: none"> <li>- Air-vent must be located highest level of Water pipe system</li> <li>- It should be installed at the point which is easy to service.</li> <li>- It takes some times to remove air in the water system if air purge is not performed sufficiently it may occur CH14 error. (Refer to 'Water Charging')</li> </ul> |

## WARNING

Do not use an automatic air-vent, as flammable refrigerant may leak into the water circuit and get released through an automatic valve into the building.

# CONFIGURATION

As **THERMAV** is designed to satisfy various installation environment, it is important to set up system correctly. If not configured correctly, improper operation or degrade of performance can be expected.

## DIP Switch Setting


### ! CAUTION

Turn off electric power supply before setting DIP switch

- Whenever adjusting DIP switch, turn off electric power supply to avoid electric shock.

## General Information

### Indoor PCB



## DIP Switch Information

## Option Switch 1

| Description                              | Setting                                                                                  |                                                 | Default                                                                                  |
|------------------------------------------|------------------------------------------------------------------------------------------|-------------------------------------------------|------------------------------------------------------------------------------------------|
| MODBUS Communication Type                | <br>1   | As Master<br>(LG extension modules)             | <br>1   |
|                                          | <br>1   | As Slave<br>(3rd party controller)              |                                                                                          |
| MODBUS Function                          | <br>2   | Unified Open Protocol                           | <br>2   |
|                                          | <br>2   | No function                                     |                                                                                          |
| Communication Outdoor ↔ Indoor Unit      | <br>3   | RS-485(EIA-485) method,<br>Flat (9600bps / TLV) | <br>3   |
|                                          | <br>3   | AC method (150bps / 7bytes)                     |                                                                                          |
| Heating cycle limited operation* control | <br>7   | Protective function is not used                 | <br>7   |
|                                          | <br>7   | Protective function is used                     |                                                                                          |
| Antifreeze Agent                         | <br>8 | Antifreeze agent is not used                    | <br>8 |
|                                          | <br>8 | Antifreeze agent is used **                     |                                                                                          |

\* Heating Cycle Limited Operation can limit product limit operation for protecting compressor, INV-PCB. If heating cycle limited operation control is used and the product operates in the outside of declared product operation map, it'll become thermal off.

- Product operation map : See Product Databook.

\*\* Possibility to allow colder water temperature by setting.  
Bridge at CN\_ANTI\_SW must be dis-connected to enable setting.

## WARNING


NEVER change setting if antifreeze agent (glycole) is not actually added.

Option Switch 2

| Description                        | Setting                                                                                  |                                                                                         | Default                                                                                                                                                                          |
|------------------------------------|------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Accessory installation information | <br>2   | <br>3  | <br>2<br><br>3 |
|                                    | <br>2   | <br>3  |                                                                                                                                                                                  |
|                                    | <br>2   | <br>3  |                                                                                                                                                                                  |
| Cycle                              | <br>4   | Heating Only                                                                            | <br>4                                                                                           |
|                                    | <br>4   | Heating & Cooling                                                                       |                                                                                                                                                                                  |
| Selecting Backup heater capacity   | <br>6   | <br>7  | <br>6<br><br>7 |
|                                    | <br>6   | <br>7  |                                                                                                                                                                                  |
|                                    | <br>6   | <br>7  |                                                                                                                                                                                  |
|                                    | <br>6  | <br>7 |                                                                                                                                                                                  |
| Thermostat installation informatio | <br>8 | Thermostat is NOT installed                                                             | <br>8                                                                                         |
|                                    | <br>8 | Thermostat is installed                                                                 |                                                                                                                                                                                  |



## Outdoor PCB



DIP Switch Information

| Description    | Setting                                                                                |                                                                                                 | Default                                                                                                                                                                          |
|----------------|----------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Low Noise Mode | <br>2 | Always Mode<br>- Maintain low noise mode even if target temp. cannot be reached for long time.  | <br>2                                                                                           |
|                | <br>2 | ON/OFF Partial mode<br>- Escape low noise mode if target temp. cannot be reached for long time. |                                                                                                                                                                                  |
| Peak Control   | <br>3 | <br>4          | <br>3<br><br>4 |
|                | <br>3 | <br>4          |                                                                                                                                                                                  |
|                | <br>3 | <br>4          |                                                                                                                                                                                  |
|                |                                                                                        | Max Mode                                                                                        |                                                                                                                                                                                  |
|                |                                                                                        | Peak Control Step 1<br>- To limit maximum current (Power saving)                                |                                                                                                                                                                                  |
|                |                                                                                        | Peak Control Step 2<br>- To limit maximum current (Power saving)                                |                                                                                                                                                                                  |

- ※ When setting the limited low noise mode, Mode can be exited to secure capacity after operating for a certain time.
- ※ Peak Control Step 3&4: Please contact LG Service for details.

NOTE

Input current value can be limited by DIP Switch operation.


| Buyer Model Name             | Model Name |           |               | Peak Control Mode Running Current (A) |        |
|------------------------------|------------|-----------|---------------|---------------------------------------|--------|
|                              | Chassis    | Phase (Ø) | Capacity (kW) | 1 Step                                | 2 Step |
| HM091 / 071 / 051MRS<br>UA40 | UN36A      | 1         | 5             | 13                                    | 11     |
|                              |            |           | 7             | 14                                    | 12     |
|                              |            |           | 9             | 15                                    | 13     |
| HM161 / 141 / 121MRS<br>UB40 | UN36B      | 1         | 12            | 23                                    | 20     |
|                              |            |           | 14            | 24                                    | 21     |
|                              |            |           | 16            | 25                                    | 22     |
| HM163 / 143 / 123MRS<br>UB40 |            | 3         | 12            | 8                                     | 6      |
|                              |            |           | 14            | 9                                     | 7      |
|                              |            |           | 16            | 10                                    | 8      |

# SERVICE SETTING

## How to enter service setting

To enter the menu displayed at the bottom, you need to enter the service setting menu as follows.

- In the menu screen, press [,<,>(left/right)] button to select the setting category, and press [OK] button to move to the setting list.
- In the setting list, select the service setting category, and press [OK] button to move to the service setting list.



## Service setting

- You can set the product service functions.
- Some functions may not be displayed/operated in some product types.

| Menu                    | Description                                                                                    |
|-------------------------|------------------------------------------------------------------------------------------------|
| Service contact         | Check and input the service center phone number that you can call when there is service issue. |
| Model information       | View product and capacity information                                                          |
| RMC Version Information | Check the remote controller model name and software version.                                   |
| Open Source License     | View the remote controller's open source license.                                              |

## Service contact

Check and input the service center phone number that the user can call when there is service issue.

- In the service setting list, select the service contact point and press [OK] button to move to the detail screen.
- While “edit” button is selected, press [OK] button to move to the edit screen, change it, and press [OK] button to change the service contact point.

Service

Back

OK

Service Contact

>

Model Information

>

RMC Version Information

>

Open Source License

>



OK

Service Contact

Back

OK

Telephone

+1544-7777

Edit



OK

Service Contact

Back

OK

Telephone

+

1

5

4

4

-

7

7

7

7


# INSTALLER SETTING

## How to enter installer setting

### ⚠ CAUTION

The installer setting mode is the mode to set the remote controller's detail function. If the installer setting mode is incorrectly set, it may cause product failure, user's injury, or property damage. It must be set by the installation specialist with the installation license, and if it is installed or changed without installation license, all problems caused will be the responsibility of the installer, and may void the LG warranty.

- In the menu screen, press [ $\leftarrow$ ,  $\rightarrow$ ] (left/right) button to select the setting category, and press [ $\wedge$ ] (up) button for 3 seconds to enter the password input screen for the installer setting.
- Input the password and press [OK] button to move to the installer setting list.



※ Installer setting password

Main screen → menu → setting → service → RMC version information → SW Version

**Example)** SW version : 3.05.3a

In the above case, the password is 3053.

### NOTE

Some categories of the installer setting menu may not be available depending on the product function or the menu name may be different.

## Installer setting

- You can set the product user functions.
- Some functions may not be displayed/operated in some product types.

| Menu hierarchy & Setting |                     | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                           | Detailed explanation                                                                                                                                                                              | Available Setting options (range) | Unit | Default           |
|--------------------------|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------|------|-------------------|
| CONFIGURATION            | Control method      | The product can be operated according to air temperature, water temperature, or both.<br>- <b>Water</b> : The product operates by comparing the current water temperature and the target water temperature.<br>- <b>Air</b> : The product operates by comparing the current air temperature and the target air temperature.<br>- <b>Air+Water</b> : The product operates considering both the water temperature and air temperature conditions above. | ○                                                                                                                                                                                                 | Air / Water / Air+Water           | -    | Water             |
|                          |                     | Definition to which circuit this Remote controller is linked to.<br>- <b>Circuit 1&amp;2</b> : This RMC is used to control the whole heating system<br>- <b>Circuit 1</b> : This RMC is used to control Circuit 1 (unmixed circuit) only<br>- <b>Circuit 2</b> : This RMC is used to control Circuit 2 (mixed circuit) only                                                                                                                           |                                                                                                                                                                                                   |                                   |      |                   |
|                          |                     | RMC linked to                                                                                                                                                                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                   |                                   |      |                   |
|                          | Select room devices | Digital input                                                                                                                                                                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                   | CN-CC / CN-THMO / CN-EXT          | -    | CN-CC             |
|                          | Circuit 1           |                                                                                                                                                                                                                                                                                                                                                                                                                                                       | In case of Air- or Water+Air-control method, either a Room sensor or the Remote controller can be used to sense the Room air temp. The device must be installed in a Reference room of Circuit 1. | Room Sensor / Remote Controller   | -    | Remote Controller |

| Menu hierarchy & Setting |                       |                    | Explanation                                                                                                                                                                                  | Detailed explanation                                                                                                                                                                                                                                                                                                                                                                                                | Available Setting options (range) | Unit    | Default           |
|--------------------------|-----------------------|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------|---------|-------------------|
| CONFIGURATION            | Select room devices   | Circuit 2          | Digital input                                                                                                                                                                                | With this setting a Digital input (Dry contact, 3rd party thermostat or external input) can be linked to Circuit 2.<br>Consequently, the signal will be used as thermo-on/off command for Circuit 2 only.                                                                                                                                                                                                           | CN-CC / CN-THMO / CN-EXT          | -       | CN-CC             |
|                          |                       |                    | Room air sensor option                                                                                                                                                                       | In case of Air- or Water+Air-control method, either a Room sensor or the Remote controller can be used to sense the Room air temp.<br>The device must be installed in a Reference room of Circuit 2.                                                                                                                                                                                                                | Room Sensor / Remote Controller   | -       | Remote Controller |
|                          | Mixing Circuit        | Mixing Circuit     | Additional mixing circuit is enabled using sensor CN-MIX-OUT and 3rd-party mixer.<br>In case of 'Heating only', the Mixing valve is closed and the Mix pump is off during Cooling operation. | Not use / Heating & Cooling / Heating only                                                                                                                                                                                                                                                                                                                                                                          | -                                 | Not use |                   |
|                          |                       | Valve Closing Time | Set operating time of 3rd-party mixer motor (Full open → Full close)                                                                                                                         | 60 ~ 999                                                                                                                                                                                                                                                                                                                                                                                                            | sec                               | 240     |                   |
|                          | Backup heater for DHW |                    |                                                                                                                                                                                              | Defines if Backup heater is used for re-heating the DHW in case of Emergency. To use this function the backup heater must be installed and configured by DIP switch!<br>If the DHW boost heater inside of the tank is configured too, both heaters will run in parallel!<br>In case of 'Combination indoor unit' with integrated tank, always the Backup heater is supporting both - space heating and DHW heating! | Use / Not use                     | -       | Not use           |



| Menu hierarchy & Setting  |                | Explanation                                                                                                                                                                                                                                                                                      | Detailed explanation | Available Setting options (range)                           | Unit | Default        |
|---------------------------|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|-------------------------------------------------------------|------|----------------|
| External pump             | Pump Setting   | Setting if External pump is used and for what purpose.<br>- Heat & Cool & DHW: The external pump operates synchronously with the built-in pump inside the product.                                                                                                                               | ○                    | Not use /<br>Heat & Cool & DHW /<br>Heat&Cool /<br>Circuit1 | -    | Not use        |
|                           |                | - Heat & Cool: The external pump operates synchronously with the built-in pump inside the product - except for DHW heating.<br>- Circuit 1: The external pump is installed within Radiator circuit (Circuit 1) in case of two circuits.                                                          |                      |                                                             |      |                |
|                           | Boiler Setting | Setting whether to use an external pump when using the boiler.<br>- Remark: If the boiler operation function is enabled, the function is activated.                                                                                                                                              |                      | Use /<br>Not use                                            | -    | Not use        |
| CONFIGURATION             |                |                                                                                                                                                                                                                                                                                                  |                      |                                                             |      |                |
| Boiler output             |                | Setting whether 3rd-party boiler is connected to TB_EXT/EXT_BOILER and enabled below Bivalent point.<br>- <b>Heat &amp; DHW:</b> The boiler is used for Space heating and DHW.<br>- <b>Heating only:</b> The boiler is used for Space heating only. The heat pump is heating the DHW year-round. | ○                    | Not use /<br>Heat & DHW /<br>Heating only                   | -    | Not use        |
| DHW boost heater          |                | If an electric boost heater is installed in the DHW tank, choose 'Installed'.                                                                                                                                                                                                                    |                      | Installed /<br>Not installed                                | -    | Installed      |
| Select outdoor air sensor |                | Definition which sensor is used to read the outdoor air temperature needed for Auto mode.                                                                                                                                                                                                        | ○                    | ODU air sensor /<br>Wall-mounted air sensor                 | -    | ODU air sensor |
| Buffer tank sensor        |                | An additional temperature sensor is installed inside or at outlet of the buffer tank and used control the water temp.                                                                                                                                                                            |                      | Not use / Use                                               | -    | Not use        |

| Menu hierarchy & Setting |                           |               | Explanation                                                                                                                                                                                                                                                                                                                                         | Detailed explanation | Available Setting options (range) | Unit | Default |
|--------------------------|---------------------------|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|-----------------------------------|------|---------|
| CONFIGURATION            | Boiler Pump Operation     | Main Pump     | Setting defines if the Main pump remains operative, while the boiler is enabled.                                                                                                                                                                                                                                                                    |                      | Not use / Use                     | -    | Not Use |
|                          |                           | External Pump | Setting defines if the External pump remains operative, while the boiler is enabled.                                                                                                                                                                                                                                                                |                      | Not use / Use                     | -    | Use     |
|                          | RMC master/slave          |               | If an additional RMC is used to be placed inside Reference room, this setting must be changed to 'Slave'. The RMC that becomes 'Master' will show all setting options.<br>The 'Slave' will show the complete User menu, but a limited Installer menu. Room air temp. measured by Slave will be used as reference for 'Air' and 'Air+Water' control. | O                    | Master / Slave                    | -    | Master  |
|                          | LG Thermo V configuration |               | Read data' will read configuration file from SD-Card. File name must be 'RS3_AWHP_DATA' in root directory!<br>'Save data' will save configuration file to SD-Card. Make sure that all settings have been adjusted before copy/paste to another site that has the same system design.                                                                |                      | Read Data / Save Data             | -    | -       |
|                          | Forced pump operation     |               | If this function is activated, the internal pump will run at set interval to prevent stucking of pump when unit is out of operation for long time.<br>Based on setting 'Configuration/External pump', the External pump will be activated, too.                                                                                                     |                      | Use / Not use                     | -    | Use     |
|                          |                           |               | Oper. Cycle                                                                                                                                                                                                                                                                                                                                         |                      | 20 ~ 180                          | h    | 20      |
|                          |                           |               | Oper. Time                                                                                                                                                                                                                                                                                                                                          |                      | 1 ~ 10                            | min  | 10      |
|                          | Pump prerin/overrun       |               | Pump prerin                                                                                                                                                                                                                                                                                                                                         |                      | 1 ~ 10                            | h    | 1       |
|                          |                           |               | Pump overrun                                                                                                                                                                                                                                                                                                                                        |                      | 1 ~ 10                            | min  | 1       |
|                          | GENERAL                   |               |                                                                                                                                                                                                                                                                                                                                                     |                      |                                   |      |         |

| Menu hierarchy & Setting |                    | Explanation       | Detailed explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Available Setting options (range)                                                      | Unit | Default           |
|--------------------------|--------------------|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|------|-------------------|
| GENERAL                  | Water flow control | Control Method    | <p>Different options to control the integrated circulation pump (Main pump):</p> <ul style="list-style-type: none"> <li>- Pump capacity: Fixed setting for pump capacity (0-100%) is applied.</li> <li>- Fixed flow rate: Fixed setting for flow rate in l/min is applied.</li> <li>- Fixed <math>\Delta T</math>: Fixed setting for temperature difference between inlet and outlet.</li> <li>- Optimal flow rate: The target temperature difference between inlet and outlet is automatically adjusted (between 5 and 10 Kelvin) based on target temperature.</li> </ul> | O<br>- Optimal Flow Rate<br>- Pump Capacity<br>- Fixed Flow Rate<br>- Fixed $\Delta T$ | -    | Optimal flow rate |
|                          |                    |                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                                                                                        |      |                   |
|                          | Pump Capacity      | Heating / Cooling | <p>The pump capacity is fixed at the set value if control method 'Pump capacity' is chosen and the heat pump cycle is in operation.</p> <p>- <b>Remark:</b> The following settings are used for all Control methods</p>                                                                                                                                                                                                                                                                                                                                                    | 10 ~ 100                                                                               | %    | 100               |
|                          |                    | Cycling           | Setting defines the pump capacity when the heat pump is cycling while the compressor is in standby (thermo-off condition).                                                                                                                                                                                                                                                                                                                                                                                                                                                 | 10 ~ 100                                                                               | %    | 30                |
|                          |                    | Anti-scale        | Setting defines the pump capacity when the frost-protection function is enabled.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | 10 ~ 100                                                                               | %    | 50                |
|                          |                    | Frost protection  | Setting defines the pump capacity during 'Forced pump operation'.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | 10 ~ 100                                                                               | %    | 100               |
|                          | Prerun/Overrun     |                   | Setting defines the pump capacity during 'Pump prerun/overrun' time.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | 10 ~ 100                                                                               | %    | 100               |

| Menu hierarchy & Setting |                    |                        |                        | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | Detailed explanation | Available Setting options (range)                                                                                                            | Unit  | Default |                                                                                                |   |
|--------------------------|--------------------|------------------------|------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|----------------------------------------------------------------------------------------------------------------------------------------------|-------|---------|------------------------------------------------------------------------------------------------|---|
| GENERAL                  | Water flow control | Fixed Flow Rate        | Fixed flow rate (Heat) | The target flow rate can be set individually for each operation mode, if control method 'Fixed flow rate' is chosen.                                                                                                                                                                                                                                                                                                                                                           |                      | 11 ~ 46                                                                                                                                      | l/min | 46      |                                                                                                |   |
|                          |                    |                        | Fixed flow rate (Cool) |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |                      |                                                                                                                                              |       |         |                                                                                                |   |
|                          |                    |                        | Fixed flow rate (DHW)  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |                      |                                                                                                                                              |       |         |                                                                                                |   |
|                          |                    | Fixed ΔT               | Fixed ΔT (Heat)        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |                      | The target temperature gap between inlet and outlet can be individually set for each operation mode, if control method 'Fixed ΔT' is chosen. |       | 5 ~ 13  | K                                                                                              | 5 |
|                          |                    |                        | Fixed ΔT (Cool)        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |                      |                                                                                                                                              |       |         |                                                                                                |   |
|                          |                    |                        | Fixed ΔT (DHW)         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |                      |                                                                                                                                              |       |         |                                                                                                |   |
|                          | Energy Monitoring  | Energy Monitoring      |                        | - Not use : Energy data is not displayed<br>- Use: Energy data is displayed. In general, the internal sensors are used to estimate the consumed electricity and generated thermal energy. If metering module is connected, the estimated values will be overwritten with measured values.<br><b>Remark:</b> If anti-freeze is used, the internal metering becomes too inaccurate and either metering module should be connected or the setting should be changed to 'Not use'! |                      | Not use / Use                                                                                                                                | -     | Use     |                                                                                                |   |
|                          |                    | Backup heater capacity | Backup heater type     | Definition what type of electric backup heater is used.                                                                                                                                                                                                                                                                                                                                                                                                                        |                      |                                                                                                                                              |       |         |                                                                                                |   |
|                          |                    |                        | Backup heater capacity |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |                      |                                                                                                                                              |       |         | Input the rated capacity of the external backup heater. It is used for energy monitoring only. |   |
|                          |                    |                        |                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |                      |                                                                                                                                              |       |         |                                                                                                |   |
|                          |                    |                        |                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |                      | 1.0 ~ 10.0                                                                                                                                   | kW    | 6       |                                                                                                |   |

| Menu hierarchy & Setting |                             | Explanation                                                                                                                                                                                                                  | Detailed explanation | Available Setting options (range) | Unit | Default |
|--------------------------|-----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|-----------------------------------|------|---------|
| GENERAL                  | Anti-freezing option        | Setting defines the anti-freezing protection while the Remote controller is turned off.<br><b>- Type 1:</b> Outside air temp. and Water inlet temp. is supervised.<br><b>- Type 2:</b> Only outside air temp. is supervised. | O                    | Type1 / Type2                     | -    | Type 1  |
|                          | Backup heater release temp. | Bivalent point: Below this outdoor air temperature, the backup heater is enabled.<br><b>Remark:</b> Even if outdoor temp. is colder, the heater will only turn on if necessary!                                              | O                    | -25 ~ 18                          | °C   | -5      |
|                          | Screed drying               | Activation                                                                                                                                                                                                                   | O                    | On / Off                          | -    | Off     |
|                          |                             | Step                                                                                                                                                                                                                         |                      | 1 ~ 11                            | -    | 1       |
|                          |                             | Max. temp.                                                                                                                                                                                                                   |                      | 35 ~ 55                           | °C   | 55      |
|                          |                             | Step 8 Holding                                                                                                                                                                                                               |                      | 1 ~ 30                            | days | 7       |
|                          | Heating priority            | Determination if room heating or sanitary hot water has higher priority to be heated.                                                                                                                                        |                      | DHW / Space heating               | -    | DHW     |
|                          |                             |                                                                                                                                                                                                                              |                      |                                   |      |         |
|                          |                             |                                                                                                                                                                                                                              |                      |                                   |      |         |
|                          |                             |                                                                                                                                                                                                                              |                      |                                   |      |         |

| Menu hierarchy & Setting |                        | Explanation                                                                                                                                                                                                                                                                                                                                                                           | Detailed explanation | Available Setting options (range)   | Unit | Default      |
|--------------------------|------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|-------------------------------------|------|--------------|
| GENERAL                  | Buffer tank hysteresis | If the buffer tank is hot enough to satisfy the heat(cool) demand of the heating (cooling) circuit(s), the heat pump won't turn on, until the buffer tank temp. has dropped below the target of the heating circuit. (has increased above the target of the cooling circuit).<br>The hysteresis should be increased step-by-step if the heat pump cycles too much even in wintertime. | O                    | 0 ~ 20                              | K    | 2            |
|                          | Password Reset         | Setting will reset the User password to '0000'.                                                                                                                                                                                                                                                                                                                                       |                      | Reset                               | -    | -            |
| CIRCUIT1                 | Control method(Heat)   | Definition if inlet or outlet temp. is used as target for heating operation.                                                                                                                                                                                                                                                                                                          |                      | Inlet / Outlet                      | -    | Outlet       |
|                          |                        | Definition if inlet or outlet temp. is used as target for Cooling operation.                                                                                                                                                                                                                                                                                                          |                      | Inlet / Outlet                      | -    | Outlet       |
|                          | Basic settings         | - <b>Time setting</b> : Main circulation pump is turned on and off according to set On/Off times.<br>- <b>Continuous operation</b> : Main circulation pump is running continuously during heating (cooling) period.<br>Only in summertime it is turned off.                                                                                                                           |                      | Time setting / Continuous Operation |      | Time setting |
|                          |                        | Setting defines duration of Main pump operation to sense reference temp. from Circuit 1.<br>Value should be adjusted based on length of pipework.                                                                                                                                                                                                                                     |                      | 1 ~ 60                              | min  | 3            |
|                          |                        | Setting defines interval between Main pump operations, while Thermo-off. Value should be adjusted based on building insulation standard.                                                                                                                                                                                                                                              |                      | 1 ~ 60                              | min  | 3            |



| Menu hierarchy & Setting |                |                               | Explanation | Detailed explanation                                                                                                                                                                                                                                                | Available Setting options (range)   | Unit | Default              |
|--------------------------|----------------|-------------------------------|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|------|----------------------|
| CIRCUIT1                 | Basic settings | Main Pump Operation (Cool)    | Type        | <p><b>- Time setting</b> : Main circulation pump is turned on and off according to set On/Off times.</p> <p><b>- Continuous operation</b> : Main circulation pump is running continuously during heating (cooling) period. Only in summertime it is turned off.</p> | Time setting / Continuous Operation |      | Continuous Operation |
|                          |                |                               | On          | Setting defines duration of Main pump operation to sense reference temp. from Circuit 1. Value should be adjusted based on length of pipework.                                                                                                                      |                                     |      |                      |
|                          |                | Off                           |             | Setting defines interval between Main pump operations, while thermo-off. Value should be adjusted based on building insulation standard.                                                                                                                            | 1 ~ 60                              | min  | 3                    |
|                          |                |                               | Temp On     | Settings define the hysteresis applied to water temp. control of Circuit 1                                                                                                                                                                                          |                                     |      |                      |
|                          |                |                               | Temp Off    |                                                                                                                                                                                                                                                                     | -9.0 ~ 0.0                          | K    | -2.0                 |
|                          |                | Hysteresis water temp. (Heat) |             |                                                                                                                                                                                                                                                                     | 0.0 ~ 4.0                           | K    | 2.0                  |
|                          |                |                               | Temp On     | Settings define the hysteresis applied to water temp. control of Circuit 1                                                                                                                                                                                          | 0.0 ~ 3.0                           | K    | 0.5                  |
|                          |                |                               | Temp Off    |                                                                                                                                                                                                                                                                     | -3.0 ~ 0.0                          | K    | -0.5                 |
|                          |                | Hysteresis room air (Heat)    | Temp On     | Settings define the hysteresis applied to room air temp. control of Circuit 1                                                                                                                                                                                       | -3.0 ~ 0.0                          | K    | -0.5                 |
|                          |                |                               | Temp Off    |                                                                                                                                                                                                                                                                     | 0.0 ~ 4.0                           | K    | 1.5                  |
|                          | Room Heating   | Hysteresis room air (Cool)    | Temp On     | Settings define the hysteresis applied to room air temp. control of Circuit 1                                                                                                                                                                                       | 0.0 ~ 3.0                           | K    | 0.5                  |
|                          |                |                               | Temp Off    |                                                                                                                                                                                                                                                                     | -3.0 ~ 0.0                          | K    | -0.5                 |
|                          |                | Air heating set temp          | Min.        | The User's setting range of room air target temperature in HEAT mode can be limited                                                                                                                                                                                 | 16 ~ 22                             | °C   | 16                   |
|                          |                |                               | Max.        |                                                                                                                                                                                                                                                                     | 24 ~ 30                             | °C   | 30                   |
|                          |                | Water heating set temp        | Min.        | The User's setting range of water target temperature in HEAT mode can be limited                                                                                                                                                                                    | 15 ~ 34                             | °C   | 15                   |
|                          |                |                               | Max.        |                                                                                                                                                                                                                                                                     | 35 ~ 75                             | °C   | 65                   |

| Menu hierarchy & Setting |                |                             |      | Explanation                                                                                                                                                                                                                                                                                                                                      | Detailed explanation | Available Setting options (range)   | Unit | Default      |
|--------------------------|----------------|-----------------------------|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|-------------------------------------|------|--------------|
| CIRCUIT1                 | Room Cooling   | Air cooling set temp        | Min. | The User's setting range of room air target temperature in COOL mode can be limited                                                                                                                                                                                                                                                              | O                    | 16 ~ 22                             | °C   | 16           |
|                          |                |                             | Max. |                                                                                                                                                                                                                                                                                                                                                  |                      | 24 ~ 30                             | °C   | 30           |
|                          |                | Water cooling set temp      | Min. | The User's setting range of water target temperature in COOL mode can be limited                                                                                                                                                                                                                                                                 | O                    | 5 ~ 20                              | °C   | 10           |
|                          |                |                             | Max. |                                                                                                                                                                                                                                                                                                                                                  |                      | 22 ~ 27                             | °C   | 24           |
| CIRCUIT2                 | Basic settings | Cut Off Temperature (Heat)  |      | Maximum temperature according underfloor heating system's manufacturer.<br>If Mix temp. sensor reach this temperature, the Mix pump will stop and the Mixing valve will close. The water will circulate inside the Mix circuit until temperature has dropped.                                                                                    |                      | 20 ~ 75                             | °C   | 40           |
|                          |                |                             |      | Minimum temperature according underfloor heating system's manufacturer. If temperature is reached, the Mix pump will stop and the Mixing valve will close. The water will circulate inside the Mix circuit until temperature has risen again.<br>Remark: Prevention of condensate must be realized by additional measures like humidity monitor. |                      | 5 ~ 24                              | °C   | 18           |
|                          |                | Mixing pump operation(Heat) | Type | <b>- Time setting</b> : Circulation pump installed in the mixing circuit is turned on and off according to set On/Off times.<br><b>- Continuous operation</b> : Circulation pump installed in the mixing circuit is running continuously during heating (cooling) period. Only in summertime it is turned off.                                   |                      | Time setting / Continuous Operation |      | Time setting |
|                          |                |                             |      | Setting defines duration of Mixing pump operation to sense reference temp. from Circuit 2. Value should be adjusted based on length of pipework.                                                                                                                                                                                                 |                      | 1 ~ 60                              | min  | 3            |
|                          |                |                             | Off  | Setting defines interval between Mixing pump operations, while Thermo-off. Value should be adjusted based on building insulation standard.                                                                                                                                                                                                       |                      | 1 ~ 60                              | min  | 3            |



| Menu hierarchy & Setting |                |                              | Explanation | Detailed explanation                                                                                                                                                                                                                                                                             | Available Setting options (range)   | Unit | Default              |
|--------------------------|----------------|------------------------------|-------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|------|----------------------|
| CIRCUIT2                 |                | Mixing pump operation(Cool)  | Type        | - Time setting : Circulation pump installed in the mixing circuit is turned on and off according to set On/Off times.<br>- Continuous operation : Circulation pump installed in the mixing circuit is running continuously during heating (cooling) period. Only in summertime it is turned off. | Time setting / Continuous Operation |      | Continuous Operation |
|                          |                |                              | On          | Setting defines duration of Mixing pump operation to sense reference temp. from Circuit 2. Value should be adjusted based on length of pipework.                                                                                                                                                 | 1 ~ 60                              | min  | 3                    |
|                          |                |                              | Off         | Setting defines interval between Mixing pump operations, while Thermo-off. Value should be adjusted based on building insulation standard.                                                                                                                                                       | 1 ~ 60                              | min  | 3                    |
|                          | Basic settings | Hysteresis water temp.(Heat) | Temp On     | Settings define the hysteresis applied to water temp. control of Circuit 2                                                                                                                                                                                                                       | -9.0 ~ 0.0                          | K    | -2.0                 |
|                          |                |                              | Temp Off    |                                                                                                                                                                                                                                                                                                  | 0.0 ~ 4.0                           | K    | 2.0                  |
|                          |                | Hysteresis water temp.(Cool) | Temp On     | Settings define the hysteresis applied to water temp. control of Circuit 2                                                                                                                                                                                                                       | 0.0 ~ 3.0                           | K    | 0.5                  |
|                          |                |                              | Temp Off    |                                                                                                                                                                                                                                                                                                  | -3.0 ~ 0.0                          | K    | -0.5                 |
|                          |                | Hysteresis room air(Heat)    | Temp On     | Settings define the hysteresis applied to room air temp. control of Circuit 2                                                                                                                                                                                                                    | -3.0 ~ 0.0                          | K    | -0.5                 |
|                          |                |                              | Temp Off    |                                                                                                                                                                                                                                                                                                  | 0.0 ~ 4.0                           | K    | 1.5                  |
|                          |                | Hysteresis room air(Cool)    | Temp On     | Settings define the hysteresis applied to room air temp. control of Circuit 2                                                                                                                                                                                                                    | 0.0 ~ 3.0                           | K    | 0.5                  |
|                          |                |                              | Temp Off    |                                                                                                                                                                                                                                                                                                  | -3.0 ~ 0.0                          | K    | -0.5                 |

| Menu hierarchy & Setting |                |                        | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | Detailed explanation | Available Setting options (range) | Unit | Default |
|--------------------------|----------------|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|-----------------------------------|------|---------|
| CIRCUIT2                 | Basic settings | Comp. Operation        | <p>- Type 1: When the compressor operates, it operates by referencing the target temperature of both Circuit 1 and Circuit 2. When only Circuit 2 is thermo-on condition, the compressor still operates. Under certain conditions, it can happen that the temperature of Circuit 1 overshoots its target temperature.</p> <p>- Type 2 : When the compressor operates, it operates by referencing the target temperature of Circuit 1. When only Circuit 2 is thermo-on condition, the compressor is stopped.</p> |                      | Type1 / Type2                     | -    | Type 2  |
|                          |                |                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |                      |                                   |      |         |
|                          | Room Heating   | Air heating set temp   | Min.<br>Max.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | O                    | 16 ~ 22                           | °C   | 16      |
|                          |                |                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |                      | 24 ~ 30                           | °C   | 30      |
|                          |                | Water heating set temp | Min.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | O                    | 15 ~ 34                           | °C   | 15      |
|                          |                |                        | Max.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                      | 35 ~ 75                           | °C   | 65      |
|                          | Room Cooling   | Air cooling set temp   | Min.<br>Max.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | O                    | 16 ~ 22                           | °C   | 16      |
|                          |                |                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |                      | 24 ~ 30                           | °C   | 30      |
|                          |                | Water cooling set temp | Min.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | O                    | 5 ~ 20                            | °C   | 10      |
|                          |                |                        | Max.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                      | 22 ~ 27                           | °C   | 24      |

| Menu hierarchy & Setting        |                     | Explanation | Detailed explanation                                                                                                                                                                                                                                                            | Available Setting options (range)                                                                                                                                                                                                                                                                                                                                                                              | Unit | Default      |
|---------------------------------|---------------------|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|--------------|
| AUTO MODE<br>Seasonal auto temp | Mode                |             | Definition if weather-dependency (Auto mode) is applied to heating and cooling or heating only.<br><br>Graphic setting of outdoor temperature ranges for heating and cooling in Auto mode.<br> | Heating only / Heating & Cooling                                                                                                                                                                                                                                                                                                                                                                               | -    | Heating only |
|                                 |                     | O1          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | O2          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | O3          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | O4          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 | Target temperatures | Circuit 1   |                                                                                                                                                                                                                                                                                 | Graphic setting of target temperatures in Heating/Cooling operation for Circuit 1 & 2.<br>- If setting 'Configuration/Control method = Air', then targets for Room air are defined here.<br>- If setting 'Configuration/Control method = Water or Water+Air', then targets for outlet or inlet temperature are expressed.<br> | ○    |              |
|                                 |                     | Circuit 2   |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | A1          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | A2          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | A3          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | A4          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | W1          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | W2          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | W3          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | W4          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | A1          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | A2          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | A3          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | A4          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | W1          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | W2          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | W3          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |
|                                 |                     | W4          |                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                |      |              |

| Menu hierarchy & Setting |                          |                              | Explanation                                                                                                                                                                                                                                                                                                            | Detailed explanation                           | Available Setting options (range) | Unit    | Default |
|--------------------------|--------------------------|------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------|-----------------------------------|---------|---------|
| DOMESTIC HOT WATER       | DHW set temp range       | Min.                         | Limitation of setting range (DHW temp. target that User can set)<br>The setting range is limited, if no boost heater is installed.                                                                                                                                                                                     | O                                              | 30 ~ 40                           | °C      | 40      |
|                          |                          | Max.                         |                                                                                                                                                                                                                                                                                                                        |                                                | 50 ~ 80                           | °C      | 65      |
|                          | DHW temperature settings | Compressor cycle limit temp. | This is the max. DHW temp. that that can be reached by using compressor cycle only (without using electrical boost heater). It also depends on effectiveness of heat transfer from heat pump to DHW tank (size of coil, sensor positioning).<br>Reducing the setting may lead to increased consumption of electricity. |                                                | 40 ~ 65                           | °C      | 65      |
|                          |                          | DHW hysteresis               | Temperature gap between DHW target temp. (by User) and DHW temperature when re-heating starts.<br><b>Example:</b><br>Target temp. = 48°C DHW hysteresis = 5 K<br>→ DHW heating starts at 43°C                                                                                                                          | 1 ~ 30                                         | K                                 | 5       |         |
|                          | Thermal disinfection 1   | Disinfection active          | Activation/Deactivation of anti-legionella operation.<br>Electric heater must be connected and activated to perform this function.                                                                                                                                                                                     | Not use / Use                                  | -                                 | Not use |         |
|                          |                          | Weekday                      | Weekday and time at which the anti-legionella function is executed.                                                                                                                                                                                                                                                    | Sun. / Mon. / Tue. / Wed. / Thu. / Fri. / Sat. | -                                 | Fri     |         |
|                          |                          | Start time                   |                                                                                                                                                                                                                                                                                                                        | 0 ~ 23                                         | hh:--                             | 23:00   |         |
|                          | Thermal disinfection 2   | Max. Temp.                   | Target temp. for thermal disinfection cycle.                                                                                                                                                                                                                                                                           | 60 ~ 80                                        | °C                                | 70      |         |
|                          |                          | Duration                     | Duration how long disinfection target temp. is kept.<br>After time has elapsed, target is reduced to normal setpoint.                                                                                                                                                                                                  | 5 ~ 60                                         | min                               | 10      |         |
|                          |                          | Forced end time              | After this time has elapsed, thermal disinfection will stop - even is disinfection temp. is not reached.                                                                                                                                                                                                               | 1 ~ 12                                         | hrs                               | 1       |         |

| Menu hierarchy & Setting |                                 | Explanation           | Detailed explanation                                                                                                                                                                         | Available Setting options (range)             | Unit | Default    |
|--------------------------|---------------------------------|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------|------|------------|
| DOMESTIC HOT WATER       | DHW heating duration            | Active time           | Duration how long DHW heating continues                                                                                                                                                      | 5 ~ 95                                        | min  | 30         |
|                          |                                 | Stop time             | Duration how long DHW heating is interrupted (if DHW target is not reached in one cycle)                                                                                                     | 0 ~ 600                                       | min  | 30         |
|                          |                                 | DHW heater usage      | - <b>Use:</b> DHW will be re-heated electrically if the heat pump cycle does not reach the target temp. within time setting.                                                                 | Use always / Use disinfection                 | -    | Use always |
|                          |                                 |                       | - <b>Use disinfection:</b> Electric re-heating is only used for anti-legionella operation and in case of emergency. If 'Use disinfection' is chosen, the DHW temp. setting range is limited! |                                               |      |            |
|                          | DHW electric re-heating         | DHW heater delay time | After time has elapsed, the DHW boost heater is released.                                                                                                                                    | 10 / 20 / 30 / 40 / 50 / 60 / 90 / 120 / 1440 | min  | 30         |
|                          |                                 | Enable re-circulation | Definition if DHW recirculation pump is connected or not. If it is used, a Schedule in the main menu becomes available to set the time frames for operating the pump.                        | Use / Not use                                 | -    | Not use    |
|                          |                                 | On                    | Definition of recirculation pump cycling pattern during release schedule. By default, the pump operates every twenty minutes for 10 minutes (only during the set Schedule!)                  | 5 ~ 60                                        | min  | 10         |
|                          |                                 | Off                   |                                                                                                                                                                                              | 5 ~ 60                                        | min  | 20         |
|                          | Solar collector operating range | Min.                  | Solar cycle will not start before collector has reached this temp.                                                                                                                           | 5 ~ 50                                        | °C   | 10         |
|                          |                                 | Max.                  | Solar cycle will not start if collector exceeds this temp.                                                                                                                                   | 60 ~ 200                                      | °C   | 135        |
| SOLAR THERMAL SYSTEM     | Solar tank temp. Limit          | Max.                  | Solar cycle will not start, if DHW tank has reached its maximum temp.                                                                                                                        | 20 ~ 90                                       | °C   | 80         |

| Menu hierarchy & Setting |                          | Explanation               | Detailed explanation                                                                                                                                                                                         | Available Setting options (range)                                                                                                                                                                                                                                                                                                                                                                                                               | Unit             | Default        |
|--------------------------|--------------------------|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|----------------|
| SOLAR THERMAL SYSTEM     | Solarthermal $\Delta T$  | Temp On                   | Delta temp. between Solar collector and DHW tank must be reached before solar pump starts.<br><b>Example:</b><br>Actual DHW temp. = 45 °C, Temp On = 8 K<br>→ Solar cycle start, if collector exceeds 53 °C  | O                                                                                                                                                                                                                                                                                                                                                                                                                                               | 3 ~ 40           | K<br>8         |
|                          |                          | Temp Off                  | Delta temp. between Solar collector and DHW tank must be undercut before solar cycle stops.<br><b>Example:</b><br>Actual DHW temp. = 45°C, Temp Off = 2K<br>→ Solar cycle stops, if collector undercuts 47°C |                                                                                                                                                                                                                                                                                                                                                                                                                                                 | 1 ~ 20           | K<br>2         |
|                          |                          | Renewable DHW heating     |                                                                                                                                                                                                              | The electrical DHW boost heater can be disabled, while solar cycle is in operation.                                                                                                                                                                                                                                                                                                                                                             | Enable / Disable | -<br>Enable    |
|                          |                          | Solar pump flush schedule |                                                                                                                                                                                                              | Frequent activation of solar pump can be activated/deactivated. This function is recommended only if there are random shadows (tree, chimney,...) covering the collector sensor. If solar cycle is out of operation, solar pump will start after this time has elapsed, in order to check the available solar temp. Duration should be as long as necessary, but as short as possible. If collector is cold, heat will be wasted "to the roof"! | On / Off         | -<br>Off       |
|                          | Solar circuit flushing   | Start Hour                | Within this time frame the Solar flushing function is enabled. Flushing is only reasonable during daytime.                                                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                 | 0 ~ 23           | hh:--<br>6:00  |
|                          |                          | Start Minute              |                                                                                                                                                                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                 | 0 ~ 59           | --:mm          |
|                          |                          | End Hour                  |                                                                                                                                                                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                 | 0 ~ 23           | hh:--<br>18:00 |
|                          |                          | End Minute                |                                                                                                                                                                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                 | 0 ~ 59           | --:mm          |
|                          | Solar pump flush setting | Oper. Time                | Duration how long the solar pump operates to flush the circuit                                                                                                                                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                 | 1 ~ 10           | -<br>1         |
|                          |                          | Oper. Cycle               | Duration until next flushing starts                                                                                                                                                                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                 | 30 ~ 120         | -<br>60        |
|                          | Solar pump test run      |                           | 'Start' will activate the solar pump for 1 hour. During this period, the pump will be turned on and off intermittently to purge air from the cycle.                                                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Start / Stop     | -<br>-         |

| Menu hierarchy & Setting |                        | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Detailed explanation | Available Setting options (range) | Unit | Default |
|--------------------------|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|-----------------------------------|------|---------|
| SERVICE                  | Pump test run          | 'Test run' will activate the Main pump for 1 hour. During this period, the pump will be turned on and off intermittently to purge air from the cycle. Based on setting 'Configuration/External pump', the External pump will be activated, too. The operation can be stopped by pushing the On/Off button on the Remote controller.                                                                                                                                                                                     | O                    | Test Run                          | -    | -       |
|                          | Frost Protection Temp. | By default, the frost protection is activated if any water temperature sensor measures a temperature below 4°C. The temperature might be reduced, if anti-freeze agent is added to the water circuit. However, this setting is only valid when the antifreeze short pin (CN_ANTL_SW) is removed and DIP switch SW1 - No.8 is turned on. Refer to detailed description in this manual.                                                                                                                                   | O                    | 4 / -1 / -6 / -11 / -16 / -21     | K    | -1      |
|                          | Actuator test          | Before actuator outputs can be tested, the 'Test mode' must be turned on. While it is enabled, normal functions will be suppressed. Make sure that all electric wiring and piping work is executed correctly before starting the Test mode!. Only professional users should use this functionality! It is highly recommended to test only one output at a time. Other than the functions 'Solar pump test run' and 'Pump test run', the actuators are turned on continuously until the setting is changed to Off again. | O                    | On / Off                          | -    | Off     |
|                          | Test mode              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                      |                                   |      |         |

| Menu hierarchy & Setting |               |              |                               | Explanation                                                                                                                                                                                                                                         | Detailed explanation | Available Setting options (range) | Unit | Default |
|--------------------------|---------------|--------------|-------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|-----------------------------------|------|---------|
| SERVICE                  | Actuator test | Pump test    | A1 Main pump                  | <p>In this Service menu, the actuators like pumps and valves can be activated to check for correct operation during commissioning.</p> <p><b>Remark :</b> A6(Mixing valve open) and A7(mixing valve close) cannot be turned on at the same time</p> |                      | On / Off                          | -    | -       |
|                          |               |              | A2 External pump              |                                                                                                                                                                                                                                                     |                      | On / Off                          | -    | -       |
|                          |               |              | A3 Mix pump                   |                                                                                                                                                                                                                                                     |                      | On / Off                          | -    | -       |
|                          |               |              | A4 Solar pump                 |                                                                                                                                                                                                                                                     |                      | On / Off                          | -    | -       |
|                          |               |              | A15 DHW Re-circulation pump   |                                                                                                                                                                                                                                                     |                      | On / Off                          | -    | -       |
|                          |               |              | A5 DHW 3-way-valve            |                                                                                                                                                                                                                                                     |                      | DHW / Space                       | -    | -       |
|                          |               |              | A6 Mixing valve open          |                                                                                                                                                                                                                                                     |                      | On / Off                          | -    | -       |
|                          | Valve test    |              | A7 Mixing valve close         |                                                                                                                                                                                                                                                     |                      | On / Off                          | -    | -       |
|                          |               |              | A12 Cooling 2-way-valve       |                                                                                                                                                                                                                                                     |                      | On / Off                          | -    | -       |
|                          |               |              | S9 Refrigerant gas            |                                                                                                                                                                                                                                                     |                      | -                                 | °C   | -       |
|                          |               |              | S10 Refrigerant liquid        |                                                                                                                                                                                                                                                     |                      | -                                 | °C   | -       |
|                          |               |              | S11 Entering water            |                                                                                                                                                                                                                                                     |                      | -                                 | °C   | -       |
|                          |               |              | S12 Leaving water             |                                                                                                                                                                                                                                                     |                      | -                                 | °C   | -       |
|                          | Monitoring    | Sensor value | S13 Backup heater outlet      |                                                                                                                                                                                                                                                     |                      | -                                 | °C   | -       |
|                          |               |              | S14 DHW tank                  |                                                                                                                                                                                                                                                     |                      | -                                 | °C   | -       |
|                          |               |              | S15 Solar collector           |                                                                                                                                                                                                                                                     |                      | -                                 | °C   | -       |
|                          |               |              | S16 Solar tank                |                                                                                                                                                                                                                                                     |                      | -                                 | °C   | -       |
|                          |               |              | S17 Water flow sensor         |                                                                                                                                                                                                                                                     |                      | -                                 | °C   | -       |
|                          |               |              | S18 Mixing circuit            |                                                                                                                                                                                                                                                     |                      | -                                 | °C   | -       |
|                          |               |              | S19 Water pressure            |                                                                                                                                                                                                                                                     |                      | -                                 | °C   | -       |
|                          |               |              | S21 Room temp. Direct circuit |                                                                                                                                                                                                                                                     |                      | -                                 | °C   | -       |
|                          |               |              | S22 Room temp. Mixing circuit |                                                                                                                                                                                                                                                     |                      | -                                 | °C   | -       |
|                          |               |              | S24 Wall-mounted air sensor   |                                                                                                                                                                                                                                                     |                      | -                                 | °C   | -       |
|                          |               |              | S25 Buffer tank sensor        |                                                                                                                                                                                                                                                     |                      | -                                 | °C   | -       |



| Menu hierarchy & Setting |              |                             | Explanation                                                                                                                                                                           | Detailed explanation | Available Setting options (range) | Unit | Default |
|--------------------------|--------------|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|-----------------------------------|------|---------|
| SERVICE                  | Input status | SG1                         | In this Service menu, the status of all physical inputs are listed up<br><b>Remark</b> : If the input signal is normal, "1" is displayed, while there is no signal, "0" is displayed. |                      | 0 / 1                             | -    | -       |
|                          |              | SG2                         |                                                                                                                                                                                       |                      | 0 / 1                             | -    | -       |
|                          |              | CN-EXT                      |                                                                                                                                                                                       |                      | 0 / 1                             | -    | -       |
|                          |              | Antifreeze shortkey         |                                                                                                                                                                                       |                      | 0 / 1                             | -    | -       |
|                          |              | Thermostat (Heating)        |                                                                                                                                                                                       |                      | 0 / 1                             | -    | -       |
|                          |              | Thermostat (Cooling)        |                                                                                                                                                                                       |                      | 0 / 1                             | -    | -       |
|                          |              | Thermostat (DHW)            |                                                                                                                                                                                       |                      | 0 / 1                             | -    | -       |
|                          | Monitoring   | A1 Main pump                | In this Service menu, the status of all physical outputs are listed up<br><b>Remark</b> : Displays "1" if a signal is being sent, and "0" if there is no signal.                      |                      | 0 / 1                             | -    | -       |
|                          |              | A2 External pump            |                                                                                                                                                                                       |                      | 0 / 1                             | -    | -       |
|                          |              | A3 Mix pump                 |                                                                                                                                                                                       |                      | 0 / 1                             | -    | -       |
|                          |              | A4 Solar pump               |                                                                                                                                                                                       |                      | 0 / 1                             | -    | -       |
|                          |              | A5 DHW 3-way-valve          |                                                                                                                                                                                       |                      | DHW / Space                       | -    | -       |
|                          |              | A6 Mixing valve (Open)      |                                                                                                                                                                                       |                      | 0 / 1                             | -    | -       |
|                          |              | A7 Mixing valve (Close)     |                                                                                                                                                                                       |                      | 0 / 1                             | -    | -       |
|                          |              | A12 Cooling 2-way-valve     |                                                                                                                                                                                       |                      | 0 / 1                             | -    | -       |
|                          |              | A15 DHW Re-circulation pump |                                                                                                                                                                                       |                      | 0 / 1                             | -    | -       |
|                          |              | A8 Backup heater (Step 1)   |                                                                                                                                                                                       |                      | 0 / 1                             | -    | -       |
|                          |              | A9 backup heater (Step 2)   |                                                                                                                                                                                       |                      | 0 / 1                             | -    | -       |
|                          |              | A10 DHW Boost heater        |                                                                                                                                                                                       |                      | 0 / 1                             | -    | -       |
|                          |              | A11 External boiler         |                                                                                                                                                                                       |                      | 0 / 1                             | -    | -       |

| Menu hierarchy & Setting |                | Explanation                | Detailed explanation                                                                                                                                                        | Available Setting options (range) | Unit | Default |
|--------------------------|----------------|----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------|------|---------|
| SERVICE                  | Runtimes       | Compressor (Total runtime) | The total runtimes are of main components re displayed.<br>The information can be used to identify cause of excessive energy consumption or abnormal cycling of compressor. | -                                 | h    | -       |
|                          |                | Compressor starts          |                                                                                                                                                                             | -                                 | -    | -       |
|                          |                | Compressor (Heat mode)     |                                                                                                                                                                             | -                                 | h    | -       |
|                          |                | Compressor (Cool mode)     |                                                                                                                                                                             | -                                 | h    | -       |
|                          |                | Compressor (DHW mode)      |                                                                                                                                                                             | -                                 | h    | -       |
|                          |                | Compressor (Defrosting)    |                                                                                                                                                                             | -                                 | h    | -       |
|                          |                | Backup heater (Step 1)     |                                                                                                                                                                             | -                                 | h    | -       |
|                          |                | Backup heater (Step 2)     |                                                                                                                                                                             | -                                 | h    | -       |
|                          |                | Boost heater               |                                                                                                                                                                             | -                                 | h    | -       |
|                          |                | Main pump                  |                                                                                                                                                                             | -                                 | h    | -       |
|                          |                | Solar pump                 |                                                                                                                                                                             | -                                 | h    | -       |
|                          | Runtimes reset | Comp. Reset                | In this menu, runtimes can be reset.                                                                                                                                        | Reset                             | -    | -       |
|                          |                | Backup heater Reset        |                                                                                                                                                                             | Reset                             | -    | -       |
|                          |                | Boost Heater Reset         |                                                                                                                                                                             | Reset                             | -    | -       |
|                          |                | Pump operation time        |                                                                                                                                                                             | Reset                             | -    | -       |
|                          |                | Solar pump Reset           |                                                                                                                                                                             | Reset                             | -    | -       |

| Menu hierarchy & Setting |                              | Explanation      | Detailed explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Available Setting options (range)                                                                                         | Unit     | Default       |
|--------------------------|------------------------------|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|----------|---------------|
| CONNECTIVITY             | Dry contact                  | Dry Contact Mode | <ul style="list-style-type: none"> <li>- Manual: Unit must be turned-on by Remote controller after release by Dry contact</li> <li>- Auto: Unit will automatically start (return to previous operation) after release by Dry contact</li> </ul>                                                                                                                                                                                                                                                                                                                                                       | Auto / Manual                                                                                                             | -        | Auto          |
|                          |                              | CN_CC            | <ul style="list-style-type: none"> <li>- D/C Automatic : Unit will recognize connected Dry contact after power-on</li> <li>- D/C Not Installed: Dry contact is not installed</li> <li>- D/C Installed: Dry contact is installed and unit always checks its state</li> </ul> <p>Additionally, check setting for 'Dry contact mode'!</p>                                                                                                                                                                                                                                                                | <ul style="list-style-type: none"> <li>- D/C Automatic</li> <li>- D/C Not Installed</li> <li>- D/C Installed</li> </ul>   | -        | D/C Automatic |
|                          | Central control address(HEX) |                  | Address setting if LG Central controller is connected                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | 00 ~ FF                                                                                                                   | hexadec. | 00            |
|                          | Modbus address(HEX)          |                  | <p>Address setting if heat pump is controlled via Modbus by 3rd-party controller</p> <p><b>Remark :</b> To use this function, switch No.1 of DIP switch SW 1 must be turned ON.</p>                                                                                                                                                                                                                                                                                                                                                                                                                   | 01 ~ FF                                                                                                                   | hexadec. | 21            |
|                          | CN_EXT                       |                  | <ul style="list-style-type: none"> <li>- Not use: CN_EXT is not used</li> <li>- Simple operation: <ul style="list-style-type: none"> <li>Open= Operation off</li> <li>Closed= Operation On</li> </ul> </li> <li>- Simple dry contact: <ul style="list-style-type: none"> <li>Open= Operation Off with dry contact lock</li> <li>Closed= lock released, operation on/off depends on setting 'Dry contact mode'</li> </ul> </li> <li>- Single emergency stop: <ul style="list-style-type: none"> <li>Open= Emergency stop with forced lock</li> <li>Closed= Forced lock released</li> </ul> </li> </ul> | <ul style="list-style-type: none"> <li>Not use / Simple Operation / Simple dry contact / Single emergency stop</li> </ul> | -        | Not use       |

| Menu hierarchy & Setting |                              | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | Detailed explanation | Available Setting options (range)      | Unit | Default |
|--------------------------|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------|----------------------------------------|------|---------|
| CONNECTIVITY             | 3rd party boiler             | Boiler can be activated either manually (by User setting) or automatically (below certain outdoor temp.)<br>- <b>Manual:</b> The Boiler is (de-)activated manually (by User setting) If the boiler is activated, the heat pump is switched off.<br>- <b>Biv-alternative:</b> Automatic switch-over between heat pump and boiler. Below Bivalent temperature, the heat pump is turned off.<br>- <b>Biv-parallel:</b> Automatic release of boiler. Below Bivalent temp., the heat pump is still in operation. The boiler is activated additionally, if the heat pump alone cannot meet the target temp. within reasonable time. | O                    | Manual / Biv-alternative/ Biv-parallel | -    | Manual  |
|                          |                              | Boiler will be activated, if outdoor temp. undercuts this value.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |                      |                                        |      |         |
|                          |                              | Boiler will be de-activated and heat pump re-activated, if outdoor temp. exceeds temp. setting plus hysteresis.<br><b>Example:</b> 'Temp.' = -7°C, 'Hysteresis' = 4K<br>→ Boiler is enabled at -7°C and disabled at -3°C outdoor temp.                                                                                                                                                                                                                                                                                                                                                                                        |                      |                                        |      |         |
|                          | Boiler 3Way Valve            | Setting 3 way valve direction when operating the boiler.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                      | DHW / Heating                          | -    | DHW     |
|                          | Boiler Control By Room Temp. | If the heat pump is active, the output TB_EXT BOILER is always off. While the boiler is enabled, there are two options:<br>- Not use: Output is continuously On.<br>- Use: Output TB_EXT BOILER is switched on/off based on Room temperature state.<br>- Remark : Disabled in Biv-parallel mode.                                                                                                                                                                                                                                                                                                                              |                      | Not use / Use                          | -    | Not use |
|                          |                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |                      |                                        |      |         |

| Menu hierarchy & Setting |                 | Explanation       | Detailed explanation                                                                                                                                                                                                                 | Available Setting options (range)   | Unit      | Default |
|--------------------------|-----------------|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|-----------|---------|
| CONNECTIVITY             | Meter Interface | Modbus address    | - Not use : Meter interface is not connected<br>- B0 : Meter interface is connected (address 1)<br>DIP SW_01M @ PENKTH000 = Off<br>- B1 : Meter interface is connected (address 2)<br>DIP SW_01M @ PENKTH000 = On                    | Not use / B0 / B1                   | -         | Not use |
|                          |                 |                   |                                                                                                                                                                                                                                      |                                     |           |         |
|                          |                 | Port 1: Pulse/kWh |                                                                                                                                                                                                                                      | 0.1 ~ 9999.9                        | pulse/kWh | 0000.0  |
|                          |                 | Port 2: Pulse/kWh |                                                                                                                                                                                                                                      | 0.1 ~ 9999.9                        | pulse/kWh | 0000.0  |
|                          |                 | Port 3: Pulse/kWh |                                                                                                                                                                                                                                      | 0.1 ~ 9999.9                        | pulse/kWh | 0000.0  |
|                          |                 | Port 4: Pulse/kWh |                                                                                                                                                                                                                                      | 0.1 ~ 9999.9                        | pulse/kWh | 0000.0  |
|                          | Energy state    | Signal type       | External devices such as Home Energy Management Systems can be used to influence the operation of the heat pump.<br>Either two 230V inputs are used to collect the status or Modbus is used (for instance when connected to LG ESS). | O<br>Not use / 230V inputs / Modbus | -         | Not use |

| Menu hierarchy & Setting |                         | Explanation                 | Detailed explanation                                                                    | Available Setting options (range) | Unit | Default |
|--------------------------|-------------------------|-----------------------------|-----------------------------------------------------------------------------------------|-----------------------------------|------|---------|
| CONNECTIVITY             | Energy state definition | Energy state 5              | Setting whether Energy state 5 is used or not.                                          | Not use / Use                     |      |         |
|                          |                         | Energy state 5 - Heat temp. | Definition how much Heating target temp. shall increase when Energy state 5 is applied. | 0 ~ 30                            | K    | 5       |
|                          |                         | Energy state 5 - Cool temp. | Definition how much Cooling target temp. shall decrease when Energy state 5 is applied. | 0 ~ -30                           | K    | -5      |
|                          |                         | Energy state 5 - DHW temp.  | Definition how much DHW target temp. shall increase when Energy state 5 is applied.     | 0 ~ 50                            | K    | 30      |
|                          |                         | Energy state 6              | Setting whether Energy state 6 is used or not.                                          | Not use / Use                     |      |         |
|                          |                         | Energy state 6 - Heat temp. | Definition how much Heating target temp. shall increase when Energy State 6 is applied. | 0 ~ 30                            | K    | 2       |
|                          |                         | Energy state 6 - Cool temp. | Definition how much Cooling target temp. shall decrease when Energy state 6 is applied. | 0 ~ -30                           | K    | -2      |
|                          |                         | Energy state 6 - DHW temp.  | Definition how much DHW target temp. shall increase when Energy state 6 is applied.     | 0 ~ 50                            | K    | 10      |
|                          |                         | Energy state 7              | Setting whether Energy state 7 is used or not.                                          | Not use / Use                     |      |         |
|                          |                         | Energy state 7 - Heat temp. | Definition how much Heating target temp. shall increase when Energy State 7 is applied. | 0 ~ 30                            | K    | -2      |
|                          |                         | Energy state 7 - Cool temp. | Definition how much Cooling target temp. shall decrease when Energy State 7 is applied. | 0 ~ -30                           | K    | 2       |
|                          |                         | Energy state 7 - DHW temp.  | Definition how much DHW target temp. shall increase when Energy State 7 is applied.     | 0 ~ 50                            | K    | 0       |

| Menu hierarchy & Setting |                           |                         | Explanation                                                                                                                                                                                                           | Detailed explanation                                                                    | Available Setting options (range)                | Unit          | Default     |         |   |    |
|--------------------------|---------------------------|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|--------------------------------------------------|---------------|-------------|---------|---|----|
| CONNECTIVITY             | Energy state              | Energy state definition | Energy state 8                                                                                                                                                                                                        | Setting whether Energy state 8 is used or not.                                          | O                                                | Not use / Use |             |         |   |    |
|                          |                           |                         | Energy state 8 - Heat temp.                                                                                                                                                                                           | Definition how much Heating target temp. shall increase when Energy State 8 is applied. |                                                  |               |             | 0 ~ 30  | K | -5 |
|                          |                           |                         | Energy state 8 - Cool temp.                                                                                                                                                                                           | Definition how much Cooling target temp. shall decrease when Energy State 8 is applied. |                                                  |               |             | 0 ~ -30 | K | 5  |
|                          |                           |                         | Energy state 8 - DHW temp.                                                                                                                                                                                            | Definition how much DHW target temp. shall increase when Energy State 8 is applied.     |                                                  |               |             | 0 ~ 50  | K | 0  |
|                          | Digital inputs assignment | State 3 (0:1)           | Definition of Energy state 3:<br>- 3 : Cooling/no effect, Heating/Target +2K, DHW/Target +5K<br>- 4 : Cooling/no effect, Heating/no effect, DHW/Target=80°C<br>- 5~8 : According setting "Energy state definition"    | O                                                                                       | 3 ~ 8                                            | -             | 3           |         |   |    |
|                          |                           | State 4 (1:1)           | Definition of Energy state 4:<br>- 3 : Cooling/no effect, Heating/Target +2K, DHW/Target +5K<br>- 4 : Cooling/no effect, Heating/no effect, DHW/Target = 80 °C<br>- 5~8 : According setting "Energy state definition" |                                                                                         |                                                  |               |             | 3 ~ 8   | - | 4  |
|                          | Thermostat control type   |                         | Setting what type of thermostat is connected                                                                                                                                                                          |                                                                                         | - Heat & Cool<br>- Heat & Cool/DHW<br>- DHW only | -             | Heat & Cool |         |   |    |

## Installer settings in detail

This chapter provides extended explanations for some of the settings.


### Configuration - Control method

#### Water

The Inverter cycle is controlled based on target water temperature and actual (inlet or outlet) water temperature.

It is possible to combine this control method with a third-party room air temperature thermostat!

Weather-dependent (Auto mode) or Fixed target (Heat/Cool mode) are possible.




#### Air

If this control method is chosen, LG room air temperature sensor(s) or LG remote controller must be placed inside reference room(s).

The Inverter cycle will be controlled directly by using room air temperature target and actual room temperature.


While heat transfer from heat pump cycle to water to air is subject to time, this control method may lead to overshooting of temperature and higher energy consumption. It is only feasible to use in case of simple installations with just a few rooms.



#### Air+Water

The Inverter cycle is controlled based on target water temperature and actual (inlet or outlet) water temperature. Additionally, LG room air temperature sensor is installed or the remote controller is placed in a reference room to operate as a room thermostat. Whenever the room temperature drops below room temperature setpoint, the heat pump cycle starts and targets the set water temperature.

Weather-dependent (Auto mode) or Fixed target (Heat/Cool mode) are possible.





## Configuration - Select room devices

In this menu, it is possible to flexibly define the devices used to control room air temperature. The possible options depend on setting 'Control method'. The devices must be placed in suitable reference rooms. Refer to chapter 'Accessories installation'.

If LG room sensors are used, the sensor controlling Circuit 1 (Direct circuit) must be connected to CN\_ROOM and the sensor controlling Circuit 2 (Mixing circuit) to CN\_ROOM2.

If remote controllers are used, the ports CN\_REMO\_A (Direct circuit) and CN\_REMO\_B (Mix circuit) must be used accordingly.

If third-party thermostats are used, the thermostat-input and/or a Dry contact can be used for connection to the heat pump.


### Example 1)

Configuration - Control method: Air+Water

Configuration - Select room devices - RMC linked to: Circuit1&2

Configuration - Select room devices - Circuit 1 - Room air sensor option: Remote controller

Configuration - Select room devices - Circuit 2 - Room air sensor option: Room Sensor



**Example 2)**

- RS3(A) is used to control both levels (upstairs/radiators & downstairs/underfloor heating) including Installer settings. This Remote controller is also used to sense the room temperature of the ground floor (Mixing circuit).

**Settings on RS3(A):**

Configuration - Control method: Air+Water

Configuration - Select room devices - RMC linked to: Circuit1&2


Configuration - Select room devices - Circuit 1 - Room air sensor option: Remote controller

Configuration - Select room devices - Circuit 2 - Room air sensor option: Remote controller

- RS3(B) is used to control only Circuit 1 (upstairs/radiators) and sense its room temperature.

**Settings on RS3(B):**

Configuration - Select room devices - RMC linked to: Circuit1




### Example 3)

Configuration - Control method: Water

Configuration - Select room devices - RMC linked to: Circuit1&2

Configuration - Select room devices - Circuit 1 - Digital input - CN-THMO

Configuration - Select room devices - Circuit 2 - Digital input - CN-CC



### NOTE

In this setup, Mode-change is only possible through Thermostat-inputs at Indoor unit (and by using the Remote controller).


The thermostat connected via Dry contact shall be used only for give thermo-on/off signal.

## Configuration - External Pump

This function can be set to control the external water pump. Three options are possible, related to the location of the pump.


### Heat & Cool & DHW

In case of long piping, the External pump is used to overcome high pressure losses or as secondary pump in combination with a parallel buffer tank. With this setting, the pump always operates in parallel to internal pump.




### Heat & Cool

In case of long piping, the External pump is used to overcome high pressure losses. The pump is installed downstream of DHW connection. With this setting, the pump operates in parallel to internal pump during space heating and cooling mode. While the DHW tank is charged, the External pump remains off.



### Circuit1

If Mixing circuit is configured, the External pump can be used to serve the direct circuit (Circuit1), while the Mix pump serves Circuit2. In this setting, the External pump operates according to thermo-on/off state of Circuit1.



## Configuration - Boiler output


This setting must be adjusted based on the system layout.

### Layout 1

Boiler output = Heat & DHW

DHW by heat pump activated (→ DIP switch SW2/2&3)

Both, heat pump and boiler can be used for space heating and DHW heating. If the Bivalent temperature is reached, the boiler takes over completely and the heat pump is turned off.




### Layout 2

Boiler output = Heating only

DHW by heat pump activated (→ DIP switch SW2/2&3)

The boiler is connected to the space heating circuit only. The heat pump is used for DHW heating even below Bivalent temperature.




**Layout 3**

Boiler output= Heating & DHW

DHW by heat pump deactivated (→ DIP switch SW2/2&3)


The boiler is connected to the space heating circuit and covers the DHW demand throughout the year. The heat pump is used for space heating above Bivalent temperature only.

**NOTE**

In any case, the boiler is not controlled actively. Only it is released and then must operate according its own controls. The External pump output should not be used for the secondary pump, because it will be deactivated, when the heat pump is not in operation!

## Configuration - Select outdoor air sensor

Setting defines if the pre-installed air sensor (mounted at grille of outdoor unit) or a dedicated outside sensor (wall-mounted / accessory) is used for weather-dependent operation (Auto mode). It is highly recommended to use wall-mounted sensor – especially when the outdoor unit is exposed to sunlight.



### NOTE

Even if wall-mounted sensor is used, the sensor at outdoor unit must NOT be dis-connected, as it is still used to control the refrigerant cycle!


To select 'Wall-mounted air sensor', a dedicated accessory (PHATS0) is required (available from 04/2024).

## Configuration - RMC master/slave

An additional Remote controller can be used to operate as Room unit with limited access.

Only User settings and monitoring functions are available on the Slave controller.


On the monitoring screen, the controller is indicated with "S". It is possible to use the Slave controller to sense the room temperature if needed.



## General - Water Flow Control

This setting defines how the integrated water circulation pump is controlled.  
Select the desired method to control the pump and set the target value if needed.

- **Pump Capacity:** The pump operates with the capacity set (10~100 %)
- **Fixed Flow Rate:** The water pump is automatically controlled to maintain the set flow rate.  
Individual settings for Heating, Cooling and DHW heating are possible.
- **Fixed  $\Delta T$ :** Set the target  $\Delta T$  (\* $\Delta T$  = temperature difference between inlet and outlet water temperature). The water pump is automatically controlled to maintain the set  $\Delta T$ .  
Individual settings for Heating, Cooling and DHW heating are possible.  
For radiators the  $\Delta T$  is typically ~10 K, for Fan coil units ~8 K and for Underfloor heating system ~5 K are common.
- **Optimal Flow Rate:** The water pump is automatically controlled at the optimum flow rate required according to current temperature settings.



Remark: In Cooling mode, Target  $\Delta T$  is fixed at 5 K.

---

## NOTE

The flow rate has a strong impact on the efficiency of the system and also may lead to errors (CH 14) and flow noise.

The settings should be adjusted only by professional users.

---



## General - Anti-freezing option

This setting defines the level of frost protection, when the Remote control is turned off.

| Setting | Detection                                    | Case                                                                                                    | Operation              |
|---------|----------------------------------------------|---------------------------------------------------------------------------------------------------------|------------------------|
| Type1   | Outside air temp.<br>+<br>Outlet water temp. | Outside temp. $< 0\text{ }^{\circ}\text{C}$<br>AND Outlet water temp. $\leq 20\text{ }^{\circ}\text{C}$ | Pump always ON         |
|         |                                              | Outside temp. $\geq 0\text{ }^{\circ}\text{C}$<br>AND Outlet water temp. $> 20\text{ }^{\circ}\text{C}$ | Pump always OFF        |
|         |                                              | Except for above two cases                                                                              | Pump intermittently ON |
| Type2   | Outside air temp.                            | Outside temp. $< 9\text{ }^{\circ}\text{C}$                                                             | Pump intermittently On |
|         |                                              | Outside temp. $\geq 9\text{ }^{\circ}\text{C}$                                                          | Pump always OFF        |



## CAUTION

If the setting is changed to ,Type2' there is an increased risk of freezing!


**General - Backup heater release temp.**

Depending on local climate conditions, it is necessary to change the temperature condition in which backup heater is released. The backup heater operates in 'Bivalent-parallel' to heat pump cycle. It means, below the set outside temperature is released, but it will only run if the target temperature is not reached by cycle.

**NOTE**

DIP switches SW2-6/7 defines if half or full capacity of electric heater is used to support the heating. If full capacity is enabled, the steps are released based on gap between target and actual temperature.

- 1)  $T_{OL} = -28\text{ }^{\circ}\text{C}$
- 2) Heating design temp. (Seasonal auto temp/Outdoor temp/O1)
- 3) General/Backup heater release temp
- 4) No heating temp. (Seasonal auto temp/Outdoor temp/O2)



|   |                                          |
|---|------------------------------------------|
| ① | Heat pump only                           |
| ② | Heat pump+ Backup heater support         |
| ③ | Backup heater only (Emergency operation) |

## General - Screed drying

This function is used to increase the temperature of a newly installed underfloor heating system. It prevents that the cement is heated too fast and breaks. After activation, the main screen displays „Screed drying“ and the step in progress at the bottom of the screen.

- Step: By default the program starts with Step1. If screed drying was interrupted, it is possible to commence from any other step.
- Max. temp.: Defines the peak temperature.
- Step 8 Holding: Defines the time how long the Max. temperature is kept.

|                       | Step |               |     |    |    |    |               |                 |    |    |    |
|-----------------------|------|---------------|-----|----|----|----|---------------|-----------------|----|----|----|
|                       | 1    | 2             | 3   | 4  | 5  | 6  | 7             | 8               | 9  | 10 | 11 |
| Outlet temp.<br>in °C | 25   | Max.<br>temp. | Off | 25 | 35 | 45 | Max.<br>temp. | Max.<br>temp.   | 45 | 35 | 25 |
| Duration in hours     | 72   | 96            | 72  | 24 | 24 | 24 | 24            | Holding<br>time | 72 | 72 | 72 |




## CAUTION

The set Max. temp. must align with the specification provided by manufacturer of the underfloor heating!

## NOTE

- If the upper limit setting value of the heating LW temperature is 55 °C or lower, it is set to 55 °C forcibly. If the lower limit setting value of the heating LW temperature is 25 °C or higher, it is set to 25 °C forcibly.
- During Screed drying operation, button input - except for installer functions - and temperature display is restricted.
- When the power is applied again after a power outage during product operation, the product operation state before power failure is remembered and the product is automatically operated.
- Screed drying operation stops when an error occurs. When error is cleared, screed drying program re-starts. (However, if the wired remote control is reset to the error occurrence state, it is compensated in the unit of one day)
- Upon releasing after an error, Screed drying operation may take up to 1 minute of waiting time after boot up. (The Screed drying operation status is judged as 1 minute cycle.)
- During Screed drying operation, Silent mode, DHW heating, Solarthermal heating is set to Off!
- During Screed drying operation, timers and reservations are not executed!
- After all steps are completed, set the function to 'Off'!




## General - Buffer tank hysteresis

If a big buffer tank is connected in parallel to the heat pump, a separate sensor can be connected to PCB-connector TB\_SENSOR/BUFFER sensing the temperature at the top of the tank or at its outlet pipe.

Consequently, the desired target water temperature (as set by User or defined by weather-dependent function) is compared to the buffer tank temperature.

Basically, it supports the same set temperature range and cycle operation as the regular water temperature control function. In addition, a dedicated hysteresis can be set - separate from existing air or water temperature control hysteresis.

The buffer tank hysteresis is 0 to 20 K (default 2 K), if the desired target temperature is set to 50 °C, Thermo-on temp. will be 48 °C and Thermo-off temp. will be 52 °C.



## NOTE

To use this function, a dedicated accessory (PHRSTAO) is required.

**Circuit 1(2) - Room heating - Air heating set temperature**

- This setting limits the air temperature range applied to Heating operation that the User can set manually in the Remote controller  
(Control method=Air or Air+Water; Mode=HEAT)

**Circuit 1(2) - Room heating - Water heating set temperature**

- This setting limits the water temperature range applied to Heating operation that the User can set manually in the Remote controller  
(Control method=Water; Mode=HEAT)

**Circuit 1(2) - Room cooling - Air cooling set temperature**

- This setting limits the air temperature range applied to Heating operation that the User can set manually in the Remote controller  
(Control method=Air or Air+Water; Mode=COOL)

**Circuit 1(2) - Room cooling - Water cooling set temperature**

- This setting limits the water temperature range applied to Cooling operation that the User can set manually in the Remote controller.  
(Control method=Water; Mode=COOL)

---



**NOTE**

- If underfloor system is used for cooling, it is very important to keep leaving water temperature higher than 16 °C. Otherwise, dew condensation can occur on the floor.
  - In case of humid environment, do not set leaving water temperature below 18 °C.
  - Do not use radiators for cooling! If cold water enters the radiators, dew will appear on the surface of the radiator.
  - If Fan coil units (FCU) are used, it is possible to cool the water down to 5 °C.
  - If FCU are used together with other types of emitters , the 2way-valve should be installed to block circuits not suitable for cold water.
-

## Auto mode - Seasonal auto temp.

If mode is set to Auto, the target temperature is adapted to outside air temperature.

This way of control is much more energy efficient than heating(cooling) mode with fixed target temperature. If 'Mode' is set to 'Heating & Cooling', it is possible to define outdoor temperatures at which the unit switch-over from Heating to Off to Cooling and vice versa.



| Setting | Description          | Control method         | Range                                  | Default   |           | Boundary                 |
|---------|----------------------|------------------------|----------------------------------------|-----------|-----------|--------------------------|
|         |                      |                        |                                        | Circuit 1 | Circuit 2 |                          |
| O1      | Heating design temp. | all                    | -25 ~ 35 °C                            | -10 °C    | -10 °C    | O1 ≤ O2 -1               |
| O2      | Heating limit temp.  |                        |                                        | 18 °C     | 18 °C     | O2 ≥ O1 +1<br>O2 ≤ O3 -5 |
| O3      | Enable cooling       |                        | 10 ~ 46 °C                             | 30 °C     | 30 °C     | O3 ≥ O2 +5<br>O3 ≤ O4 -1 |
| O4      | Cooling design temp. |                        |                                        | 40 °C     | 40 °C     | O4 ≥ O3 +1               |
| W1      | High temp. (Heating) | Water /<br>Water + Air | 15 <sup>1)</sup> ~ 75 <sup>2)</sup> °C | 50 °C     | 35 °C     | W1 ≥ W2                  |
| W2      | Low temp. (Heating)  |                        |                                        | 40 °C     | 28 °C     | W2 ≤ W1                  |
| W3      | High temp. (Cooling) |                        | 5 ~ 27 °C                              | 12 °C     | 18 °C     | W3 ≥ W4                  |
| W4      | Low temp. (Cooling)  |                        |                                        | 10 °C     | 16 °C     | W4 ≤ W3                  |
| A1      | High temp. (Heating) | Air                    | 16 ~ 30 °C                             | 21 °C     | 21 °C     | A1 ≥ A2                  |
| A2      | Low temp. (Heating)  |                        |                                        | 19 °C     | 19 °C     | A2 ≤ A1                  |
| A3      | High temp. (Cooling) |                        | 18 ~ 30 °C                             | 21 °C     | 21 °C     | A3 ≥ A4                  |
| A4      | Low temp. (Cooling)  |                        |                                        | 19 °C     | 19 °C     | A4 ≤ A3                  |

1) Without Backup heater, the lowest outlet water temp. is 20 °C.


2) If Control method is set to 'Outlet' water temperature control, the maximum setpoint in heating is 65 °C.

※ Range is limited by settings in menu 'Circuit 1(2) / Room cooling / Water cooling set temp.'  
In case of 'Inlet water control', the minimum setpoint is 5 degrees higher compared to 'Outlet water temp. control'.


# Domestic hot water - DHW temperature settings

The DHW target temperature is set in Main screen by User. 'DHW set temp range' will limit the setting range. The type and volume of the tank, as well as the consumption should be taken into account.

Case 1: 'DHW target temp.' set lower than 'Compressor cycle limit temp.'



Case 2: 'DHW target temp.' set higher than 'Compressor cycle limit temp.'



## NOTE

If 'DHW target temp.' is higher than 'Comp. cycle limit temp.' (Case 2), the Cycle limit temp. will be used as reference for 'DHW hysteresis'!

Set 'DHW target temp.' as low as possible (with respect to required comfort level) and 'Compressor cycle limit temp.' as high as possible (as long as no error appears).




## Domestic hot water - Thermal disinfection

This function can help to prevent legionella bacteria from growing. It is recommended to activate the function if the DHW is not consumed on a regular base.

In order to kill the bacteria, a temperature of 70 °C or higher is recommended. For this purpose it is necessary to install and activate an electric boost heater.

During Thermal disinfection, the target hot water temp. is increased for a certain period of time.




# Domestic hot water - DHW heating duration

## Domestic hot water - DHW electric re-heating

The following settings can be used to limit the duration of DHW heating and DHW boost heater:

- Domestic hot water - DHW heating duration - Active time:  
Maximum time how long DHW heating by heat pump cycle is activated, until operation mode returns to space heating
- Domestic hot water - DHW heating duration - Stop time:  
After DHW heating by heat pump cycle has stopped, it won't commence before 'Stop time' time has elapsed. The Boost heater might be used.
- Domestic hot water - DHW electric re-heating - DHW heater delay time:  
Time gap between start of DHW heating by cycle and release of DHW boost heater.



| Time | Event                                                                                                                                                                                                                                                                                                          |
|------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 7:30 | The User activates the DHW function in the Remote controller.<br>DHW heating starts by using the heat pump cycle, as thermo-on condition is reached.                                                                                                                                                           |
| 7:45 | The DHW boost heater is activated, even though the 'DHW boost heater delay time' has not yet ended. This is because the DHW temp. reached the 'Compressor cycle limit temp.' The compressor cycle turns off to prevent High-pressure error. The 'Active time' immediately ends and 'Stop time' counter starts. |
| 7:50 | The 'DHW heater delay time' (20 min) ends, but it has no effect, because the heater is already operating.                                                                                                                                                                                                      |
| 7:55 | After reaching the DHW set point, DHW heating stops.                                                                                                                                                                                                                                                           |
| 8:10 | The DHW temperature has dropped below set point again, but the DHW heating is not started due to 'Stop time' (30 min).                                                                                                                                                                                         |
| 8:15 | After end of 'Stop time', DHW heating commences using the heat pump cycle only, because the DHW temp. is lower than 'Compressor cycle limit temp.'                                                                                                                                                             |
| 8:35 | The DHW boost heater is enabled, after boost heater delay time. The heater starts, because DHW target temp. is not reached. The Compressor cycle remains active, because DHW temp. is still lower than 'Compressor cycle limit temp.'                                                                          |
| 8:45 | After end of 'Active time', the heat pump cycle stops. DHW heating commences using the Boost heater only.                                                                                                                                                                                                      |
| 8:50 | The DHW target temperature is reached. The heater stops.                                                                                                                                                                                                                                                       |
| 8:55 | The User turns off DHW heating in the Remote controller.                                                                                                                                                                                                                                                       |


## Domestic hot water - DHW re-circulation

In this menu, the recirculation pump can be activated and the pattern of operation is defined.

### NOTE

Operation times of the Recirculation pump should be limited to times when comfort is really needed. If the pump is released for long time, energy consumption may increase a lot due to heat dissipation into the building and need to re-heat the hot water tank!

### Example)



### Installer level

Setting - Domestic hot water - DHW re-circulation - Enable re-circulation = Use  
 Setting - Domestic hot water - DHW re-circulation - On = 10 min  
 Setting - Domestic hot water - DHW re-circulation - Off = 20 min

### NOTE

A schedule (accessible via Main screen) becomes available, after 'Enable recirculation' is set to 'Use'.

### User level

1. Schedule - DHW Recirculation - Usage = Use  
 Schedule - DHW Recirculation - Time = 06:00 ~ 07:00  
 Schedule - DHW Recirculation - Day = Everyday
2. Schedule - DHW Recirculation - Usage = Use  
 Schedule - DHW Recirculation - Time = 18:00 ~ 20:00  
 Schedule - DHW Recirculation - Day = Everyday

### NOTE


If you set the start time before the current time, the pump will be activated tomorrow at the set time.

**Example:** If you set times as above and it is 19:00 now, the pump will be activated tomorrow at 06:00 for the first time!

**Solarthermal system - Solar collector operating range**  
**Solarthermal system - Solar tank temp. limit**  
**Solarthermal system - Solathermal dT**

Basically, the Solar pump starts if the Collector temperature (TB\_SENSOR/SOLAR) is higher than the temperature at bottom part of the DHW tank (CN\_TH4/WATER TANK SENSOR(B)). By default, the pump starts when the collector is 8 degrees warmer and stops when it is only 2 degrees warmer. This is because some heat losses can be expected on the way from roof to the technical room.

Additionally, the pump is turned off, when either the collector or the tank reaches it's maximum temperature. The values can be adjusted based on local conditions.



- A) Solarthermal system - Solar collector operating range - Min  
B) Solarthermal system - Solar collector operating range - Max  
C) Solarthermal system - Solar tank temp limit - Max  
D) DHW target temperature (User setting)


| No | Event                                                                                                                                                                                                       |
|----|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1  | Solar pump starts, because Collector temp. is eight degrees warmer than the tank                                                                                                                            |
| 2  | Solar pump stops, because Collector temp. is only two degrees warmer.                                                                                                                                       |
| 3  | After cloudy period, the Collector temp. rises again. Solar pump starts, because Collector temp. is again eight degrees warmer than the tank.                                                               |
| 4  | The collector is still five degrees warmer, but the pump stops, because the tank has reached its maximum temperature of 80°C.                                                                               |
| 5  | In the evening, the tank temperature drops due to consumption.                                                                                                                                              |
| 6  | The heat pump re-heats the DHW tank up to its setpoint of 50°C, as the collector is not hot enough.                                                                                                         |
| 7  | The next morning, the Solar pump starts, because Collector temp. is eight degrees warmer than the tank.                                                                                                     |
| 8  | The collector has reached its maximum temperature of 135°C. The pump stops. The solar fluid inside of the collector evaporates and pushes the liquid into the pipeworks. The Solar system is at standstill. |

## Service - Pump test run

'Test run' will activate the Main pump for 1 hour. During this period, the pump will be turned on and off intermittently to purge air from the cycle.

Based on setting 'Configuration/External pump', the External pump will be activated, too.

The operation can be stopped by pushing the On/Off button on the Remote controller.



### NOTE

The settings for Dry contact should be disabled to use the Pump test run function.

Connectivity - Dry contact - CN-CC = D/C Not installed

Connectivity - CN\_EXT = Not use

After finishing the Test run, make sure to change back to previous settings.

## Service - Actuator test - Test mode

## Service - Actuator test - Pump test

## Service - Actuator test - Valve test

These functions allow direct activation and de-activation of individual pumps and valves to check correct wiring and hydronic connection.

### NOTE

The settings for Dry contact should be disabled to use the Actuator test function.

Connectivity - Dry contact - CN-CC = D/C Not installed

Connectivity - CN\_EXT = Not use

After finishing the Actuator test, make sure to change back to previous settings.

## Service - Frost protection temperature

A frost protection function prevents freeze up of water pipes. If any pipe sensor measures a temperature below 4 °C (Default), the water pump and backup heater are turned on.


Defrosting operation is blocked if the leaving water temperature drops below 4 °C (Default) and it won't start until a temperature of 15 °C (Default) is reached.

If anti-freeze (glycol) is added to the water, the permitted temperature level can be as low as -1 °C (lowered by 5 degrees) down to -21 °C (lowered by 25 degrees).

All related temperatures will be shifted in the same way. For example, if 'Frost Protection Temp.' is selected as -1 °C, all temperatures that are the basis for judging frost protection are shifted by 5 degrees, too.

Consequently, the frost protection will be cancelled at a water temperature of 10 °C instead of 15 °C.

Antifreeze short pin



### NOTE

Before change of setting is applied, the antifreeze short pin (CN\_ANTI\_SW) must be removed and DIP switch SW1 - No.8 must be on.

Frost protection must be tested with a refractometer on a frequent basis!

## Connectivity - Modbus address(HEX)

This function allows control of the heat pump by external devices.

### NOTE

To use this function DIP switch No.1 of SW1 must be set to ON and No.2 to ON.

### Modbus memory map

- Baud Rate : 9 600 bps
- Stop Bit : 1 stop bit
- Parity : None Parity

#### Coil Register (0x01)

| Register | Description                      | Value explanation                            |
|----------|----------------------------------|----------------------------------------------|
| 00001    | Enable/Disable (Heating/Cooling) | 0 : Operation OFF / 1 : Operation ON         |
| 00002    | Enable/Disable (DHW)             | 0 : Operation OFF / 1 : Operation ON         |
| 00003    | Silent Mode Set                  | 0 : Silent mode OFF / 1 : Silent mode ON     |
| 00004    | Trigger Disinfection operation   | 0 : Keep status / 1 : Operation start        |
| 00005    | Emergency Stop                   | 0 : Normal operation / 1 : Emergency stop    |
| 00006    | Trigger Emergency Operation      | 0 : Keep status / 1 : Operation Start        |
| 00007    | Active Power Limitation          | 0: Not used / 1: Limit power acc. Reg. 40025 |

**Discrete Register (0x02)**

| Register | Description                                              | Value explanation                                   |
|----------|----------------------------------------------------------|-----------------------------------------------------|
| 10001    | Water flow status                                        | 0 : Flow rate ok / 1 : Flow rate too low            |
| 10002    | Water Pump status                                        | 0 : Water Pump OFF / 1 : Water Pump ON              |
| 10003    | Ext. Water Pump status                                   | 0 : Water Pump OFF / 1 : Water Pump ON              |
| 10004    | Compressor status                                        | 0 : Compressor OFF / 1 : Compressor ON              |
| 10005    | Defrosting status                                        | 0 : Defrost OFF / 1 : Defrost ON                    |
| 10006    | DHW heating status<br>(DHW Thermal On/Off)               | 0 : DHW inactive / 1 : DHW active                   |
| 10007    | DHW Tank disinfection status                             | 0 : Disinfection inactive / 1 : Disinfection active |
| 10008    | Silent mode status                                       | 0 : Silent mode inactive / 1 : Silent mode active   |
| 10009    | Cooling status                                           | 0 : No cooling / 1 : Cooling operation              |
| 10010    | Solar pump status                                        | 0 : Solar pump OFF / 1 : Solar pump ON              |
| 10011    | Backup heater (Step 1) status                            | 0 : OFF / 1 : ON                                    |
| 10012    | Backup heater (Step 2) status                            | 0 : OFF / 1 : ON                                    |
| 10013    | DHW boost heater status                                  | 0 : OFF / 1 : ON                                    |
| 10014    | Error status                                             | 0 : no error / 1 : error state                      |
| 10015    | Emergency Operation Available<br>(Space heating/cooling) | 0 : Unavailable / 1 : Available                     |
| 10016    | Emergency Operation Available<br>(DHW)                   | 0 : Unavailable / 1 : Available                     |
| 10017    | Mix pump status                                          | 0 : Mix pump OFF / 1 : Mix pump ON                  |



Input Register (0x03)

| Register | Description                | Value explanation                                                                   |
|----------|----------------------------|-------------------------------------------------------------------------------------|
| 30001    | Error Code                 | Error Code                                                                          |
| 30002    | ODU operation Cycle        | 0 : Standby(OFF) / 1 : Cooling / 2 : Heating                                        |
| 30003    | Water inlet temp.          | [0.1 °C ×10]                                                                        |
| 30004    | Water outlet temp.         | [0.1 °C ×10]                                                                        |
| 30005    | Backup heater outlet temp. | [0.1 °C ×10]                                                                        |
| 30006    | DHW tank water temp.       | [0.1 °C ×10]                                                                        |
| 30007    | Solar collector temp.      | [0.1 °C ×10]                                                                        |
| 30008    | Room air temp. (Circuit 1) | [0.1 °C ×10]                                                                        |
| 30009    | Current Flow rate          | [0.1 LPM ×10]                                                                       |
| 30010    | Flow temp. (Circuit 2)     | [0.1 °C ×10]                                                                        |
| 30011    | Room air temp. (Circuit 2) | [0.1 °C ×10]                                                                        |
| 30012    | Energy State input         | 0 : Energy state 0; 1: Energy state 1....                                           |
| 30013    | Outdoor Air temp.          | [0.1 °C ×10]                                                                        |
| 30014    | Water pressure             | [0.1 bar ×10]                                                                       |
| 39998    | Produc Group               | 0x8X (0x80, 0x83, 0x88, 0x89)                                                       |
| 39999    | Product Info.              | Split : 0 / Monobloc : 3 / High Temp. : 4 /<br>Medium Temp. : 5 / System Boiler : 6 |

## Holding Register (0x04)

| Register | Description                                   | Value explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|----------|-----------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 40001    | Operation Mode                                | 0 : Cooling / 4 : Heating / 3 : Auto                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| 40002    | Control method (Circuit 1/2)                  | 0 : Water outlet temp. control<br>1 : Water inlet temp. control<br>2 : Room air control                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| 40003    | Target temp (Heating/Cooling)<br>Circuit 1    | [0.1 °C ×10]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 40004    | Room Air Temp. Circuit 1                      | [0.1 °C ×10]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 40005    | Shift value(Target) in auto mode<br>Circuit 1 | 1K                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 40006    | Target temp (Heating/Cooling)<br>Circuit 2    | [0.1 °C ×10]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 40007    | Room Air Temp. Circuit 2                      | [0.1 °C ×10]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 40008    | Shift value(Target) in auto mode<br>Circuit 2 | 1K                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| 40009    | DHW Target temp.                              | [0.1 °C ×10]                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 40010    | Energy state input                            | 0 : Not Use<br>1 : Forced off (equal to TB_SG1=close /<br>TB_SG2=open)<br>2 : Normal operation (equal to TB_SG1=open /<br>TB_SG2=open)<br>3 : On-recommendation (equal to<br>TB_SG1=open / TB_SG2=close)<br>4 : On-command (equal to TB_SG1=close /<br>TB_SG2=close)<br>5 : On-command step 2 (++ Energy<br>Consumption compared to Normal)<br>6 : On-recommendation Step 1 (+ Energy<br>Consumption compared to Normal)<br>7 : Energy Saving mode (- Energy Consumption<br>compared to Normal)<br>8 : Super Energy saving mode (– Energy<br>Consumption compared to Normal) |
| 40025    | Power Limitation value                        | 0.1 kW ~ 25.0 kW                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |

## Connectivity - CN\_EXT

Instead of external Dry contact, CN-EXT can be used to lock the heat pump by external signals.

| Setting               | Contact input | Operation *                           | Remark                                                                                                                                                                                                                                                                                                                   |
|-----------------------|---------------|---------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Not use               | -             | -                                     | CN_EXT is not used                                                                                                                                                                                                                                                                                                       |
| Simple operation      | Open          | Operation "Off"                       | In case of simple operation, operation on/off is possible as per either the remote controller or external input signal.                                                                                                                                                                                                  |
|                       | Close         | Operation "On"                        |                                                                                                                                                                                                                                                                                                                          |
| Simple Dry contact    | Open          | Operation "Off" with dry contact lock | In this case, "Operation on" is possible only with the Central controller.                                                                                                                                                                                                                                               |
|                       | Close         | Lock released                         | Release dry contact lock setting and "operation on" is possible depend on dry contact auto setting<br><br><b>Follows setting</b><br>'Dry contact mode':<br>Auto = Contact closed → Operation on<br>Manual = Contact closed → Keep on "operation off" state, but "operation on" is possible by remote controller manually |
| Single Emergency stop | Open          | Emergency stop with forced lock       | In this case, "Operation on" is impossible with any other controller.                                                                                                                                                                                                                                                    |
|                       | Close         | Forced lock released                  | Release forced lock and keep on "operation off" state, but "operation on" is possible by remote controller manually<br>Priority: Emergency stop lock > Central control lock > Dry contact lock                                                                                                                           |

\* This operation on / off means remote controller of / off for heating & cooling.

## Connectivity - 3rd party boiler

Either the heat pump or the boiler is used for space heating

**Three different modes are available to switch-over between heat pump and boiler:**


- Manual: The boiler is activated and de-activated by User setting 'Function/3rd party boiler'.
- Biv-alternative: The boiler output is activated based on outdoor temperature.  
The bivalent temperature (Default: -7 °C) and the switch-over hysteresis (Default: 4 K) can be adjusted by setting.
- Biv-parallel : Automatic release of boiler. Below bivalent temperature, the heat pump is still in operation. The boiler is activated additionally, if the heat pump alone cannot meet the target temperature within reasonable time. The bivalent temperature (Default: -7 °C) and the switch-over hysteresis (Default: 4 K) can be adjusted by setting. The operation limit temperature is according to the type of model.

### NOTE

Prices for electricity and fuel, as well as the maximum capacity of the heat pump must be considered when changing the Bivalent temp.

### Biv-alternative


- 1) Seasonal auto temp / Outdoor temp / O1
- 2) Connectivity / 3rd party boiler / Temp
- 3) Connectivity / 3rd party boiler / Hysteresis
- 4) Seasonal auto temp / Outdoor temp / O2



|   |                |
|---|----------------|
| ① | Heat pump only |
| ② | Boiler only    |

## Biv-parallel

- 1) Seasonal auto temp / Outdoor temp / O1
- 2) Connectivity / 3rd party boiler / Temp (BP)
- 3) Connectivity / 3rd party boiler / Hysteresis
- 4) Seasonal auto temp / Outdoor temp / O2
- 5) Operation Limit temp (AP)
  - HM\*\*\*HF U\*\*\* = -28°C
  - HM\*\*\*MRS U\*\*\* = -25°C



|   |                    |
|---|--------------------|
| ① | Heat pump only     |
| ② | Boiler only        |
| ③ | Heat pump + Boiler |

## Connectivity - Energy state

The sub menu 'Energy state' can be used to influence the heat pumps's operation based on availability of renewable energy - for instance from PV-panels.

**There are two options to make use of this logic:**

- Use Modbus: LG Energy Storage System (ESS) or another third-party device is connected by Modbus serial line.
- Use Digital inputs: A third-party controller (e.g. SmartHome controller or PV inverter) is connected through 230 V inputs ("SG-Ready contacts").

Using Modbus RTU allows to use eight different energy states, while Digital inputs provides four different energy states.

| Digital inputs (TB_SG) |       | Energy state | Mode    | Default      | Range   |
|------------------------|-------|--------------|---------|--------------|---------|
| ES1                    | ES2   |              |         |              |         |
| Close                  | Open  | 1            | Heating | Off          | Fixed   |
|                        |       |              | Cooling | Off          | Fixed   |
|                        |       |              | DHW     | Off          | Fixed   |
| Open                   | Open  | 2            | Heating | Normal       | Fixed   |
|                        |       |              | Cooling | Normal       | Fixed   |
|                        |       |              | DHW     | Normal       | Fixed   |
| Open                   | Close | 3            | Heating | 2            | Fixed   |
|                        |       |              | Cooling | +/- 0        | Fixed   |
|                        |       |              | DHW     | 5            | Fixed   |
| Close                  | Close | 4            | Heating | +/- 0        | Fixed   |
|                        |       |              | Cooling | +/- 0        | Fixed   |
|                        |       |              | DHW     | Target: 80°C | Fixed   |
| -                      | -     | 5            | Heating | 5            | 0 ~ +30 |
|                        |       |              | Cooling | -5           | -30 ~ 0 |
|                        |       |              | DHW     | 30           | 0 ~ +50 |
| -                      | -     | 6            | Heating | 2            | 0 ~ +30 |
|                        |       |              | Cooling | -2           | -30 ~ 0 |
|                        |       |              | DHW     | 10           | 0 ~ +50 |
| -                      | -     | 7            | Heating | -2           | -30 ~ 0 |
|                        |       |              | Cooling | 2            | 0 ~ +30 |
|                        |       |              | DHW     | +/- 0        | -50 ~ 0 |
| -                      | -     | 8            | Heating | -5           | -30 ~ 0 |
|                        |       |              | Cooling | 5            | 0 ~ +30 |
|                        |       |              | DHW     | +/- 0        | -50 ~ 0 |

### NOTE

Use setting 'Digital inputs assignment' to replace Energy state 3 and/or 4 with any of Energy states 3~8.

# COMMISSIONING

Before starting operation, pre-check points are described in this chapter. Some comments about maintenance and how to do troubleshooting are presented.

## Check List before Starting Operation

### CAUTION

Turn off the power before changing wiring or handling product.

| No | Category             | Item                   | Check Point                                                                                                                                                                                                                                                                                                                                                                                                                         |
|----|----------------------|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1  | Electricity          | Field wiring           | <ul style="list-style-type: none"> <li>• All switches having contacts for different poles should be wired tightly according to regional or national legislation.</li> <li>• Only qualified person can proceed wiring.</li> <li>• Wiring and local-supplied electric parts should be complied with European and regional regulations.</li> <li>• Wiring should be following the wiring diagram supplied with the product.</li> </ul> |
| 2  |                      | Protective devices     | <ul style="list-style-type: none"> <li>• Install ELB (earth leakage breaker) with 30 mA residual current.</li> <li>• ELB of Backup heater located inside of Hydro unit should be turned on before starting operation.</li> </ul>                                                                                                                                                                                                    |
| 3  |                      | Earth wiring           | <ul style="list-style-type: none"> <li>• Earth should be connected. Do not earth to gas or city water pipe, metallic section of a building, surge absorber, etc.</li> </ul>                                                                                                                                                                                                                                                         |
| 4  |                      | Power supply           | <ul style="list-style-type: none"> <li>• Use dedicated power line.</li> </ul>                                                                                                                                                                                                                                                                                                                                                       |
| 5  |                      | Terminal block wiring  | <ul style="list-style-type: none"> <li>• Connections on the terminal block (inside the control box of the unit) should be tightened.</li> </ul>                                                                                                                                                                                                                                                                                     |
| 6  | Water                | Charged water pressure | <ul style="list-style-type: none"> <li>• After water charging, the pressure gauge (in front of the unit) should indicate 2.0~2.5 bar. Do not exceed 3.0 bar.</li> </ul>                                                                                                                                                                                                                                                             |
| 7  |                      | Air purge              | <ul style="list-style-type: none"> <li>• During water charging, air should be vented through air purges until water is spilling out. After all air is released, check to close all air vents tightly. There should be no noise caused by circulating air bubbles in any part of the system.</li> </ul>                                                                                                                              |
| 8  |                      | Shut-off valve         | <ul style="list-style-type: none"> <li>• Two shut-off valves (Field supply) - located at the end of water inlet pipe and water outlet pipe of the unit) should be open.</li> </ul>                                                                                                                                                                                                                                                  |
| 9  |                      | By-pass valve          | <ul style="list-style-type: none"> <li>• A device that ensures the minimum flow rate (e.g. Bypass valve, hydronic separator, buffer tank) should be installed and adjusted to secure enough water flow rate. If water flow rate is low, flow switch error (CH14) can occur.</li> </ul>                                                                                                                                              |
| 10 | Product Installation | Hang to the wall       | <ul style="list-style-type: none"> <li>• As the unit is hung on the wall, vibration or noise can be heard if the unit is not fixed tightly.</li> <li>• If the unit is not fixed tightly, it can fall down during operation.</li> </ul>                                                                                                                                                                                              |
| 11 |                      | Parts inspection       | <ul style="list-style-type: none"> <li>• There should be no apparently damaged parts inside the unit.</li> </ul>                                                                                                                                                                                                                                                                                                                    |
| 12 |                      | Refrigerant leakage    | <ul style="list-style-type: none"> <li>• Refrigerant leakage is a serious danger.</li> <li>• If leakage found, contact qualified LG air conditioning installation person.</li> </ul>                                                                                                                                                                                                                                                |
| 13 |                      | Drainage treatment     | <ul style="list-style-type: none"> <li>• While cooling operation, condensed dew can drop down to the bottom of the unit. In this case, prepare drainage treatment (for example, vessel to contain condensed dew) to avoid water drop.</li> </ul>                                                                                                                                                                                    |

To assure best performance of **THERMAV**-, it is required to perform periodical check and maintenance. It is recommended to proceed following check list for once a year.

 **CAUTION**

Turn off the power before proceeding maintenance.

| No | Category    | Item                    | Check Point                                                                                                                                                                                                                |
|----|-------------|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1  | Water       | Water pressure          | <ul style="list-style-type: none"><li>• In normal state, the pressure gauge (in front of the unit) should indicate 2.0~2.5 bar.</li><li>• If the pressure is less than 0.3 bar, please recharge the water.</li></ul>       |
| 2  |             | Strainer (Water filter) | <ul style="list-style-type: none"><li>• Close the shut-off valves and disassemble strainer. Then wash the strainer to make it clean.</li><li>• While disassembling the strainer, be careful for water flood out.</li></ul> |
| 3  |             | Safety valve            | <ul style="list-style-type: none"><li>• Open the switch of the safety valve and check if water is flood out through the drain hose.</li><li>• After checking, close the safety valve.</li></ul>                            |
| 4  | Electricity | Terminal block wiring   | <ul style="list-style-type: none"><li>• Look and inspect if there is loosen or defected connection on the terminal block.</li></ul>                                                                                        |



## Starting Operation

### Check before Starting Operation

- Check to see whether there is any refrigerant leakage, and check whether the power or transmission cable is connected properly.
- Confirm that 500 V megger shows 2.0 MΩ or more between power supply terminal block and ground. Do not operate in the case of 2.0 MΩ or less.

### NOTE

Never carry out mega ohm check over terminal control board.


Otherwise the control board may break.

Immediately after mounting the unit or after leaving it turned off for an extended length of time, the resistance of the insulation between the power supply terminal board and the ground may decrease to approx. 2.0 MΩ as a result of refrigerant accumulation in the internal compressor.

If the insulation resistance is less than 2.0 MΩ, turn on the main power supply.

- When the power is applied for the first time, operate the product after preheating for 6 hours. To protect the unit by increasing the oil temperature of the compressor.

### Starting Operation flow chart



# Trouble shooting

If **THERMAV** operates not properly or it does not start operation, please check following list.

## ⚠ CAUTION


Turn off the power before proceeding troubleshooting.

|                                |                 | Critical trouble / Error                                                                                  | Heavy trouble                                                                                   | Slight trouble                                                | Option trouble                                                      |
|--------------------------------|-----------------|-----------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|---------------------------------------------------------------|---------------------------------------------------------------------|
| Description                    |                 | Problem which can stop system operation, and can be resumed only after certificated professional's check. | Compressor cycle trouble.<br>Emergency mode operation is performed by optional electric heater. | In most case, this trouble is concerned with sensor problems. | A problem is found for Option operation such as water tank heating. |
| Priority <sup>1)</sup>         |                 | 1                                                                                                         | 2                                                                                               | 3                                                             | 4                                                                   |
| Availability of Emergency mode | Heat pump cycle | X                                                                                                         | X                                                                                               | O                                                             | O <sup>2)</sup>                                                     |
|                                | Backup heater   | X                                                                                                         | O <sup>3)</sup>                                                                                 | O                                                             | O <sup>2)</sup>                                                     |
| Related error codes            |                 | 03,09,14,15,16,20,52,232                                                                                  | 02,05,06,22,23,24,26,27,29,32,34,35,40,41,43,44,45,46,48,53,57,60,61,62,114,115                 | 01,17,18,19,21,54,231                                         | 08,13                                                               |

- 1) If more than one trouble occurs ("Duplicated trouble"), the trouble with higher priority defines the consequences (whether Emergency operation is possible or not).
- 2) Operation possible without optional function that has trouble. For instance, when DHW sensor is broken (CH08), hot water heating is not available.
- 3) Heating operation only. Not possible to use Cooling function.

## NOTE

- Emergency mode operation is activated by pressing OK button on popup-window!
- After power reset, Emergency mode does NOT automatically resume!



## Troubleshooting for Problem while Operation

| Problem                                                                                                         | Reason                                                                                                 | Solution                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-----------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Heating or Cooling is not satisfactory.                                                                         | <ul style="list-style-type: none"> <li>Setting target temperature is not proper.</li> </ul>            | <ul style="list-style-type: none"> <li>Set target temperature correctly.</li> <li>Check if temperature is water-based or air-based. See 'Remote sensor active' and 'Temp. sensor selection'</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|                                                                                                                 | <ul style="list-style-type: none"> <li>Charged water is not enough.</li> </ul>                         | <ul style="list-style-type: none"> <li>Check pressure gauge and charge more water until pressure gauge is indication 2~2.5 Bar</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|                                                                                                                 | <ul style="list-style-type: none"> <li>Water flow rate is low.</li> </ul>                              | <ul style="list-style-type: none"> <li>Check if strainer gathers too much particles. If so, strainer should be cleaned.</li> <li>Check if pressure gauge indicates above 4 Bar</li> <li>Check if water pipe is getting closed due to stacked particles or lime.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Although electric power supply is OK (remote controller displays information), the unit does not start working. | <ul style="list-style-type: none"> <li>Water inlet temperature is too high.</li> </ul>                 | <ul style="list-style-type: none"> <li>If water inlet temperature is above 57 °C, the unit does not operated for the sake of system protection</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|                                                                                                                 | <ul style="list-style-type: none"> <li>Water inlet temperature is too low.</li> </ul>                  | <ul style="list-style-type: none"> <li>If water inlet temperature is below 5 °C in cooling operation, the unit does not operated for the sake of system protection. Wait while unit warms up the water inlet temperature.</li> <li>If water inlet temperature is below 15 °C in heating operation, the unit does not operated for the sake of system protection. Wait while unit warms up to 18 °C the water inlet temperature.</li> <li>If you are not using the back up heater accessory (HA**1M E1), increase the water temperature with the external heat source (heater, boiler). If the problem persists, contact your dealer.</li> <li>If you want to use the screed drying function, be sure to purchase and install back up hater accessories (HA**1M E1).</li> </ul> |
| Water pump noise.                                                                                               | <ul style="list-style-type: none"> <li>Air purging is not completely finished.</li> </ul>              | <ul style="list-style-type: none"> <li>Open the cap of air purge and charge more water until pressure gauge is indicating 2~2.5 Bar</li> <li>If water does not splash out when the tip(at the top of the hole) is pressed, then air purging is not completed yet. If well purged, the water will splash out like fountain.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|                                                                                                                 | <ul style="list-style-type: none"> <li>Water pressure is low.</li> </ul>                               | <ul style="list-style-type: none"> <li>Check if pressure gauge indicates above 0.3 Bar.</li> <li>Check if the expansion tank and pressure gauge operates well.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Water is flood out through drain hose.                                                                          | <ul style="list-style-type: none"> <li>Too much water is charged.</li> </ul>                           | <ul style="list-style-type: none"> <li>Flood out water by opening the switch of the safety valve until pressure gauge is indicating 2~2.5 Bar.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|                                                                                                                 | <ul style="list-style-type: none"> <li>Expansion tank is damaged.</li> </ul>                           | <ul style="list-style-type: none"> <li>Replace the expansion tank.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| DHW is not hot.                                                                                                 | <ul style="list-style-type: none"> <li>Thermal protector of water tank heater is activated.</li> </ul> | <ul style="list-style-type: none"> <li>Open the side panel of the DHW tank and push the reset button of the thermal protector. (for more detail information, please refer to installation manual of DHW tank.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|                                                                                                                 | <ul style="list-style-type: none"> <li>DHW Heating is disabled.</li> </ul>                             | <ul style="list-style-type: none"> <li>Select DHW Heating Operation and identify if icon is displayed on the remote controller.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |

## Troubleshooting for Error Code

| Error code | Title                                                                                                             | Cause of error                                                                                                                                                                                                                                                                                          | Check point                                                                                                                                                                                                                                                                                                                                                                                                |
|------------|-------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1          | Room air temp. sensor is broken                                                                                   | <ul style="list-style-type: none"> <li>• Incorrect connection between sensor and PCB</li> <li>• PCB fault</li> <li>• Sensor fault</li> </ul>                                                                                                                                                            | <ul style="list-style-type: none"> <li>• Resistance*: 10 kΩ at 25°C (unplugged)</li> <li>• Voltage: 2.5 VDC at 25°C (plugged)</li> <li>• Resistance*: 5 kΩ at 25°C (unplugged)</li> <li>• Voltage: 2.5 VDC at 25°C (plugged)</li> </ul>                                                                                                                                                                    |
| 2          | Refrigerant gas temperature sensor broken                                                                         |                                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                                                                                                                                                                                                            |
| 3          | Communication error (Indoor-PCB ↔ Remote Control)                                                                 | <ul style="list-style-type: none"> <li>• Communication line is broken</li> <li>• RMC is broken or has wrong software</li> <li>• IDU-PCB is abnormal</li> </ul>                                                                                                                                          | <ul style="list-style-type: none"> <li>• Check condition and polarity of wire between Remote controller and Indoor-PCB</li> </ul>                                                                                                                                                                                                                                                                          |
| 5          | Outdoor unit communication error judging from Indoor PCB with AC* communication method (Outdoor-PCB ↔ Indoor-PCB) | <ul style="list-style-type: none"> <li>• Communication line between outdoor and indoor unit is broken</li> <li>• Outdoor-PCB is damaged</li> <li>• Software setup is not compatible</li> <li>• Communication method is mismatching. (Flat method in outdoor unit ↔ AC method in indoor unit)</li> </ul> | <ul style="list-style-type: none"> <li>• Check condition and polarity of wire between Outdoor- and Indoor-PCB</li> <li>• Check internal wiring between terminal blocks and PCB</li> <li>• Check software versions of Outdoor- and Indoor-PCB</li> <li>• Check communication method matching-indoor &amp; outdoor unit. If outdoor unit uses Flat method, turn on the DIP S/W 1-3 in indoor-PCB.</li> </ul> |
| 6          | Refrigerant liquid temperature sensor broken                                                                      | <ul style="list-style-type: none"> <li>• Incorrect connection between sensor and PCB</li> <li>• PCB fault</li> <li>• Sensor fault</li> </ul>                                                                                                                                                            | <ul style="list-style-type: none"> <li>• Resistance*: 5 kΩ at 25°C (unplugged)</li> <li>• Voltage: 2.5 VDC at 25°C (plugged)</li> </ul>                                                                                                                                                                                                                                                                    |
| 8          | DHW tank sensor broken                                                                                            |                                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                                                                                                                                                                                                            |
| 9          | EEPROM error                                                                                                      | <ul style="list-style-type: none"> <li>• Electrical or mechanical damage of EEPROM (Indoor-PCB)</li> </ul>                                                                                                                                                                                              | <ul style="list-style-type: none"> <li>• Request support from LG</li> </ul>                                                                                                                                                                                                                                                                                                                                |
| 10         | BLDC water pump lock                                                                                              | <ul style="list-style-type: none"> <li>• Trouble with BLDC-type water pump</li> </ul>                                                                                                                                                                                                                   | <ul style="list-style-type: none"> <li>• BLDC water pump defect</li> <li>• Wrong connection or damage of driver cable</li> </ul>                                                                                                                                                                                                                                                                           |
| 11         | Correspondence error (Outdoor-PCB ↔ Inverter-PCB)                                                                 | <ul style="list-style-type: none"> <li>• Communication line between outdoor-PCB and Inverter-PCB is broken</li> <li>• Inverter-PCB is damaged</li> </ul>                                                                                                                                                | <ul style="list-style-type: none"> <li>• Loose connector or wiring between internal PCBs in outdoor unit</li> </ul>                                                                                                                                                                                                                                                                                        |
| 13         | Solarthermal sensor is broken                                                                                     | <ul style="list-style-type: none"> <li>• Incorrect connection between sensor and PCB</li> <li>• PCB fault</li> <li>• Sensor fault</li> </ul>                                                                                                                                                            | <ul style="list-style-type: none"> <li>• Resistance*: 5 kΩ at 25°C (unplugged)</li> <li>• Voltage: 2.5 VDC at 25°C (plugged)</li> </ul>                                                                                                                                                                                                                                                                    |

\* Flat method is default in HM1\*\*HF\* & HN16\*\*HC Model.

But HN16\*\*HC model can change the communication method for communication compatibility with previous models

| Error code | Title                                            | Cause of error                                                                                                                                                                                                                | Check point                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------------|--------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 14         | Flows Switch/Flow sensor error                   | <ul style="list-style-type: none"> <li>Flow rate <math>\leq</math> Minimum flow for at least 15 seconds while water pump is in operation.</li> <li>Minimum flow rate :<br/>(7,9 kW) 5 LPM<br/>(12,14,16 kW) 10 LPM</li> </ul> | <ul style="list-style-type: none"> <li>Check the actual flow rate in the remote controller (Monitoring screen)</li> <li>Make sure there is no water leakage / low pressure</li> <li>Make sure the strainer or water pipe is not clogged and valves are open.</li> <li>Make sure all air is released from heating circuit (!)</li> <li>Check the condition of internal water circulation pump</li> <li>Check installation of external pump (if needed)</li> <li>Check the flow sensor itself</li> </ul> |
| 15         | Water pipe abnormal overheat                     | <ul style="list-style-type: none"> <li>Abnormal operation of Backup heater</li> <li>Leaving water temperature <math>&gt; 75^{\circ}\text{C}</math></li> </ul>                                                                 | <ul style="list-style-type: none"> <li>External heat source not de-coupled from heat pump</li> <li>Problem with Backup heater</li> </ul>                                                                                                                                                                                                                                                                                                                                                               |
| 16         | AWHP temperature sensor at once error            | <ul style="list-style-type: none"> <li>More than one sensor shows invalid data</li> </ul>                                                                                                                                     | <ul style="list-style-type: none"> <li>Sensors mixed up or multiple damages</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 17         | PHEX inlet temp. sensor Error                    | <ul style="list-style-type: none"> <li>Incorrect connection between sensor and PCB</li> <li>PCB fault</li> <li>Sensor fault</li> </ul>                                                                                        | <ul style="list-style-type: none"> <li>Resistance*: 5 k<math>\Omega</math> at <math>25^{\circ}\text{C}</math> (unplugged)</li> <li>Voltage: 2.5 VDC at <math>25^{\circ}\text{C}</math> (plugged)</li> </ul>                                                                                                                                                                                                                                                                                            |
| 18         | PHEX outlet temp. sensor Error                   |                                                                                                                                                                                                                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| 19         | Unit (Electric heater) outlet temp. sensor Error |                                                                                                                                                                                                                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| 20         | Backup heater/Thermal fuse                       | <ul style="list-style-type: none"> <li>Abnormal overheat (<math>\geq 80^{\circ}\text{C}</math>) of internal Backup heater</li> </ul>                                                                                          | <ul style="list-style-type: none"> <li>Mechanical fault at thermal fuse</li> <li>Wire damaged</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                               |
| 21         | DC Peak (IPM Fault)                              | <ul style="list-style-type: none"> <li>Instant over current</li> <li>Over Rated current</li> <li>Poor insulation of IPM</li> </ul>                                                                                            | <ul style="list-style-type: none"> <li>An instant over-current in the U,V,W phase <ul style="list-style-type: none"> <li>- Comp lock</li> <li>- Abnormal connection of U,V,W</li> </ul> </li> <li>Over load condition <ul style="list-style-type: none"> <li>- Overcharging of refrigerant</li> <li>- Pipe length/diameter</li> <li>- Outdoor fan locked</li> </ul> </li> <li>Poor insulation of compressor</li> </ul>                                                                                 |

| Error code | Title                                     | Cause of error                                                                                                                                                                                                                                                                         | Check point                                                                                                                                                                                                                                                                                                                                           |
|------------|-------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 22         | CT 2 (Max CT)                             | <ul style="list-style-type: none"> <li>• Input over-current</li> </ul>                                                                                                                                                                                                                 | <ul style="list-style-type: none"> <li>• Malfunction of compressor</li> <li>• Blocking of pipe</li> <li>• Low voltage input</li> <li>• Refrigerant, Pipe length, Blockage...</li> </ul>                                                                                                                                                               |
| 23         | DC Link Voltage is low or high            | <ul style="list-style-type: none"> <li>• DC Link Voltage is above 420 V DC</li> <li>• DC Link Voltage is below 140 V DC</li> </ul>                                                                                                                                                     | <ul style="list-style-type: none"> <li>• Check CN_(L), CN_(N) Connection</li> <li>• Check Input Voltage</li> <li>• Check PCB DC Link voltage sensor parts</li> </ul>                                                                                                                                                                                  |
| 24         | High Pressure Switch Perception Error     | <ul style="list-style-type: none"> <li>• High pressure is above 34~36 kgf/cm<sup>2</sup></li> <li>• Pressure switch is self-defective</li> </ul>                                                                                                                                       | <ul style="list-style-type: none"> <li>• Check the high pressure</li> <li>• Check the connection of harness</li> </ul>                                                                                                                                                                                                                                |
| 26         | DC Compressor positioning                 | <ul style="list-style-type: none"> <li>• Compressor starting fail error</li> </ul>                                                                                                                                                                                                     | <ul style="list-style-type: none"> <li>• Check the connection of comp wire "U,V,W"</li> <li>• Malfunction of compressor</li> <li>• Check the component of "IPM", detection parts.</li> </ul>                                                                                                                                                          |
| 27         | AC input instant over-current             | <ul style="list-style-type: none"> <li>• PCB(Inverter) input current is over 100 A(peak) for 2 us</li> </ul>                                                                                                                                                                           | <ul style="list-style-type: none"> <li>• Overload operation (Pipe clogging/Covering/EEV defect/Ref. overcharge)</li> <li>• Compressor damage (Insulation damage/Motor damage)</li> <li>• Input voltage abnormal (L,N)</li> <li>• Powerline assemble condition abnormal</li> <li>• ODU-PCB (Assembly 1) damage (input current sensing part)</li> </ul> |
| 29         | Inverter compressor over-current          | <ul style="list-style-type: none"> <li>• HM**1HF.UB60 INV phase current <math>\geq 33</math>A</li> <li>• HM**3HF*.UB60 INV phase current <math>\geq 31</math>A</li> </ul>                                                                                                              | <ul style="list-style-type: none"> <li>• Overload operation (Pipe clogging/Covering/EEV defect/Ref. overcharge)</li> <li>• Compressor damage (Insulation damage/Motor damage)</li> <li>• Input voltage low</li> <li>• ODU-PCB (Assembly 1) damage</li> </ul>                                                                                          |
| 32         | Temperature at discharge-pipe is too high | <ul style="list-style-type: none"> <li>• Overload operation (Outdoor fan constraint, screened, blocked)</li> <li>• Refrigerant leakage or insufficient charge</li> <li>• INV Comp. discharge sensor failure</li> <li>• LEV connector displaced/poor</li> <li>• LEV assembly</li> </ul> | <ul style="list-style-type: none"> <li>• Check outdoor fan constraint/ screened/ flow structure</li> <li>• Check refrigerant leakage</li> <li>• Check if the sensor is normal</li> <li>• Check the status of EEV assembly</li> </ul>                                                                                                                  |

| Error code | Title                                               | Cause of error                                                                                                          | Check point                                                                                                                                                                                                                                                                                                                         |
|------------|-----------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 35         | Low Pressure error                                  | <ul style="list-style-type: none"> <li>Excessive decrease of low pressure</li> </ul>                                    | <ul style="list-style-type: none"> <li>Defective low pressure sensor</li> <li>Defective fan (motor)</li> <li>Refrigerant shortage/leakage</li> <li>Deformation of refrigerant pipe</li> <li>Defective EEV</li> <li>Outdoor-HEX blocked</li> <li>SVC valve clogging</li> <li>Defective PCB</li> <li>Defective Pipe sensor</li> </ul> |
| 41         | Problem in discharge-pipe temperature sensor        | <ul style="list-style-type: none"> <li>Open / Short</li> <li>Soldered poorly</li> <li>Internal circuit error</li> </ul> | <ul style="list-style-type: none"> <li>Bad connection of thermistor connector</li> <li>Defect of thermistor connector (Open/Short)</li> <li>Defect of outdoor PCB(Inverter)</li> </ul>                                                                                                                                              |
| 42         | (Low-)pressure sensor (Open/Short)                  | <ul style="list-style-type: none"> <li>Abnormal value of sensor(Open/Short)</li> </ul>                                  | <ul style="list-style-type: none"> <li>Bad connection of connector PCB</li> <li>Bad connection Low pressure connector</li> <li>Defect of Low pressure connector (Open/Short)</li> <li>Defect of connector PCB (Open/Short)</li> <li>Defect of PCB</li> </ul>                                                                        |
| 43         | (High-)pressure sensor (Open/Short)                 | <ul style="list-style-type: none"> <li>Abnormal value of sensor (Open/Short)</li> </ul>                                 | <ul style="list-style-type: none"> <li>Bad connection of connector PCB</li> <li>Bad connection high pressure connector</li> <li>Defect of high pressure connector (Open/Short)</li> <li>Defect of connector PCB(Inverter) (Open/Short)</li> <li>Defect of PCB</li> </ul>                                                            |
| 44         | Problem in AIR temperature sensor                   | <ul style="list-style-type: none"> <li>Open / Short</li> <li>Soldered poorly</li> <li>Internal circuit error</li> </ul> | <ul style="list-style-type: none"> <li>Bad connection of thermistor connector</li> <li>Defect of thermistor connector (Open/Short)</li> <li>Defect of outdoor PCB</li> </ul>                                                                                                                                                        |
| 45         | Problem in condenser-middle pipe temperature sensor | <ul style="list-style-type: none"> <li>Open / Short</li> <li>Soldered poorly</li> <li>Internal circuit error</li> </ul> | <ul style="list-style-type: none"> <li>Bad connection of thermistor connector</li> <li>Defect of thermistor connector (Open/Short)</li> <li>Defect of outdoor PCB</li> </ul>                                                                                                                                                        |
| 46         | Problem in suction pipe temperature sensor          | <ul style="list-style-type: none"> <li>Open / Short</li> <li>Soldered poorly</li> <li>Internal circuit error</li> </ul> | <ul style="list-style-type: none"> <li>Bad connection of thermistor connector</li> <li>Defect of thermistor connector (Open/Short)</li> <li>Defect of outdoor PCB</li> </ul>                                                                                                                                                        |

| Error code | Title                                                                                | Cause of error                                                                                                                                                                                                                                                            | Check point                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------------|--------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 48         | Problem in condenser out pipe temperature sensor                                     | <ul style="list-style-type: none"> <li>• Open / Short</li> <li>• Soldered poorly</li> <li>• Internal circuit error</li> </ul>                                                                                                                                             | <ul style="list-style-type: none"> <li>• Bad connection of thermistor connector</li> <li>• Defect of thermistor connector (Open/Short)</li> <li>• Defect of outdoor PCB</li> </ul>                                                                                                                                                                                                                                                     |
| 52         | Correspondence Error (Inverter-PCB ↔ Outdoor-PCB)                                    | <ul style="list-style-type: none"> <li>• Communication line between Outdoor-PCB and Inverter-PCB is broken</li> <li>• Inverter-PCB is damaged</li> </ul>                                                                                                                  | <ul style="list-style-type: none"> <li>• Generation of noise source interfering with communication</li> <li>• Checking the communication state between Outdoor-PCB and Inverter-PCB</li> </ul>                                                                                                                                                                                                                                         |
| 53         | Indoor unit Communication Error judging from outdoor PCB. (Outdoor-PCB ↔ Indoor-PCB) | <ul style="list-style-type: none"> <li>• Communication line between Outdoor-PCB and Indoor-PCB is broken</li> <li>• Indoor-PCB is damaged</li> <li>• Software setup is not compatible</li> </ul>                                                                          | <ul style="list-style-type: none"> <li>• Check condition and polarity of wire between Outdoor- and Indoor-PCB</li> <li>• Check internal wiring between terminal blocks and PCB</li> <li>• Check software versions of Outdoor- and Indoor-PCB</li> </ul>                                                                                                                                                                                |
| 54         | Phase sequence incorrect                                                             | <ul style="list-style-type: none"> <li>• Prevention of phase unbalance and prevention of reverse rotation of constant-rate compressor</li> </ul>                                                                                                                          | <ul style="list-style-type: none"> <li>• Main power wiring fault</li> </ul>                                                                                                                                                                                                                                                                                                                                                            |
| 60         | EEPROM Checksum mismatched                                                           | <ul style="list-style-type: none"> <li>• EEPROM Access error and Check SUM error</li> </ul>                                                                                                                                                                               | <ul style="list-style-type: none"> <li>• EEPROM contact defect/wrong insertion</li> <li>• Different EEPROM Version</li> <li>• ODU Inverter &amp; Main PCB (Assembly 1) damage</li> </ul>                                                                                                                                                                                                                                               |
| 61         | Temperature at condenser-pipe is too high                                            | <ul style="list-style-type: none"> <li>• Overload operation (Outdoor fan constraint, screened, blocked)</li> <li>• Unit heat exchanger contaminated</li> <li>• EEV connector displaced / poor EEV assembly</li> <li>• Poor Cond. Pipe sensor assembly / burned</li> </ul> | <ul style="list-style-type: none"> <li>• Check outdoor fan constraint / screened / flow structure</li> <li>• Check if refrigerant overcharged</li> <li>• Check the status of EEV assembly</li> <li>• Check the status of sensor assembly / burn</li> </ul>                                                                                                                                                                             |
| 62         | Temperature at heatsink is too high                                                  | <ul style="list-style-type: none"> <li>• Heat sink sensor detected high temp.(85 °C)</li> </ul>                                                                                                                                                                           | <ul style="list-style-type: none"> <li>• HM**1HF.UB60 : EBR39538401</li> <li>• HM**3HF*.UB60 : EBR89145606</li> <li>- Check the soldered condition in the T1, T2 Pin of IGBTM</li> <li>- Check the heat sink sensor : 5kΩ ±5% / at 25 (Unplugged)</li> <li>- Check the screw torque of IGBTM</li> <li>- Check the spreadable condition of thermal grease on IGBTM</li> <li>- Check the pipe refrigerant cooling performance</li> </ul> |



| Error code | Title                                           | Cause of error                                                                                                                                                                    | Check point                                                                                                                                                                                                                                     |
|------------|-------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 65         | Problem in heatsink temperature sensor          | <ul style="list-style-type: none"> <li>Abnormal value of sensor(Open/Short)</li> </ul>                                                                                            | <ul style="list-style-type: none"> <li>Check if there is defect of thermistor connector (Open/Short)</li> <li>Check defect of outdoor PCB</li> </ul>                                                                                            |
| 67         | ODU BLDC fan lock                               | <ul style="list-style-type: none"> <li>Fan rotation speed &lt; 10 rpm for 5 seconds during start-up operation or &lt; 40 rpm in normal operation</li> </ul>                       | <ul style="list-style-type: none"> <li>Fan motor damage.</li> <li>Assembly condition abnormal.</li> <li>Jammed fan by surroundings.</li> </ul>                                                                                                  |
| 88         | Inverter PCBA PFC EEPROM Error                  |                                                                                                                                                                                   |                                                                                                                                                                                                                                                 |
| 114        | Problem in Injection EEV in let temp. sensor    | <ul style="list-style-type: none"> <li>Open (Below -48.7 °C)/ Short(Over 96.2 °C)</li> <li>Soldered poorly Internal circuit error</li> </ul>                                      | <ul style="list-style-type: none"> <li>Bad connection of thermistor connector</li> <li>Defect of thermistor connector (Open/Short)</li> <li>Defect of outdoor PCB</li> </ul>                                                                    |
| 115        | Problem in Injection EEV outlet temp. sensor    | <ul style="list-style-type: none"> <li>Open (Below -48.7 °C) / Short(Over 96.2 °C)</li> <li>Soldered poorly</li> <li>Internal circuit error</li> </ul>                            | <ul style="list-style-type: none"> <li>Bad connection of thermistor connector</li> <li>Defect of thermistor connector (Open/Short)</li> <li>Defect of outdoor PCB</li> </ul>                                                                    |
| 117        | Problem in condenser-in-pipe temperature sensor | <ul style="list-style-type: none"> <li>Open / Short</li> <li>Soldered poorly</li> <li>Internal circuit error</li> </ul>                                                           | <ul style="list-style-type: none"> <li>Bad connection of thermistor connector</li> <li>Defect of thermistor connector (Open/Short)</li> <li>Defect of outdoor PCB</li> </ul>                                                                    |
| 145        | Communication error (Main PCB ↔ Sub PCB)        | <ul style="list-style-type: none"> <li>Communication line is broken</li> <li>Main PCB is broken or has wrong software</li> <li>Sub PCB is broken or has wrong software</li> </ul> | <ul style="list-style-type: none"> <li>Check condition and polarity of wire between Main PCB and Sub PCB</li> </ul>                                                                                                                             |
| 231        | Water pressure sensor problem                   | <ul style="list-style-type: none"> <li>Incorrect connection between sensor and PCB</li> <li>PCB fault</li> <li>Sensor fault</li> </ul>                                            | <ul style="list-style-type: none"> <li>Check the actual water pressure value shown on the remote controller.</li> <li>Voltage : 0.65 V at 1.0 bar (plugged)</li> <li>Refer to voltage-pressure table to check at different pressure.</li> </ul> |
| 232        | Water flow sensor problem                       | <ul style="list-style-type: none"> <li>Incorrect connection between sensor and PCB</li> <li>PCB fault</li> <li>Sensor fault</li> </ul>                                            | <ul style="list-style-type: none"> <li>Check the actual water flow rate shown on the remote controller</li> <li>Voltage : 1.22 V at 23 LPM (plugged)</li> <li>Refer to voltage-flow table to check at different flow rates</li> </ul>           |

| Error code | Title                                                                                       | Cause of error                                                                                                                                                                                                                                                                                          | Check point                                                                                                                                                                                                                                            |
|------------|---------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 233        | Problem in Solar hot water tank temperature sensor                                          | <ul style="list-style-type: none"> <li>• Open / Short</li> <li>• Soldered poorly</li> <li>• Internal circuit error</li> </ul>                                                                                                                                                                           | <ul style="list-style-type: none"> <li>• Bad connection of thermistor connector</li> <li>• Defect of thermistor connector (Open/Short)</li> <li>• Defect of indoor PCB</li> </ul>                                                                      |
| 234        | Problem in Ambient temperature sensor                                                       | <ul style="list-style-type: none"> <li>• Open / Short</li> <li>• Soldered poorly</li> <li>• Internal circuit error</li> </ul>                                                                                                                                                                           | <ul style="list-style-type: none"> <li>• Bad connection of thermistor connector</li> <li>• Defect of thermistor connector (Open/Short)</li> <li>• Defect of indoor PCB</li> </ul>                                                                      |
| 235        | Problem in Buffer tank temperature sensor                                                   | <ul style="list-style-type: none"> <li>• Open / Short</li> <li>• Soldered poorly</li> <li>• Internal circuit error</li> </ul>                                                                                                                                                                           | <ul style="list-style-type: none"> <li>• Bad connection of thermistor connector</li> <li>• Defect of thermistor connector (Open/Short)</li> <li>• Defect of indoor PCB</li> </ul>                                                                      |
| 237        | Communication modem Error in indoor unit with Flat communication method<br>*RS-485(EIA-485) | <ul style="list-style-type: none"> <li>• Communication line between outdoor and indoor unit is broken</li> <li>• Outdoor-PCB is damaged</li> <li>• Software setup is not compatible</li> <li>• Communication method is mismatching. (AC method in outdoor unit ↔ Flat method in indoor unit)</li> </ul> | <ul style="list-style-type: none"> <li>• Check condition and polarity of wire between Outdoor- and Indoor-PCB</li> <li>• Check internal wiring between terminal blocks and PCB</li> <li>• Check software versions of Outdoor and Indoor-PCB</li> </ul> |

# ANNEX

## NOTE

The sensor resistance value and the voltage value at both ends may vary depending on the ambient temperature and the value has a deviation of 5 %.  
There may be some errors depending on the measurement equipment.

### Air temperature sensors / Wall mounted air sensor (NTC 10kOhm)

| Temperature (°C) | Resistance (kΩ) | Voltage (V) |
|------------------|-----------------|-------------|
| -25              | 148             | 4.6         |
| -20              | 108             | 4.5         |
| -15              | 79              | 4.3         |
| -10              | 59              | 4.2         |
| -5               | 45              | 3.9         |
| 0                | 34              | 3.7         |
| 5                | 26              | 3.4         |
| 10               | 20              | 3.1         |
| 15               | 16              | 2.8         |
| 20               | 13              | 2.5         |
| 25               | 10              | 2.3         |
| 30               | 8               | 2.0         |
| 35               | 6               | 1.7         |
| 40               | 5               | 1.5         |
| 45               | 4               | 1.3         |

**Pipe temperature sensors / Tank temperature sensors (NTC 5 kOhm)**


| Temperature (°C) | Resistance (kΩ) | Voltage (V) |
|------------------|-----------------|-------------|
| -10              | 29.6            | 4.1         |
| -5               | 22.3            | 3.9         |
| 0                | 17.0            | 3.7         |
| 5                | 13.1            | 3.4         |
| 10               | 10.2            | 3.1         |
| 15               | 8.0             | 2.8         |
| 20               | 6.3             | 2.5         |
| 25               | 5.0             | 2.2         |
| 30               | 4.0             | 2.0         |
| 35               | 3.2             | 1.7         |
| 40               | 2.6             | 1.5         |
| 45               | 2.2             | 1.3         |
| 50               | 1.8             | 1.1         |
| 55               | 1.5             | 1.0         |
| 60               | 1.2             | 0.8         |
| 65               | 1.0             | 0.7         |
| 70               | 0.9             | 0.6         |
| 75               | 0.7             | 0.5         |
| 80               | 0.6             | 0.5         |
| 85               | 0.5             | 0.4         |
| 90               | 0.5             | 0.3         |
| 95               | 0.4             | 0.3         |

**Solar Temperature sensor (PT1000)**

| Temperature(°C) | Resistance (Ω) |
|-----------------|----------------|
| -40             | 842.47         |
| -30             | 882.11         |
| -20             | 921.57         |
| -10             | 960.86         |
| 0               | 1000           |
| 10              | 1039.03        |
| 20              | 1077.94        |
| 30              | 1116.73        |
| 40              | 1155.41        |
| 50              | 1193.97        |
| 60              | 1232.42        |
| 70              | 1270.75        |
| 80              | 1308.97        |
| 90              | 1347.07        |
| 100             | 1385.06        |
| 110             | 1422.93        |
| 120             | 1460.68        |

Flow sensor

| Flow(l/min) | Voltage(V) |
|-------------|------------|
| 5.0         | 0.50       |
| 10.0        | 0.70       |
| 15.0        | 0.90       |
| 20.0        | 1.10       |
| 25.0        | 1.30       |
| 30.0        | 1.50       |
| 35.0        | 1.70       |
| 40.0        | 1.90       |
| 45.0        | 2.10       |
| 50.0        | 2.30       |
| 55.0        | 2.50       |
| 60.0        | 2.70       |
| 65.0        | 2.90       |
| 70.0        | 3.10       |
| 75.0        | 3.30       |
| 80.0        | 3.50       |




|                                                                                                |       |                                                          |
|------------------------------------------------------------------------------------------------|-------|----------------------------------------------------------|
| PIN 1                                                                                          | Black | Power supply 5 VDC ±5%                                   |
| PIN 2                                                                                          | White | Analogue output flow 0.5 - 3.5 V correspond 5 - 80 l/min |
| PIN 3                                                                                          | Blue  | GND                                                      |
| PIN 4                                                                                          | Brown | NPN open collector, 200 pulses/Liter                     |
| PIN 5                                                                                          | -     | Not connected                                            |
| $V_{out}=1.5 \cdot P+0.5$ or $V_{in} \cdot (0.3 \cdot P+0.1)$ Where, P=Pressure Applied [MPaG] |       |                                                          |

NOTE

Supply voltage of 5VDC must be supplied between Pins 1 (black) and 3 (blue).  
Measure voltage between Pins 2 (white) and 3 (blue) and compare with chart above.

Water pressure sensor

| Pressure (bar) | Voltage(V) |
|----------------|------------|
| 0.2            | 0.53       |
| 0.4            | 0.56       |
| 0.6            | 0.59       |
| 0.8            | 0.62       |
| 1.0            | 0.65       |
| 1.2            | 0.68       |
| 1.4            | 0.71       |
| 1.6            | 0.74       |
| 1.8            | 0.77       |
| 2.0            | 0.80       |
| 2.2            | 0.83       |
| 2.4            | 0.86       |
| 2.6            | 0.89       |
| 2.8            | 0.92       |
| 3.0            | 0.95       |



|       |       |                                |
|-------|-------|--------------------------------|
| PIN 1 | Red   | Vin 5.0 ± 0.5 VDC              |
| PIN 2 | White | Vout 0.5VDC - 3.5VDC (to 3.8V) |
| PIN 3 | Black | GND                            |

NOTE

Supply voltage of 5VDC must be supplied between Pins 1 (RED) and 3 (Black). Measure voltage between Pins 2 (white) and 3 (Black) and compare with chart above.