







7	Intake air temperature sensor cover	—
6	Handle	—
5	Liquid Pipe Connection	—
4	Gas Pipe Connection	—
3	Power and communication cable connection	—
2	Control cover & SVC valve cover	—
1	Air Outlet	—
No.	Part Name	Description